



VISCOUNT

# *Legend* ‘70s

Artist - W

Artist  
Compact



User Manual - EN  
Manuale Utente - IT

---

Edition: 1.0

# IMPORTANT SAFETY INSTRUCTIONS


WARNING: READ THIS FIRST!

\*\*\*

AVIS IMPORTANT!



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



**WARNING**  
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK:  
DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE  
AND OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES,  
SHOULD NOT BE PLACED ON THIS APPARATUS.  
DO NOT REMOVE COVER (OR BACK)  
NO USER-SERVICEABLE PARTS INSIDE  
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

**ATTENTION**  
AFIN D'EVITER LES RISQUES DE FEU OU SCHOCK ÉLECTRIQUE:  
N'EXPOSÉZ PAS CET INSTRUMENT À PLUIE OU HUMIDITÉ  
NE PAS OUVRIR LE COUVERCLE (OU PANNEAU ARRIÈRE)  
L'UTILISATEUR NE PEUT EFFECTUER AUCUNE REPARATION  
POUR TOUTE REPARATION EVENTUELLE, FAIRE APPEL À  
UN PERSONNEL QUALIFIÉ

## "INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS"

### **WARNING:**

- 1) Read these instructions.
  - 2) Keep these instructions.
  - 3) Heed all warnings.
  - 4) Follow all instructions.
  - 5) Do not use this apparatus near water.
  - 6) Clean only with dry cloth.
  - 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
  - 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
  - 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
  - 10) Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
  - 11) Only use attachments/accessories specified by the manufacturer.
  - 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.  
*When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.*
  - 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
  - 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- NOTE:** The socket-outlet shall be installed near the equipment and shall be easily accessible. To completely disconnect this apparatus from the AC MAINS, disconnect the power supply cord plug from the AC receptacle.



**SAVE THESE INSTRUCTIONS**

\*\*\*

**INSTRUCTIONS A CONSERVER**

# TABLE OF CONTENTS

IMPORTANT NOTES .....	2
Product Care.....	2
Notes about this manual .....	2
INTRODUCTION.....	3
Main features .....	3
FRONT PANEL.....	5
General description.....	5
Installing modules .....	6
Main panel .....	8
Common controls.....	11
E.PIANO module .....	11
A.PIANO module .....	12
CLAVI module.....	13
SOUND COLLECTION module .....	14
EXTERNAL module .....	15
REAR PANEL.....	17
SWITCHING ON AND BASIC FUNCTIONS .....	19
Connecting to audio devices.....	19
Connecting to MIDI devices .....	20
Using a computer.....	21
Using a portable audio player .....	21
Connecting pedals .....	22
Using sounds .....	23
Using effects .....	23
PROGRAM MODE .....	25
What is a Program .....	25
Selecting a Program .....	26
Saving a Program .....	27
MODIFYING A PROGRAM.....	28
COMMON Section .....	29
KEY RANGE section.....	30
EFFECTS section .....	32
REVERB section.....	41
E.PIANO section .....	42
A.PIANO section .....	44
CLAVI section .....	45
SOUND COLLECTION section .....	46
EXTERNAL section.....	47
SONG MODE .....	48
What is a Song .....	48
Song selection .....	48
Saving a Song .....	49
MODIFYING A SONG OR LIST .....	50
PARTS function .....	50
ORDER function .....	51
COPY/PASTE function .....	51
LISTS function .....	52
SYSTEM MENU.....	53
KEYBOARD section.....	54
EQUALIZER section .....	54
MIDI section.....	55
PEDAL SETUP section .....	56
PREFERENCES section .....	57
UTILITY MENU .....	58
IDENTIFY MODULES function .....	58
BACKUP ALL function .....	59
RESTORE ALL function.....	59
FACTORY RESET function .....	60
RELEASE/UPDATE function .....	60
APPENDIX.....	62
Quick functions .....	62
Error messages .....	62
Troubleshooting .....	64
List of effect presets.....	64
List of Sound Collection sounds.....	65
MIDI Informations.....	MIDI - 1

## IMPORTANT NOTES

### Product Care

- Do not apply excessive force to the instrument's structures and controls (knobs, buttons, keyboard etc...).
- Whenever possible, do not place the instrument close to units that generate strong interference, such as radio - TV sets, monitors, etc ...
- Do not place the instrument close to heat sources, in damp or dusty places or in the vicinity of strong magnetic fields.
- Do not expose the instrument to direct sunlight.
- Never insert foreign bodies or liquids of any kind into the instrument.
- For cleaning use only a soft brush or compressed air; never use detergents, solvents or alcohol.
- Always use good quality screened cables for connection to amplification or diffusion systems. When disconnecting cables from sockets, always take hold of the connector and not the cable itself; when winding cables do not knot or twist them.
- Before making connections make sure that the other units you are about to connect (especially amplification and diffusion systems) are switched off. This will prevent noisy or even dangerous signal peaks.
- Connect the net cable to an earthed socket.
- Check that the voltage corresponds to the voltage shown on the serial number plate of the organ.
- If the instrument is to be out of use for long periods, disconnect the power cable from the power socket.
- Do not place the power cord near heat sources. Do not bend the cable too much, or damage it.

### Notes about this manual

- Keep this manual with care.
- This manual is an integral part of the instrument. The descriptions and illustrations contained in this publication are not binding.
- While the instrument's essential characteristics remain the same, the manufacturer reserves the right to make any modifications to parts, details or accessories considered appropriate to improve the product or for requirements of a constructional or commercial nature, at any time and without undertaking to update this publication immediately.
- All rights reserved; the reproduction of any part of this manual, in any form, without the manufacturer's specific written permission, is forbidden.
- All the trademarks referred to in this manual are the property of the respective manufacturers.
- Please read all the information carefully, so that you obtain the best performance and will from your instrument.
- The codes or numbers in square brackets ([ ]) indicate the names of the buttons, sliders, trimmers and connectors on the instrument. For example, [ON/OFF] refers to the ON/OFF button.
- The illustrations are purely for information purposes and may differ from your product.
- The instructions provided in this manual only concern the instrument's operating system version that was up to date when the document was released. Therefore, such instructions might not describe faithfully your current operating system release.
- Please, visit the website [www.viscountinstruments.com](http://www.viscountinstruments.com) to check for the newest operating system release and manual.

This user manual is updated to version 1.00 of the instrument's operating system.

# INTRODUCTION

## Main features

*Legend '70s* has been designed to resemble to the 'legendary' electric pianos of the 70's, while simulating all the typical sounds of the music scene of that decade. Beside being a vintage instrument, *Lenged '70s* also offers all the features of a modern stage piano and easily adapts to the needs of the musician in different situations and environments.

However, *Legend '70s* is not just a revamp of famous and classical instruments. For the first time in the world of stage pianos, *Legend '70s* introduces the concept of modularity and scalability, offering the musician, unlike all other digital pianos on the market, the opportunity to choose the configuration that best suits your needs, in the times and ways you want.

- **Vintage Piano Feeling**

*Legend '70s* has the typical vintage look from the past decades, making it stand out immediately on the stage. The vintage style, with its black and glossy finish, combined with the aluminium decorative elements, is a tribute to the most iconic electric piano, the protagonist on the stage of the early '70s.

Furthermore, the broad flat surface of the instrument can be used to fit other devices, such as a keyboard, a tablet, a laptop or all of them. This particular shape was designed during the project stage and represent an extra feature that responds to the need of the musician, making *Legend '70s* even more competitive. However, this does not increase the weight or compromise the portability of the instrument.

The optional adjustable keyboard stand comes with aluminium legs, and completes the vintage looks that even the most nostalgic musicians will appreciate.

- **The power of the stage piano**

*Legend '70s* looks like a vintage electric piano, but has all the features of a modern stage piano. It contains a wide array of sounds, such as acoustic and electric piano, strings, pads, bass guitars, guitars, brass, organs, choir, and many others, all thanks to the sound generation models installed in the instrument. Sounds can be assigned to different areas of the keyboard, according to the set range for each sound or, more simply, to the Lower and Upper sections of the keyboard by using the Split function. This, together with a complex chain of effects of the highest quality, allows the musician to recreate any sound.

*Legend '70s* offers all the typical stage piano features, such as general and section transposition, fine tuning, several velocity curves to choose from and velocity options. The instrument also has advanced Master-keyboard functions, to control external devices connected through the MIDI and USB ports.

The wide range of adjustable panel controls allow a quick access to all the main functions while playing. The pitch bend and modulation wheels can be used for a memorable performance.

- **The flexibility of a modular piano**

*Legend '70s* is the first instrument ever to use the concept of modular piano. The musician can now choose the sound generation models as they wish, allowing for a greater flexibility.

The instrument has a wide front panel with one main section and some mobile sections that can be installed in their dedicated slots, also called "modules". Thanks to the instrument's accurate design, the musician can access the single slots easily and quickly, installing their favourite module in the preferred slot and changing the setup at will.

These modules are equipped with state-of-the-art sound generation technology and a dedicated interface to offer the best performance for every sound family. Each module allows easy access to the main controls, placed ergonomically for a quick sound configuration.

- **High-quality sounds and effects**

The sounds of the *Legend '70s* have been developed by studying the physics and functioning of the original instrument, in order to simulate it as closely as possible. The electric piano sounds are the top achievement of the physical modeling technology, the **Viscount PM (Physical Modeling)**. It consists of mathematical models that represent the physics at work behind the instrument: how it was originally built and how it generates sound.

Other sound families, such as acoustic pianos, brass, strings, organs, bass, etc. use the **Viscount HDS (High Definition Sampling)** technology. It is a system that employs the best multi-sampling techniques to recreate the sound wave in real time, according to the pitch and velocity of each note. At the same time, high-quality filters applied to the audio samples create a rich authentic a realistic sound.

Beside the excellent sounds, *Legend '70s* also features a whole section of effects designed specifically for this instrument. There are classical effects such as tremolo, vibrato, chorus, flanger, phaser, wah, and the more common effects such as reverb, delay, equalizer, compression and a wide range of amplifiers. All effects were designed to recreate the sound of the legendary hits from the '70s.

### • Keyboard and velocity curve

All models are equipped with a high quality hammer action keyboard that reproduces faithfully the velocity sensitivity of the original electric pianos. Each key has three sensors that detect its movement with high precision.

The *Artist-W* model was developed for the most demanding musicians. It features a graduated hammer adjustment: hammers are heavier in the lower section of the keyboard and they get gradually lighter as they move up the keyboard. Furthermore, the *Artist-W* keys are made of real wood, just like acoustic pianos. The wood for this keyboard is carefully selected and seasoned to avoid flaws and bending and deformations through time.

The keyboard sensitivity to the touch can be customised by selecting one of the available velocity curves. The sounds can play throughout the keyboard or be assigned to a specific area of the keyboard in order to play different sounds with the left and right hand.

### • High connectivity

The instrument is equipped with four analog line outputs and one analog audio input. It features a USB Audio / MIDI interface which, with a single USB cable, allows you to receive and then reproduce the audio source of the connected device or a virtual instrument controlled by *Legend '70s*. The instrument is also equipped with the usual 5 pin DIN connectors to connect external MIDI devices.

Up to six pedals can be connected to the instrument: one to select the Programs, one working as Sustain pedal and four more pedals that can be assigned to different functions. A USB flash drive can be used to save and load programs and settings, and also to update the operating system. The USB connector can also be used to charge different devices like smartphones and tablets.

### • Editing Software


A dedicated editing software was designed to set all the *Legend '70s* parameters quickly and easily. The most demanding users can also use the software to modify parameters that cannot be adjusted through the main panel, for an extra fine tuning of sounds and effects. The customised settings can be saved and loaded at will.

The software runs on Windows, Mac Os and iOS, and can be downloaded for free from the Viscount website [www.viscountinstruments.com](http://www.viscountinstruments.com).

## FRONT PANEL

### General description

The front panel consists of a main section and additional modules ad described on page 3.



**NB**

- The image above refers to the Artist-W and Artist models equipped with all modules. The modules are the same for each model. The only difference is that up to 5 models can be installed on Artist-W and Artist, while the Compact model supports only 4 modules.
- The arrangement and number of modules in the image and on the display screens shown in the manual are for information purposes only as they can be freely rearranged by the user.

**1 Main section (page 8).**

This section contains all the main volume and equalizer controls of the instruments, effects controls, Program and Song selection controls, together with all the general parameters and settings.

**2 E.PIANO module (page 11).**

This module selects and controls the electric piano sounds.

**3 A.PIANO module (page 12).**

This module selects and controls the acoustic piano sounds.

**4 CLAVI module (page 13).**

This module selects and controls the Clavinet sounds.


**5 SOUND COLLECTION module (page 14).**

This module selects and controls pad, strings, choir, brass, keyboard, organ, bass and other sounds.

**6 EXTERNAL module (page 15).**

This module controls external MIDI devices.

### Wheels




To the left of the keyboard you will find two wheels that modify the sound in real time.

The Pitch Bend wheel **1** automatically returns to the centre and controls the sound pitch.

The wheel **2**, although normally assigned to modulation control, is programmable and assignable to various functions (see the *Mod.Wheel Dest* parameter, page 29).

## Headphones connector



On the left side of the instrument, under the keyboard, you will find a 1/4" jack connector to plug in your headphones.

**NB**

- Keep in mind that using headphones at a sufficiently high volume level may cause hearing loss.
- Connecting headphones does not affect the signal sent to the AUDIO OUT MAIN [L/MONO], [R] and AUX [1], [2] outputs of the rear panel (see page 17).


## Installing modules

As already mentioned, the *Legend '70s* front panel consists of a main section that comes already been installed and of other additional modules. If no additional module has been installed, this part of the instrument will be covered by empty panels. These are the slots for the placement of modules





Follow this procedure to install a module:

1. First make sure that the instrument is switched off, and that the power cable is plugged off.
2. Unscrew the screw on the cover bar, located between the top of the instrument and the front panel, then remove the bar. Keep the screw ready at hand, as they will be necessary to fasten the bar at the end of the procedure (Fig. A).


Fig. A



3. Unscrew the two screws located in the slot where you wish to install the module, then remove the slot cover. Keep the screw ready at hand, as they will be necessary to fasten the module at the end of the procedure (Fig. B).
4. Connect the flat-cable to connector (1) on the slot and connector (2) on the module. The cable can be found in the module box (Fig. C).
5. Place the module on the front panel by first inserting the teeth on the bottom of the module inside the tracks on the lower part of the panel (Fig. D).
6. Fasten the module to the front panel by using the screws described at point 3 (Fig. E).




7. Fasten the bar to the top of the instrument and to the front panel by using the screws described at point 2.

**NB**

- Each time you change the position of the modules, please use the Identify Modules function described on page 58.
- It is not possible to install two or more modules of the same type.

## Main panel

The main panel is the fixed section of the instrument. Here you can find the general volume, a three-band equalizer section, a reverb section, effect controls and a section that controls all the parameters that appear on the display, i.e. sounds, effects and system parameters.



### Volume control and EQUALIZER section

#### 1 [MASTER VOLUME] knob.

This knob controls the instrument's general volume.

#### 2 EQUALIZER [LOW], [MID] and [HIGH] slider.

This slider controls the general equalizer. Each slider has a gain range between -12 dB and +12 dB for [LOW], [MID] and [HIGH] frequencies. The equalizer affects the stereo signal on the MAIN [L/MONO] and [R] outputs and the headphones output. The AUX [1] and [2] outputs are unaffected by this control.

The equalizer can be adjusted in several ways by accessing the dedicated controls through the display. For further information on this subject, read the *Equalizer Section* (page 54).

### REVERB section

This section on the main panel includes the main controls of the reverb effect.

The reverb effect affects the stereo signal on the MAIN [L/MONO] and [R] outputs and the headphones output. The AUX [1] and [2] outputs are unaffected by this effect.

The reverb can be adjusted in several ways by accessing the dedicated controls through the display. For further information on this subject, read the *Reverb section* (page 41).

#### 3 This knob selects the reverb style.

Available reverb styles are:

Reverb	Description
Room	Simulates the reverb of a room.
Hall	Simulates the acoustics of a concert hall.
Stage	Simulates the acoustics of a concert stage.
Plate	Simulates the reverb created by a metal plate, which was very common in the '70s.
Spring	Simulates the reverb created by a spring mechanism, as used in the amplifiers during the '70s.
Tape	Simulates the reverb produced by a tape recorder and a reverb chamber

#### NB

- Press this knob to select the reverb type of the selected category.
- Press and hold the knob for a short while to access the reverb parameters.

#### 4 [DRY / WET] knob.

Balances the direct and reverberated signal.

#### 5 [REV ON] button.

Reverb On / Off switch.

## EFFECT section controls

This section includes the main controls of the effects. There are two available, independent effects. They have the same set of controls but different values. When one of the two effects is selected, the control Leds of this section are updated according to the settings of the currently selected effect.

The display shows several parameters to adjust the effect. For further information read the *Effects section* (page 32).

### 6 Effect type selection knob.

Available effect types:

Effect	Description
Tremolo	Tremolo or vibrato effect. Rotate the [AMOUNT] knob to adjust the effect depth. Rotate the [RATE] knob or press the [TAP] button to set the modulation speed.
Chorus	Chorus effect. Rotate the [AMOUNT] knob to adjust the effect amount. Rotate the [RATE] knob or press the [TAP] button to set the modulation speed.
Flanger	Flanger effect. Rotate the [AMOUNT] knob to adjust the effect amount. Rotate the [RATE] knob or press the [TAP] button to set the modulation speed.
Phaser	Phaser effect. Rotate the [AMOUNT] knob to adjust the effect feedback. Rotate the [RATE] knob or press the [TAP] button to set the modulation speed.
Wah	Wah-wah effect. Rotate the [AMOUNT] knob to adjust the filter's resonance. The [RATE] and the [TAP] button can adjust different parameters according to the currently selected Wah effect.
Amp	Amplifier effect. Rotate the [AMOUNT] knob to adjust the distortion. Rotate the [RATE] knob to set the output level of the effect. When the Rotary effect is selected, the [RATE] knob selects the rotation speed (Slow-Fast) while the [TAP] button stops the rotation (Brake).
Delay	Delay effect. Rotate the [AMOUNT] knob to adjust the effect amount. Rotate the [RATE] knob or press the [TAP] button to set the time span between the repetitions of the signal.
Others	Various effects (equalizers, compressors, etc.). For further information read the <i>Effects section</i> (page 32).

**NB**

- Press this knob to select the effect type.
- Press the knob for a short while to access the effect parameters.

### 7 Effect selection buttons.

As described in the introduction to this section, there are two available effects. To select one and adjust its parameters through the panel controls in this section, press the buttons [1] and [2]. When one of the two effects is selected, the Led lights of this section's controls are updated according to the settings of the currently selected effect. The blinking Led of button [1] or [2] indicates that though that effect is not selected, it is still active.

### 8 [AMOUNT] knob.

Use this knob to adjust the effect intensity. For further information on the parameters that can be controlled by this knob, read point 6 in this section or the *Effects section* (page 32).

### 9 [TAP] button.

Press this button to set the tempo or modulation frequency manually. Tap the tempo on the button at least four times to set the value manually. The [RATE] knob Led will blink at the speed calculated from your tapping (see point 10). For further information on the parameters that can be controlled by this knob, read point 6 in this section or the *Effects section* (page 32).

### 10 [RATE] knob.

Set the modulation speed for the selected effect. The Led on this control blinks at the selected speed. For further information on the parameters that can be controlled by this knob, read point 6 in this section or the *Effects section* (page 32).

**NB**

- The light of the [RATE] knob is switched off when the effect is inactive, or when using specific effect types.
- When the Rotary effect is selected, the light blinks at either a slow or fast speed, depending on the currently selected Rotary speed (Slow or Fast). The led does not blink when the Rotary is in Brake position.

**11 [FX ON] button.**

Press this button to switch on / off the selected effect.

**NB**

To assign a module output to the selected effect, press the [FX ON] and the [ON/OFF] buttons simultaneously on that module. The pairing between module and effect is indicated by the [FX 1] and [FX 2] Leds on each module.

**12 Leds for the effect settings FX1 and FX2** (page 32, parameter *Effects Config*).

- [PAR]: the effects FX1 and FX2 are in parallel.
- [SER]: effects FX1 and FX2 have a serial link (FX1 output enters FX2 input).

## PROGRAM section controls

The PROGRAM section allows the user to save and recall programs, to access the Song mode and the keyboard Split function. This section includes menus that allow access to all the instrument and system configuration parameters.

**13 [SET] buttons.**

Buttons for immediate selection of four Programs of your choice (page 26) or of the four parts of the Song (page 48).

**14 [SONG MODE] / [SYSTEM] button.**

Press this button once to recall the Song mode. For further information read *Song Mode* (page 48).

Press this button for a short while to access the *SYSTEM* menu on the display, which includes all the instrument's general settings. For further information read *Menu System* (page 53).

**15 [EDIT] / [STORE] button.**

Press this button once to access the *EDIT* menu for the current mode (either Song or Program). Use this menu to adjust all the parameters of a Program or Song.

Press the button for a short while to access the Program or Song save function.

**16 [<] and [>] buttons.**

Use this buttons to select the Program bank from the main screen, or to move the cursor up/left or down/right respectively.

**17 [SPLIT] button.**

Push this button to activate the Split function. It divides the keyboard in two parts, so as to play different sounds with the left and right hand (see page 29, *Split Mode* parameter). The Split Point marks the division between the two parts of the keyboard. It can be set by the user (see parameter *Split Point*, page 29).

**NB**

- While pressing the [SPLIT] button, push the [ON/OFF] button on a module to assign that module to the Lower or Upper part of the keyboard (press again to switch between the two sections).
- Press a key on the keyboard while pushing the [SPLIT] button to set the Split Point.

**18 [EXIT] button.**

Press this button to quit the current video page or to refuse a system request.

**19 Display.**

OLED monochrome display, 128x64 pixel. The display shows all the instrument's settings.

**20 Data entry dial and access / confirm button.**

Use this dial to select a Program or Song, to move the cursor on menus, to set parameter values, to select a character to write Program or Song names.


Press the dial to access video pages or confirm system requests.

## Common controls

On the left part of any module there are controls shared by all modules: On/Off button, volume knob and status Led lights.

### 1 [ON / OFF] button.

Switches on/off the sound generated by the module (or the part of the module, if it is comprised of multiple parts). When the Led light of this button is on, the module is active and can receive data from the keyboard.



### 2 [VOLUME] knob.

Adjusts the volume of the sound generated by the module (or the part of the module, if it is comprised of multiple parts).

### 3 Status Leds.


These Led lights show the status of several sound generation parameters. When the Led light is on:

- **[FX1]**: the Split function is active (page 29, parameter *Split Mode*) and the sound is assigned to the Lower part of the keyboard. You can activate the Split function and assign the sound to the lower section by pushing [SPLIT] and the module [ON/OFF] button simultaneously. Once the sound has been assigned, press [SPLIT] and [ON/OFF] (on the module) again, to assign the sound to the Upper section.
- **[FX2]**: the sound is currently transposed (page 42, parameter *Note Shift*).
- **[FX3]**: the module output signal is assigned to the effect FX1 (page 42, parameter *Output Routing*). To assign an effect, select the FX1 effect (to do so, press the [FX 1] button under the EFFECTS section) then, while pressing [FX ON], push the [ON/OFF] button on the module. Once the effect has been assigned, press [FX ON] and [ON/OFF] again to undo.
- **[FX4]**: the module output signal is assigned to effect FX2 (page 42, parameter *Output Routing*). To assign an effect, select the FX2 effect (to do so, press the [FX 2] button under the EFFECTS section) then, while pressing [FX ON], push the [ON/OFF] button on the module. Once the effect has been assigned, press [FX ON] and [ON/OFF] again to undo.

## E.PIANO module

The E.Piano module allows the user to customise the electric piano sounds (Rhodes, Wurlitzer and CP80). This module is the state of the art of the **Viscount PM technology (Physical Modeling)**. Thanks to complex algorithms, the instrument can reproduce faithfully the dynamic and physic-acoustic features of the electric piano, recreating the original sound with all its nuances. The module is also equipped with dedicated effects: the classic Tremolo, and an Amplifier simulator that recreates the sound of different kinds of amps.

Panel controls are further expanded by many other parameters that can be modified through the *EDIT PROGRAM* menu (see *E.Piano* section, page 42) and by the *Legend '70s Editor*



### NB

Controls 1, 2 and 3 are further described under the Common controls section at page 11

### 4 Sound selector

Use this control to select an electric piano sound.

Position	Description
Rhod 1, Rhod 2, Rhod 3, Rhod 4, Rhod 5	Rhodes electric piano simulator.
Wurl 1, Wurl 2	Wurlitzer electric piano simulator.
E.Grand	Electric grand piano CP-80 simulator.

**NB**

Press and hold the knob for a short while to access the module configuration parameters.

**5 [BASS] knob.**

Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the E.PIANO module.

**6 [TREBLE] knob.**

Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the E.PIANO module.

**7 [INTENSITY] knob.**

Set the modulation depth for the Tremolo effect applied to the E.PIANO module.

**8 [SPEED] knob.**

Set the modulation speed of the Tremolo effect applied to the E.PIANO module. This control has a Led light that blinks at the frequency set through the knob.

**NB**

The [SPEED] knob light is off when the Tremolo is inactive.

**9 [TREM ON] button.**

On/Off switch of the Tremolo effect

**[NB**

Press and hold the [TREM ON] button to activate the Tremolo effect and to access the modulation waveform parameter.

**10 [AMP ON] button.**

Switch on / off the Amplifier effect.


**NB**

Press the [AMP ON] button for a short while to access the Amp effect parameters.

## A.PIANO module

The A.PIANO module comprises a collection of acoustic piano sounds: grand pianos, baby grand pianos and upright pianos. This module uses the **Viscount HDS (High Definition Sampling)** technology. It is an advanced multi-sampling technology that ensures a faithful and authentic reproduction of the original sounds.

The module also comprises dynamic range and brilliance controls, that adjust the sound in real time, during the performance. Panel controls are further expanded by many other parameters that can be modified through the *EDIT PROGRAM* menu (see *A.Piano section*, page 44) and through the *Legend '70s Editor App*.

**NB**

Controls 1, 2 and 3 are further described under the Common controls section at page 11.

#### 4 Sound selector

Use this control to select an acoustic piano sound.

**NB**

Press and hold the knob for a short while to access the module's parameter configuration screen

#### 5 [DYNAMIC] knob.

Set the dynamic range of the acoustic piano: decrease (negative values) or increase (positive value) the difference between pianissimo and fortissimo.

#### 6 [BRILLIANCE] knob.

Set the sound brilliance. Set the knob in its central position for a perfectly balanced sound.

Turn the knob counter-clockwise (negative values) to dampen high frequencies, for a less brilliant sound.

Turn the knob clockwise (positive values) to increase high frequencies, for a more brilliant sound.


## CLAVI module

The CLAVI module is dedicated to one of the most renowned electric pianos of the '70: the Clavinet.

This module applies the **Viscount PM technology (Physical Modeling)** to reproduce faithfully and precisely the distinctive and brilliant sound of this instrument, the top icon of funky music.

Panel controls are further expanded by many other parameters that can be modified through the EDIT PROGRAM menu (see *Clavi section*, page 45) and by the *Legend '70s Editor* application.

The module includes the two most famous models of this instrument, together with the classic equalizer and pickup configuration controls.


**NB**

Controls 1, 2 and 3 are further described under the Common controls section at page 11.

#### 4 These buttons activate the equalization filters.

Button	Description
[BRILLIANT]	High-pass filter that increases brilliance.
[TREBLE]	A Band-pass filter that enhances high frequencies.
[MEDIUM]	A low-pass filter, with a cutoff frequency in the middle range.
[SOFT]	A low-pass filter that generates a softer and darker sound.

#### 5 Pickup selection buttons.

The led light indicates the D and B positions. As in the original instrument, the [A B] button is used to select the pickup, while [C D] selects the phase relationship between the two. Here is a description of the four available combinations:

Combination	Description
C A	Lower pickup only, full sound
C B	Upper pickup only, for a thinner, percussive sound.
D B	Both pickups, for a richer sound.
D A	Both pickups but with opposite phase, for a thin, nasal sound.

#### 6 Model selection buttons.

Select one of the two Clavinet models.

Button	Description
[Clavi 1]	Clavinet D6 simulator.
[Clavi 2]	Clavinet E7 simulator.

**NB**

Press and hold one of these buttons for a short while to access the module configuration parameters.

#### 7 [MUTE] button.

Select the maximum position of the attenuation felt (Sliding Damper) that, when the Led light is on, decreases the decay time of the sound.

**NB**

Press the button for a short while to activate the Mute. The display will show the decay time control.


## SOUND COLLECTION module

The SOUND COLLECTION module includes a wide array of different sounds, reproducing the most commonly used instruments that all musicians need.

Thanks to the **Viscount HDS (High Definition Sampling)** technology, each instrument has been accurately sampled with several different dynamics, in order to better recreate the variety in dynamics and tone of the original instruments. The sampled instruments are therefore realistic and rich in definition. These sounds are divided into 8 groups: Pad, Strings, Choir, Brass, Keys, Organ, Bass and Others.

The module is comprised of two different parts. Each can be recalled with the respective selection button.

Panel controls are further expanded by many other parameters that can be modified through the *EDIT PROGRAM* menu (see Sound Collection section at page 46) and through the *Legend '70s Editor* application.


**NB**

Controls 1, 2 and 3 are further described under the Common controls section at page 11.

#### 4 Sound category selector.

Use this control to select the sound category, that can then be recalled through the knob described at point 6.

Position	Description
Pad	Synth Pad
Strings	Acoustic and synthesized bowed instruments.
Choir	Choirs
Brass	Acoustic or synthesized brass instruments.
Keys	Acoustic and electronic pianos, synths, accordions.
Organ	Electric, electromechanic and pipe organs.
Bass	Acoustic, electric and synthesized bass.
Others	Various kinds of instruments.

**NB**

Press and hold the knob for a short while to access the module configuration parameters.

### 5 Part selection buttons.

As described in the introduction, this module is comprised of two different parts. To select a part, so as to access its main parameters through the panel controls, press button [1] or [2]. When a part is selected, the controls' led lights and the adjustable parameters are set according to the currently selected part.

**NB**

*A blinking light on buttons [1] or [2] indicates that the part, though not currently selected, is active.*

### 6 Sound selector

Use this control to recall a sound belonging to the sound group (selected by the knob described at point 4). The display shows the digit corresponding to the selected sound (point 7) while the name of the sound appears on the main panel display.

### 7 Sound display

Displays the sound selected through the knob described at point 6.

### 8 Generation parameter knobs.

These three knobs control three sound generation parameters. The parameter controlled by each knob depends on the currently selected sound. For further information on the adjustable parameters see page 46.


## EXTERNAL module

The EXTERNAL module allows real-time control of external MIDI devices connected to the instrument through the MIDI or USB [TO HOST] connectors. Like the sound generation modules, it can be activated / deactivated and assigned to keyboard parts.

This module allows an easy access to the advanced master keyboard functions of the instrument.

The module is comprised of two different, independent parts, that can be recalled by pressing two buttons on the panel. These two parts can both be active at the same time and can be combined in layer or split modes. Panel controls are further expanded by many other parameters that can be modified through the *EDIT PROGRAM* menu (see *External section*, page 47) and through the *Legend '70s Editor App*.

Whether the module is present or not, all master keyboard functions of the instrument are still available, since the External function is an integral part of *Legend '70s*. Without the dedicated module, all the functions connected to the control of external devices can be accessed through the *EDIT PROGRAM* menu.


**NOTE**

*Further information on the controls described at points 1, 2 and 3 can be found on page 11. The Led lights described at point 3 are not available, since this module is not a sound generation module and, as such, it does not have [FX1] or [FX2].*

### 4 MIDI parameter knob.

Use this knob to select a MIDI parameter, so as to send it out or adjust it through the knob at point 6.

Parameter	Description
Port	MIDI message transmission port
Channel	MIDI message transmission channel
LSB Bank	Bank Select LSB message transmission
MSB Bank	Bank Select MSB message transmission
Prg Change	Program Change message transmission
Ctrl 1 CC	Control Change 1 assigned to the [CTRL 1] knob
Ctrl 2 CC	Control Change 2 assigned to the [CTRL 2] knob
Ctrl 3 CC	Control Change 3 assigned to the [CTRL 3] knob

**NB**

*Press and hold the knob for a short while to access the module configuration parameters.*

**5 Part selection buttons**

These buttons select one of the two module parts. When one of the two parts is selected, the module controls are updated according to the selected part. The blinking light of buttons [1] or [2] indicates that the part, though not currently selected, is active.

**6 Value display.**

Displays the value controlled by the knob described at point 7.


**7 Value control knob.**

This knob controls the MIDI parameter selected through the knob described at point 1.

**8 Control Change transmission knob.**

Use this knob to transmit the Control Change message, assigned through the control described at point 1.

## REAR PANEL



**1 [AUDIO IN] mini jack.**

Standard mini jack audio input, stereo, 1/8". Use to connect to external devices such as smartphones, tablets or computers. The signal on this input is then sent to the headphones output and to the AUDIO OUT MAIN [L/MONO] and [R] outputs. This signal is not affected by the [MASTER VOLUME] knob on the front panel. Use this knob to mix different signals from *Legend '70s* and external audio devices.

**2 AUDIO OUT [AUX 1] and [AUX 2] jacks.**


Standard 1/4" auxiliary mono audio outputs that transmit the signal from *Legend '70s*. The modules or effects output can be routed to the auxiliaries audio outputs instead of the main outputs, either stereo or mono (see the *Output Routing* parameter, page 32 and 42).

**3 AUDIO OUT [MAIN L/MONO] and [MAIN R] jacks.**

Standard 1/4" mono audio outputs that transmit the signal from *Legend '70s*. The modules and effects outputs are sent to the main outputs by default. However, they can be re-routed to the auxiliary outputs (see *Output Routing* parameter, page 32 and 42). When using a mono speaker, only connect the [MAIN L/MONO] jack.

**NOTES ON THE AUDIO OUTPUTS**

- The signal on the AUDIO OUT AUX outputs is not affected by the general equalizer (see point 2, page 8) or by the Reverb effect (see point 3 page 8).
- Connect the cables while the speakers and the instrument are switched off. Then switch on the instrument first and eventually the speakers.
- Balanced cables are recommended for audio outputs.



**4 [PROGRAM + / -] PEDAL jack.**

Use a stereo jack to connect this to a foot switch with two switches. One switch selects the previous Program, the other goes to the next. The two-switch pedal can be used to select the next and previous Program (also inside Songs). It is also possible to connect a one-button footswitch with a mono jack. Doing so, the foot switch will select only the next or previous Program, according to the currently selected operating mode (see *Program +/- Type*, page 57).

**5 [SUSTAIN] PEDAL jack.**

Use a mono jack to connect this to a foot switch to control the Sustain effect; use a Half-Damper pedal to play with the half-pedaling technique, or the Studiologic SLP3-D triple pedal to play with three pedals like an acoustic piano. To ensure that the pedal works properly, manually select the pedal type on the instrument (see *Sustain Type* parameter, page 56).

**6 [FOOT SWITCH 1] and [FOOT SWITCH 2] PEDAL jacks.**

Connect to a foot switch through a mono jack to control a selected function (see *FS1 Dest* and *FS2 Dest* parameters, page 29).

**7 [FOOT CONTROLLER 1] and [FOOT CONTROLLER 2] PEDAL jack.**

Connect to a foot controller to *control a selected function* (see *FC1 Dest* and *FC2 Dest* parameters, page 28).

**NOTES ABOUT PEDALS**

- When using Foot switch pedals, the polarity must be set manually (see Sustain Polarity, FS1 Polarity, FS2 Polarity and Progr +/- Polarity, page 56).
- When using foot controller pedals, the user must select the correct pedal type (see FC1 Type and FC2 Type parameters, page 56).
- For further information on connecting and using pedals, see Pedal connection, page 22.

**8 MIDI [OUT] port.**

This connector sends the MIDI data generated by *Legend '70s*. Connect it to the MIDI input connector of the receiving device.

**9 MIDI [IN] port.**

This connector receives MIDI data from an external unit that can play and control *Legend '70s*. Connect this port to the MIDI output of the transmitting device (e.g. keyboard, master controller, sequencer).

**NB**

For further information on *Legend '70s* MIDI interface refer to the MIDI Informations section, page *MIDI - 1*.

**10 USB [TO HOST] port.**

Use this port to connect a tablet or a computer via USB cable. Use this port to send and receive USB MIDI data, connect with the *Legend '70s Editor* application and receive USB Audio stereo signal, that can be played through the outputs **AUDIO OUT MAIN [L/MONO]** and **[R]**.

**NB**

- Use USB cables type A/B.
- *Legend '70s* can receive audio signal via USB cable on two channels (1 stereo channel) with a sampling frequency of 44.1 kHz.
- Computers running Microsoft Windows as operating system need a USB driver. This driver is automatically installed when connecting the instrument to the computer for the first time. Follow the instructions on the computer to complete the installation.

**11 USB [TO DEVICE] port.**

Use this port to connect a USB flash drive. The USB drive can be used to save and load settings and programs, and to update the operating system.

**NB**

- Only use flash drives using the FAT or FAT32 file system (no NTFS or other).
- This connector can also be used to charge various devices such as tablets or smartphones. The charge function can be activated on the display through the **USB to Device** parameter, described on page 57.

**12 [POWER] switch.**

On / off switch.

**13 [MAINS AC-IN] connector**

Use this connector to plug the power cable included with the instrument.

# SWITCHING ON AND BASIC FUNCTIONS

To switch on the instrument, please follow these simple rules

1. Make sure that the [POWER] switch on the rear panel is set to 0.
2. Make sure that all connected speakers or amplifiers (if any) are switched off.
3. Connect the included power cable to the instrument.
4. Turn the [MASTER VOLUME] knob counter-clockwise all the way to the lowest value (mute).
5. If headphones are connected, do not wear them.
6. Switch on the instrument by pressing the [POWER] switch.
7. Switch on any connected speaker or amplifier.
8. Adjust the instrument volume through the [MASTER VOLUME] knob.

To switch off the instrument, follow this procedure:

1. Turn the [MASTER VOLUME] knob counter-clockwise all the way to the lowest value (no volume).
2. Switch off any connected speaker or amplifier.
3. Switch off the instrument by pressing the [POWER] switch.

**NB**

- Only use the AC power cable provided with the instrument. Using an incorrect cable may cause overheating or electric shock.
- The cable provided with Legend '70s must not be used with other electrical appliances. Not following this precaution may cause damage to electrical devices or cause fire.
- If the instrument is to be out of use for long periods, disconnect the plug from the power socket.
- The instrument can also be programmed to switch off automatically when idle for a certain period of time. To do so, activate the Auto Power Off function, page [57](#).

## Connecting to audio devices

Legend '70s is not equipped with internal loudspeakers. In order to produce sound, it must be connected to external audio devices, such as amplifiers, loudspeakers or headphones connected to the jack (located under the keyboard to the left). Legend '70s offers several ways to connect with external diffusors. Here are a couple of examples. Follow the illustrations to make the connection according to your needs.


### Connection with amplifiers or amplified speakers

Use a pair of amplified speakers (or amplifiers with a line input) to play Legend '70s.

This connection needs two audio cables with mono jack 1/4" connectors. Plug the jacks into the AUDIO OUT MAIN [L/MONO] and [R] outputs on the rear panel of the instrument, and into the amplifiers' inputs, as in the image.

To play with a single amplifier (or amplified speaker) only use the AUDIO OUT MAIN [L/MONO] connector.


Legend '70s is equipped with two auxiliary outputs: AUDIO OUT AUX [1] and [2]. These can be used in conjunction with MAIN outputs. Each module or effect can be assigned to an audio output (see *Output Routing* parameter, page [32](#) and [42](#)).



## Connecting to a mixer

When recording or performing live, it might be necessary to connect the instruments to an audio mixer, which then sends the signal to amplifiers or amplified speakers. To do so, connect the AUDIO OUT MAIN [L/MONO] and [R] outputs on the rear panel to the inputs of the mixer channels through two audio cables with mono 1/4" jacks, as in the image. To send the instrument's monophonic signal to a single mixer channel, only use the AUDIO OUT MAIN [L/MONO] connector.

*Legend '70s* is also equipped with two auxiliary outputs: AUDIO OUT AUX [1] and [2]. These can be used in conjunction with MAIN outputs. Each module or effect can be assigned to an audio output (see *Output Routing* parameter, page 32 and 42).



## Connecting to MIDI devices

Use standard MIDI cables to connect *Legend '70s* to other MIDI devices, such as synthesizers or audio modules (expanders). Connect the MIDI [IN] and [OUT] ports of *Legend '70s* to the MIDI ports of the external devices to exchange MIDI data.

**NB**


To exchange MIDI data through the MIDI [IN] and [OUT] connectors, first activate the respective MIDI ports (see parameter Control Port, page 55).

## Controlling an external sound generator

Connect the MIDI [OUT] connector on *Legend '70s* to the MIDI IN terminal of an external sound generator (synthesizer, expander, etc.) with a USB cable to play the sounds of the external generator with the *Legend '70s* keyboard.

Use the EXTERNAL section (page 15) to split the keyboard in two sections, each of which is assigned to a different sound. When doing so, sounds from other MIDI devices can be played together with *Legend '70s* sounds.

When the EXTERNAL section is not in use, controls and notes are still transmitted to the general channel (see *Global Channel* parameter, page 55) on the whole keyboard.


**NB**


To play an external sound generator, the corresponding receiving channel must correspond to the one set through the Global Channel parameter (page 55) or on the EXTERNAL section (page 47).

## Controlling Legend '70s with an external keyboard

To play, select and modify the *Legend '70s* sounds, connect the MIDI OUT terminal of an external MIDI keyboard to the MIDI [IN] connector of *Legend '70s*.

**NB**

*To play the Legend '70s sounds with an external MIDI device, the corresponding transmitting channel must correspond to the one set through the Global Channel parameter (page 55).*



## Using a computer


*Legend '70s* can be connected to a computer to use a DAW application to create user songs, to record and play performances and to play audio files.

Here are some of the things that can be done by connecting *Legend '70s* to a computer:

- Using *Legend '70s* as an external sound source to play MIDI sequences (.mid files) through a DAW software.
- Recording and playing user-made performances in MIDI format through a DAW software.
- Playing audio files (.mp3, .wav, .wma, .ogg, files etc...) through a DAW software.

To connect *Legend '70s* to a computer and exchange data, follow this procedure:

1. Enable the USB port through the *Control Port* parameter (see page 55).
2. Connect the USB [TO HOST] connector on *Legend '70s* to the USB port of the computer using a USB cable.
3. Computers running Microsoft Windows, need to install a USB driver. This driver is automatically installed when connecting the instrument to the computer for the first time. Follow the instructions on the computer to complete the installation.


**NB**


- DAW is the acronym for Digital Audio Workstation; DAW software can record, play, modify and mix audio and data on a computer.
- When *Legend '70s* is connected to a computer, DAW apps will detect two MIDI devices: *Legend '70s* MIDI Port and MIDIIN2 (*Legend '70s* MIDI Port). To use the instrument with a DAW, select *Legend '70s* MIDI port.

## Using a portable audio player

Connect a portable audio player to the [AUDIO IN] connector to play music from the external device through the headphones or *Legend '70s*' audio outputs, or play along with your favorite songs.

**NB**

*Use the volume control on the connected device to balance its volume with *Legend '70s*' volume.*



## Connecting pedals

*Legend '70s* can be played with several kinds of pedals: foot switches, on-off pedals that can be used to control functions and binary parameters; Half-Damper Sustain pedals that can be used in conjunction with the Half-Damper function, foot controllers for continuous control parameters; triple pedals, to imitate the three pedals of acoustic pianos. Pedals must be plugged to the dedicated connectors on the rear panel. However, they need different jacks and can be assigned to different functions as described below.


### Sustain pedal

The PEDAL [SUSTAIN] connector is dedicated to sustain pedals. Plug here a foot switch of the on-off type to use as a sustain pedal on an acoustic piano. When this pedal is pressed, notes played on the keyboard will resonate with a longer decay time, even after the key has been released.

Use this connector with a sustain half-damper pedal to use the "half pedaling" technique. When doing so, the damper effect varies according to pedal pressure.

Another option is using the Studiologic SLP3-PD pedal group, to have all three acoustic pianos pedals at your disposal. The SLP3-D triple pedal controls the "Soft" effect (also known as "una corda") with the left pedal, the "Sostenuto" effect with the middle pedal and the "Sustain" effect (damper) with the right pedal, working as "half-damper".

However, other functions can be assigned to the left and middle pedal, so as to use the triple pedal with sounds other than acoustic piano.



#### NB

- The sustain pedal can be used on the A.PIANO module to generate the "sympathetic" vibration of piano strings and mechanical sounds caused by the damper moving.
- When using the triple pedal, the left and middle pedal use the same functions assigned to [FOOT SWITCH 1] and [FOOT SWITCH 2], respectively.
- To ensure that the sustain pedal works properly, manually select the pedal type on the instrument (see the Sustain Type parameter, page 56).


### Foot switch

Use the PEDAL [FOOT SWITCH 1] and [FOOT SWITCH 2] connectors to plug in foot switch pedals. These pedals can be assigned to different functions, such as switching on / off a module or an effect, controlling the "Sostenuto" or soft effects on acoustic piano sounds, etc.

Furthermore, *Legend '70s* is equipped with a PEDAL [PROGRAM + / -] connector for two-switch pedals that can be used to select the next or previous Program.

Regular (one switch) foot switch pedals can also be connected to this port. When doing so, the foot switch will only select the next or previous Program.

Foot switches are not included. There are two types of foot switches on the market: N.O.(Normally Open) and N.C. (Normally Closed). The footswitch polarity (N.O. or N.C.) must be set correctly on the instrument.




## Foot controller

A foot controller, or expression pedal, allows continuous control of a parameter, unlike a footswitch.

Pedals connected to the PEDAL [FOOT CONTROLLER 1] and [FOOT CONTROLLER 2] connectors can be assigned a range of parameters, such as a Sound volume, tuning, modulation, Wah-Wah and more.

Foot controllers are not included. There are two types of foot controllers on the market: RTS and TRS. The pedal type must be set correctly on the *Legend '70s*.



**NB**

- To set a pedal's type and polarity, read the chapter Pedal Setup Section, page 56.
- To assign a function to a pedal, read Common Section, page 29.
- To avoid undesirable effects, always connect and disconnect pedals while the instrument is switched off.

## Using sounds

*Legend '70s* features a wide range of sounds, also depending on the installed modules. As already described, each single module contains several sound types. One or more modules can be played at the same time, up to all active modules together.

To use one or more sounds, follow the procedure.


1. Switch on the module of the desired sound by pressing its [ON/OFF] button.
2. Turn the selection knob to select the sound (or sound group, for modules that have them e.g. SOUND COLLECTION).
3. If the module has sound groups, use the sound selection knob to choose a sound.
4. Use the dedicated module controls to set the main sound parameters.

For a thorough description of sound parameters, read the description of the module Sections that can be found under the *EDIT* menu (page 42 and following) or by holding down the sound (or sound group) selection knob for a short while.

## Using effects

*Legend '70s* includes a high quality effects section, comprised of two independent effect processors: FX1 and FX2, of a reverb unit and a 3-band equalizer unit. The main effect parameters can be controlled through the main panel. For a complete configuration of all parameters, access the dedicated sections under the *EDIT* menu. To control the FX1 or FX2 effect, first select it by pressing the respective button [1] or [2] of the EFFECTS section on the panel.

The complete effects routing is explained by the following image:



## Activating and selecting the effect FX1 or FX2

---

To use the effect FX1 or FX2 follow this procedure:

1. Press the [1] button to select FX1, or press [2] to select FX2.
2. Press [FX ON] to activate the effect.
3. Turn the selection knob to select an effect category.
4. Press the selection knob and turn it or the data entry dial to select an effect preset.
5. Use the [AMOUNT] and [RATE] controls to adjust the main effect parameters.

For a thorough description of effect parameters, read the description of the *Effects Section*. The section can be found under the *EDIT* menu (page 32) or reached by pressing the effect type selection knob for a short while.

## Assign a module to FX1 or FX2

---

To assign a module output to the effect FX1 or FX2 follow this procedure:

1. Press the [1] button to select FX1, or press [2] to select FX2.
2. Hold down the [FX ON] button and press [ON/OFF] on the module you wish to assign.

The internal instrument connection allows you to assign more than one module to the same FX1 or FX2 effect. It is also possible to assign a module output to both FX1 and FX2.

## Activating and selecting the reverb effect

---

To use the reverb effect, follow this procedure:

1. Press the [REV ON] button to activate the effect.
2. Rotate the selection knob to choose a reverb category.
3. Press the selection knob and turn it (or the data entry dial) to choose a reverb type from the selected category.
4. Adjust the [DRY/WET] control to set the general reverb level.

If you wish to modify the quantity of signal sent to the reverb separately for each module, modify the *Reverb Send* parameter, available under the *EDIT* menu.

For a thorough description of the reverb parameters, read about the *Reverb Section* (page 41). To reach this section, access the *EDIT* menu or press the reverb selection knob for a short while.

## PROGRAM MODE

The Program mode is the main operating mode of the instrument. While in this mode, the user can run, select and save a Program.

While in Program mode, the display is divided into 4 areas, with the following fields:



**1 Program location.**


The letter indicates the Program Bank, the digit indicates its location.

**2 Program name**

Programs can be assigned a name when they are saved (page 27).

**3 Active modules.**

This area shows the icons corresponding to the modules which are active in the currently selected Program.



**4 Notification area.**

This area shows information and events related to particular conditions, such as keyboard transposition or the activation of the EXTERNAL section (if the dedicated module is not installed on the instrument).

**NB**


- The External section is always present, even if the module is not installed on the instrument. If the module is not installed on the instrument and one of the two parts of this section is active, the display will show the EXT field.
- The icon position is determined by the Identify Modules function (page 58).

## What is a Program

A Program contains the settings of all sound generation, control and effect sections. These settings are:

- Sound generation parameters and configurations of each module.
- Keyboard and keyboard sections configurations.
- Effects parameters (from the REVERB and EFFECTS sections).
- Pedals status and assigned function.
- Pitch bend and modulation wheels status and assigned functions.

Legend '70s contains 256 Programs, divided into 16 banks, each with 16 Programs. Every Program is identified by its Bank (a character between A and P) and by its location (a digit between 1 and 16). Furthermore, Programs can have a name.



*NB: the image refers to an instrument with the full range of modules.*

## Selecting a Program

To select a Program, use the PROGRAM section of the main panel; otherwise, if the instrument is in Program Mode, use the data entry dial beneath the display, the Bank buttons [<>] or the [SET] buttons. Programs can also be selected through the foot switch connected to the PEDAL [PROGRAM + / -] port on the rear panel. In the latter case, the display does not need to be on the main page.

To select a Program, use the data entry dial: rotate clockwise to select the next location, or counter-clockwise to select the previous one. When the last location of the Bank is selected (e.g. A16), rotating the dial clockwise will select the first location of the following Bank (for example B01). The opposite is also true: when the first location of a Banks is selected (e.g. B01), rotating the dial counter-clockwise will select the last location of the previous Bank (A16 in the example).

### PROGRAM SELECTION SEQUENCE

...O16 ← O01... ← P15 ← P16 ← **A01** → A02 → A03 →...A16 → B01...

To switch Bank, press the button [<] (from P to A) or [>] (from A to P). When the last Bank is selected (P), pressing [>] will select the first Bank (A). The same happens with the opposite situation: when the first Bank is selected (A), pressing [<] will select the last Bank (P).

### PROGRAM BANK SELECTION SEQUENCE

...A01 ← B01... ← P01 ← **A01** → B01 →...P01 → A01...

According to the current status of the *Confirm Program* parameter (page 57) the new Program can be recalled immediately or only when the user confirms the change by pressing the data entry dial. In the latter case, the Program location will blink until the dial is pressed. To cancel the Program selection, press [EXIT].

*Legend '70s* also allows to select four Programs directly, by pressing the [SET] buttons. These buttons can be used to select Programs quickly without having to scroll through locations with the data entry dial. For example, if you need to select Program D-12 right after B-01, the Program can be assigned to a [SET] button.

To assign a Program to a [SET] button, select the Program, then press a [SET] button for a short while. The Program will be assigned to that specific button. Once this is done, the following screen will appear on the display:

The main parameters of a Program can be adjusted in real time while running it. To do so, use the controls on the main panel and on the additional modules. Each time one of the controls is used, the name and value of the modified parameter will appear on display. For example, when the [DRY/WET] control of the Reverb effect is used, the display will show the video page:


PROGRAM  
STORED IN  
SET 1

REVERB  
Dry/Wet:  
7.0

Further information on display operations and navigation buttons can be found at page 10.

## Saving a Program



After modifying a Program, all changes will be lost as soon as you select another Program or switch off the instrument. To prevent that and make these changes permanent, Programs must be saved. To save a Program, you must assign it a name and select a location, if you don't want to overwrite the current Program. To save a Program, follow this procedure:

1. Set the instrument in Program Mode.
2. Press the [EDIT]/[STORE] button for a short while. This will recall the STORE function. The button light starts blinking. The display will show:  


The display shows the text "STORE AS" in white on a black background. Below it, the program name "EPiano+Strings" is displayed in white. At the bottom, there is a character selection bar with the letters "ZABCD E FGHijk" in white, where the letter "E" is underlined, indicating it is the active character.
3. Press the data entry dial or the [EDIT]/[STORE] button to confirm the Program name, or write a new one. To change name, press the buttons [<] or [>] to move the cursor (highlighted character) and rotate the data entry dial to select a different character. The lower part of the display shows all available characters for the Program name.  
Push [>] while pressing [EXIT] to insert a character before the one selected.  
Push [<] while pressing [EXIT], to delete the selected character.  
When you have finished writing the Program name, press the data entry dial or the [EDIT]/[STORE] button to continue. Press [EXIT] to abort.
4. Press the data entry dial or the [EDIT]/[STORE] button to overwrite the current Program location, or use the dial to select a new location. Press the buttons [<] or [>] to select a different Bank. While selecting the storage location, the display shows the name of the program stored in that location.  
When you have selected the location, press the data entry dial or the [EDIT]/[STORE] button to confirm, or [EXIT] to abort.

**NB**

- All 256 Programs of Legend '70s can be modified by the user and saved to one of the 256 memory locations.
- Overwriting a Program, whatever its location, means that all its settings will be inevitably lost. To avoid losing Programs, all current settings they can be saved to a USB flash drive so as to reload them whenever necessary and avoid losing data. For further information, read about the Backup All function, page 59. Furthermore, the instrument can be reset to the original factory settings at any time. For further information, read about the Factory Reset function at page 60.



## MODIFYING A PROGRAM

Press the [EDIT] button while in Program Mode to access the current Program's parameters.

The main menu *EDIT PROGRAM* contains all the main sections of a Program, and includes the following fields:

**1 Name of the menu.**

It means that you are on the main page of the menu *EDIT PROGRAM*.



**2 Page number.**

Shows the current page of the menu (for example "1/3" means that the current page is the first of the three available pages).

**3 Program sections list.**

Press the button [<] or [>] or rotate the data entry dial to move the cursor on the desired Program section. Then press the data entry dial to access that section and its parameters. Available sections are:

Section	Description
COMMON	General Program parameters, determining the functioning of all sections.
KEY RANGE	Set the key range of the Upper and Lower sections, according to the current status of the Split function.
EFFECTS	Configuration parameters of the REVERB section on the main panel.
REVERB	Configuration parameters of the EFFECTS section on the main panel.
E.PIANO	Configuration parameters of the E.PIANO module.
A.PIANO	Configuration parameters of the A.PIANO module.
CLAVI	Configuration parameters of the CLAVI module.
SOUND COLLECTION	Configuration parameters of the SOUND COLLECTION module.
EXTERNAL	Configuration parameters of the EXTERNAL module.

**NB**

- The sections E.PIANO, A.PIANO, CLAVI and SOUND COLLECTION only appear if the corresponding module is installed on the instrument. The sections on the *EDIT PROGRAM* menu appear on the order set by the Identify Modules function (page 58).
- Programs always include an EXTERNAL section, even when the dedicated module is not installed.

Press [EXIT] or [EDIT]/[STORE] to return to the main video page of the Program Mode.

Press the data entry dial while on a section to access its adjustable parameters. The following fields appear on the display:

**1 Submenu name.**

Indicates the name of the currently selected *EDIT PROGRAM* menu.



**2 Page number.**

Shows the current menu page (for example "1/9" means that the current page is the first of the nine available pages).

**3 Parameter name**

The name of the parameter currently being modified.

**4 Parameter value.**

Indicates the parameter value.

Rotate the data entry dial to modify the parameter value; press the button [<>] or [<>] to scroll through the section's parameters.

To leave the submenu and return to the *EDIT PROGRAM* menu, press [EXIT]. Press [EDIT]/[STORE] to return to the main video page of the Program.

## COMMON Section

The COMMON menu contains the general parameters of the Program, determining the operation of all the sections within.

To access the menu, enter the *EDIT PROGRAM* screen (page 28) and place the cursor on the COMMON field, then press the data entry dial.

Parameter name	Description
<b>Split Mode</b>	<p>Keyboard operating mode When <i>Split Mode</i> = OFF any sound can be assigned to the whole keyboard or to a part of it. To assign the sound to a portion of the keyboard, use the <i>KEY RANGE</i> function (page 30). When <i>Split Mode</i> = ON the keyboard is split in two. A Sound can be assigned to the Upper or Lower part. The boundary between the two parts is determined by the <i>Split Point</i> parameter, which sets the highest note of the Lower part. The Split Mode can also be set through the [SPLIT] button on the main panel.</p> <p><b>Values:</b> OFF, ON</p>
<b>Split Point</b>	<p>The boundary between the Upper and Lower parts, when the Split mode is active. The Split Point can be set directly through the keyboard, by pressing the [SPLIT] button and the desired key at the same time.</p> <p><b>Values:</b> between C-1 and G9</p>
<b>FS1 Dest</b> <b>FS2 Dest</b> <b>SoftPd/FS1Dest</b> <b>SostPd/FS2Dest</b>	<p>Function assigned to the pedals connected to the PEDAL ports [FOOT SWITCH 1] (FS1) and [FOOT SWITCH 2] (FS2), on the rear panel.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>OFF:</b> no function assigned.</li> <li>• <b>Sostenuto:</b> Sostenuto effect. Only available for Sounds from the modules SOUND COLLECTION, A.PIANO and E.Grand of the E.PIANO module). When using this function, only the notes played while the pedal is pressed are affected by the Sostenuto (soft) effect.</li> <li>• <b>Soft:</b> Soft effect. Only available for Sounds from the modules SOUND COLLECTION, A.PIANO, and for the E.Grand sound of the E.PIANO module). When using this function, the Soft effect is applied to all notes played while the pedal is pressed (i.e. have a slightly lower volume and a softer, damped timbre)</li> <li>• <b>FX1 ON:</b> switch on/off FX1 on the EFFECTS section.</li> <li>• <b>FX1 TAP:</b> parameter controlled by the [TAP] button for FX1.</li> <li>• <b>FX2 ON:</b> switch on/off FX2 on the EFFECTS section.</li> <li>• <b>FX2 TAP:</b> parameter controlled by the [TAP] button for FX2.</li> <li>• <b>REV ON:</b> switch on/off the effect of the REVERB section.</li> <li>• <b>Module ON:</b> switch on/off the modules according to the setting of Foot Switch 1 and Foot Switch 2 in the submenu of each module. The function must be enabled for each module with the parameters Foot Switch 1 and Foot Switch 2 on each module menu.</li> </ul> <p><b>NB</b></p> <ul style="list-style-type: none"> <li>- The parameter assigned to the [TAP] button varies according to the currently selected effect. For further information read EFFECTS section, page 32.</li> <li>- When the Sustain Type parameter (page 56) is set to Triple, these fields will appear as SoftPd/FS1Dest and SostPd/FS2Dest; they assign a function to the left (Soft) and central pedal (Sostenuto) of the triple pedal connected to the PEDAL [SUSTAIN] connector.</li> </ul>
<b>FC1 Dest</b> <b>FC2 Dest</b> <b>Mod.Wheel Dest</b>	<p>Function assigned to the pedals connected to the PEDAL [FOOT CONTROLLER 1] (FC1) and [FOOT CONTROLLER 2] (FC2) connector on the rear panel, and function assigned to the modulation wheel (see Wheels, page 5).</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>OFF:</b> no function assigned.</li> <li>• <b>Expression:</b> continuous control of the volume while playing.</li> <li>• <b>Modulation:</b> continuous control of the modulation while playing.</li> <li>• <b>Aftertouch:</b> send a MIDI message Aftertouch to the MIDI ports and channels (set by the EXTERNAL section).</li> <li>• <b>FX1 Amount:</b> parameter controlled through the [AMOUNT] knob for FX1.</li> <li>• <b>FX1 Rate:</b> parameter controlled through the [RATE] knob for FX1.</li> <li>• <b>FX2 Amount:</b> parameter controlled through the [AMOUNT] knob for FX2.</li> <li>• <b>FX2 Rate:</b> parameter controlled through the [RATE] knob for FX2.</li> </ul>

	<ul style="list-style-type: none"> <li><b>Rev Dry/Wet:</b> balance between direct and reverberated signal.</li> <li><b>Module Par1:</b> control a module parameter (see table below). This function has to be enabled in each module using the <i>Foot Controller 1</i> and <i>Foot Controller 2</i> parameters present in the menu of the module concerned.</li> <li><b>Module Par2:</b> control a module parameter (see table below). This function has to be enabled in each module using the <i>Foot Controller 1</i> and <i>Foot Controller 2</i> parameters present in the menu of the module concerned.</li> </ul> <table border="1"> <thead> <tr> <th>Module</th><th>Par 1</th><th>Par 2</th></tr> </thead> <tbody> <tr> <td>E.PIANO</td><td>Trem Intensity</td><td>Trem Speed</td></tr> <tr> <td>A.PIANO</td><td>Dynamic</td><td>Brilliance</td></tr> <tr> <td>CLAVI</td><td>Mute</td><td>Mute</td></tr> <tr> <td>SOUND COLLECTION</td><td>[KNOB 1] parameter</td><td>[KNOB 2] parameter</td></tr> <tr> <td>EXTERNAL</td><td>[CTRL 1] Control Change</td><td>[CTRL 2] Control Change</td></tr> </tbody> </table>	Module	Par 1	Par 2	E.PIANO	Trem Intensity	Trem Speed	A.PIANO	Dynamic	Brilliance	CLAVI	Mute	Mute	SOUND COLLECTION	[KNOB 1] parameter	[KNOB 2] parameter	EXTERNAL	[CTRL 1] Control Change	[CTRL 2] Control Change
Module	Par 1	Par 2																	
E.PIANO	Trem Intensity	Trem Speed																	
A.PIANO	Dynamic	Brilliance																	
CLAVI	Mute	Mute																	
SOUND COLLECTION	[KNOB 1] parameter	[KNOB 2] parameter																	
EXTERNAL	[CTRL 1] Control Change	[CTRL 2] Control Change																	
<b>Master Clock</b>	<p>Tempo source to synchronise the effects Tremolo, Chorus, Flanger, Phaser, Wah and Delay of the EFFECTS section, and the Tremolo effect of the E.PIANO module.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li><b>Internal:</b> tempo is set through the <i>Master Tempo</i> parameter.</li> <li><b>External:</b> tempo is set according to the MIDI Clock messages received by the instrument.</li> </ul> <p><b>NB</b></p> <ul style="list-style-type: none"> <li>To enable/disable synchronisation, modify the Sync parameter, described under the submenu EFFECTS of each effect.</li> <li>When an effect is synchronised with the External Master Clock, but no sync MIDI message is available, the tempo is set to 120bpm.</li> </ul>																		
<b>Master Tempo</b>	<p>Tempo expressed in Beats per Minute (bpm) of the <i>Master Clock</i> parameter when is set to Internal.</p> <p><b>Values:</b> between 25 and 250 bpm</p> <p><b>NB</b></p> <ul style="list-style-type: none"> <li>When the Master Clock is set to External, the Master Tempo parameter is disabled and the value will appear as ---“.</li> </ul>																		

## KEY RANGE section

Through the *KEY RANGE* menu the user can assign each module to a specific keyboard zone, or to the Upper or Lower section, when in Split mode. The Split mode can be enabled / disabled by pressing the [SPLIT] button in the PROGRAM area of the main panel.


To access the *KEY RANGE* menu, enter the *EDIT PROGRAM* page (read page 28), then place the cursor on the *KEY RANGE* field and press the data entry dial.

### Split mode disabled (SPLIT MODE = OFF)

When the Split mode is disabled, you can select a different keyboard range for each instrument module.

The top of the screen represents a keyboard; the lines below represent the keyboard areas assigned to each module, as represented by the acronyms:

- **EP:** E.PIANO
- **AP:** A.PIANO
- **CL:** CLAVINET
- **SC:** SOUND COLLECTION
- **EXT:** EXTERNAL




**NB**

Since the SOUND COLLECTION and EXTERNAL modules are comprised of two parts, the top line indicates the keyboard area assigned to part 1, while the bottom line represents part 2.

To define the boundaries of a keyboard zone assigned to a module, move cursor on the line of the desired module through the data entry dial or the buttons [<>], then press the dial.

Clearly, *Low Key* sets the lower key of the keyboard zone, while *Hi Key* sets the highest key. All keys inside the interval will produce sound according to the selected module.



To select the *Lower Key* hold down the [<>] button and push a key. Hold down [<>] and press a key to select the *Upper Key*.

It is also possible to use the data entry dial to select a note, and the [<>] and [<<] buttons to move the cursor. Once you have finished setting the parameters, press [EXIT] to return to the previous page.


### Split mode enabled (SPLIT MODE = ON)

When the Split mode is enabled, the keyboard is split in two parts: the Lower and Upper parts, and each module can be assigned to one of these parts. The Split point is the key that sets the boundary between the two parts, as described in the COMMON section (page 29).

The video page is similar to the one that appears when the Split mode is disabled; however, now the keyboard only has two parts.

Each module can be assigned to either the Upper or Lower part.

The Upper section begins on the key to the right of the Split point, while the Lower section includes the key that serves as Split Point.



To assign a module to one of the parts, use the data entry dial or the [<>] and [<<] buttons to place the cursor on the line of the desired module, then press the dial.

The *Split Part* parameter indicates the keyboard part assigned to the selected module. To change a value, use the data entry dial. Once you have finished setting the parameters, press [EXIT] to return to the previous page.



**NB**

- Hold down the [SPLIT] button and press a key to set the Split point directly on the keyboard.
- Hold down [the SPLIT] button and press [ON/OFF] once or twice to assign it to the Upper and Lower parts (press again to cycle between Upper and Lower).

## EFFECTS section

The *EFFECTS* menu includes the parameters of the *EFFECTS* section on the main panel (see page 9).

The *EFFECTS* section allows to use two independent effects, that can be recalled through the buttons [1] and [2] on the main panel. Doing so will update the parameter value shown on the display. The effect selected for editing appears on the display on the heading of the menu by the field FX1 or FX2.

To access this menu, enter the *EDIT PROGRAM* screen (page 28) place the cursor on the *EFFECTS* field and press the data entry dial or hold down the effect category selection knob for a short while (see point 6, page 9).

**FX1:Chorus** 5/15  
Category:  
**Chorus**

### Effect types

The available effects on *Legend '70s* belong to eight categories. To choose a category, use the dedicated knob (read point 6, page 9) or the *Category* parameter under the *EFFECTS* menu.

Each effect category disposes of an adequate number of presets, that allow the user to recall programmed configurations, each carefully calibrated to faithfully represent the features of the specific effect. The main parameters of each effect can be adjusted by using the [AMOUNT] and [RATE] knobs, and the [TAP] button on the main panel. The more demanding musician can use the *Custom* preset to modify all available parameters, to further customise the effect.



To select an effect configuration, press the effect type knob or use the *Preset* parameter.

**NB**

- The following tables show all the parameters that the user can modify through the *Custom* preset. Under the parameter name, the screen shows the knob and [TAP] button that allow to control said parameter.
- For a complete list of available presets read table List of effect presets, page 64.
- For the *Others* category, after pressing the category selection knob to select a preset, use the [<] and [>] buttons to switch to *PEQ3*, *PEQ5*, *GEQ5*, *Comp* or *Rotary*.

### Tremolo and Vibrato

The Tremolo modulates the signal amplitude, i.e. its volume, in a cycle, in order to obtain a trembling effect.  
The Vibrato modulates the signal frequency, i.e. its pitch, in a cycle.

Parameter name	Description
<b>Switch [FX ON]</b>	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b>	Connect the effects FX1 and FX2 of the <i>EFFECTS</i> section. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Parallel:</b> parallel link. The FX1 output signal is summed to the FX2 output signal.</li> <li>• <b>Serial:</b> serial link. The FX1 output signal is sent to the FX2 input.</li> </ul> <p><b>PARALLEL</b></p>  <p><b>SERIAL</b></p> 

<b>FX Out Routing</b>	Assign FX1 or FX2 an audio output. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Main L-R:</b> AUDIO OUT [MAIN L/MONO] and [MAIN R] connectors on the rear panel (stereo signal)</li> <li>• <b>Aux1 Mono:</b> AUDIO OUT [AUX 1] connector on the rear panel (mono signal).</li> <li>• <b>Aux2 Mono:</b> AUDIO OUT [AUX 2] connector on the rear panel (mono signal).</li> <li>• <b>Aux1-2:</b> AUDIO OUT [AUX 1] and [AUX 2] connectors on the rear panel (stereo signal).</li> </ul>
<b>Reverb Send</b>	Set the level of the audio signal sent to the Reverb effect. <b>Values:</b> between 0 and 127  <b>NB</b> When the effects FX1 and FX2 have a serial link (parameter FX Config), the level of the signal sent to REVERB is determined by the Reverb Send parameter of FX2.
<b>Mod. Type</b>	Modulation type. <b>Values:</b> Tremolo, Vibrato
<b>LFO Depth [AMOUNT]</b>	Modulation depth. <b>Values:</b> between 0.0 and 10.0
<b>LFO Speed [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ If the <b>Sync</b> parameter = OFF Modulation frequency. <b>Values:</b> between 0.0 and 10.0</li> <li>▪ If the <b>Sync</b> parameter = ON Time signature used to calculate the modulation frequency, based on metronome tempo set through the <i>Master Clock</i> parameter on the <i>COMMON</i> section (page 30).  <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64  <b>NB</b> D : dot T: triplets</li> </ul>
<b>LFO Wave</b>	Modulating signal waveform. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Triangle:</b> triangular waveform.</li> <li>• <b>Sine:</b> sinusoid waveform.</li> <li>• <b>Square:</b> pulse wave.</li> <li>• <b>Suit76:</b> Rhodes Suitcase 76 Tremolo.</li> <li>• <b>Wr200:</b> Wurlitzer 200 Tremolo.</li> </ul>
<b>L/R Phase</b>	Modulating signal phase between right and left channels. <b>Values:</b> between 0 and 180 deg (degrees). The value 0 deg corresponds to a monophonic signal. As the value increases, the signal becomes more and more stereophonic.
<b>Sync</b>	Synchronisation between the modulating signal and metronome tempo, as set through the <i>Master Clock</i> parameter of the <i>COMMON</i> section (page 30). <b>Values:</b> OFF, ON
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB

## Chorus

Modulation effect that makes the sound warmer and deeper.

Parameter name	Description
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Chorus Type</b>	Chorus type. <b>Values:</b> Chorus1, Chorus2, Chorus3, Chorus4,
<b>LFO Depth</b>	Modulation depth. <b>Values:</b> between 0.0 and 10.0
<b>LFO Speed</b> [RATE], [TAP]	<ul style="list-style-type: none"> <li>▪ <b>If the Syncparameter = OFF</b> Modulation frequency. <b>Values:</b> between 0.0 and 10.0</li> <li>▪ <b>If the Syncparameter = ON</b> Time signature used to calculate the modulation frequency, based on metronome tempo set through the <i>Master Clock</i> parameter on the <i>COMMON</i> section (page <a href="#">30</a>).   <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64           </li> </ul> <p><b>NB</b>  <i>D : dot</i>  <i>T: triplets</i></p>
<b>Pre Delay</b>	Modulation offset. <b>Values:</b> between 0.0 and 50.0 msec
<b>L/R Phase</b>	Phase between the right and left channel of the modulating signal. <b>Values:</b> between 0 and 180 deg (degrees). The value 0 deg corresponds to a monophonic signal. As the value increases, the signal becomes more and more stereophonic.
<b>Sync</b>	Synchronisation between the modulating signal and metronome tempo, as set through the <i>Master Clock</i> parameter of the <i>COMMON</i> section (page <a href="#">30</a> ). <b>Values:</b> OFF, ON
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Dry/Wet</b> [AMOUNT]	Balance between the effect's original input signal ( <i>Dry/Wet</i> =0.0) and the effected signal ( <i>Dry/Wet</i> =10.0). <b>Values:</b> between 0.0 and 10.0

## Flanger

Modulating effect that makes the sound cyclical and metallic.

Parameter name	Description
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Flanger Type</b>	Flanger type. <b>Values:</b> Flanger1, Flanger 2, Flanger 3, Flanger 4,
<b>LFO Depth</b>	Modulation depth. <b>Values:</b> between 0.0 and 10.0
<b>LFO Speed</b> [RATE], [TAP]	<ul style="list-style-type: none"> <li>▪ <b>If the Syncparameter = OFF</b> Modulation frequency. <b>Values:</b> between 0.0 and 10.0</li> <li>▪ <b>If the Syncparameter = ON</b> Time signature used to calculate the modulation frequency, based on metronome tempo set</li> </ul>

	through the <i>Master Clock</i> parameter on the <b>COMMON</b> section (page 30).
	<b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64 <b>NB</b> <i>D</i> : dot <i>T</i> : triplets
<b>Feedback</b>	Quantity and phase of the signal that is sent back to the effect's input, determining how much the signal is enriched and modified. Negative values correspond to an inverted phase signal. <b>Values:</b> between -5.0 and +5.0
<b>Pre Delay</b>	Modulation offset. <b>Values:</b> between 0.0 and 50.0 msec
<b>L/R Phase</b>	Phase between the right and left channel of the modulating signal. <b>Values:</b> between 0 and 180 deg (degrees). the value 0 deg corresponds to a monophonic signal. As the value increases, the signal becomes more and more stereophonic.
<b>Sync</b>	Synchronisation between the modulating signal and metronome tempo, as set through the <i>Master Clock</i> parameter of the <b>COMMON</b> section (page 30). <b>Values:</b> OFF, ON
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Dry/Wet [AMOUNT]</b>	Balance between the effect's original input signal ( <i>Dry/Wet</i> =0.0) and the effected signal ( <i>Dry/Wet</i> =10.0). <b>Values:</b> between 0.0 and 10.0

## Phaser

This effect modulates the phase of the signal and sums it to the original signal.

Parameter name	Description
<b>Switch [FX ON]</b>	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page 32.
<b>Phaser Type</b>	Phaser type. <b>Values:</b> 4-Stage, 6-Stage, 8-Stage, 12-Stage
<b>LFO Depth</b>	Modulation depth. <b>Values:</b> between 0.0 and 10.0
<b>LFO Speed [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ <b>If the Syncparameter = OFF</b> Modulation frequency.  <b>Values:</b> between 0.0 and 10.0</li> <li>▪ <b>If the Syncparameter = ON</b> Time signature used to calculate the modulation frequency, based on metronome tempo set through the <i>Master Clock</i> parameter on the <b>COMMON</b> section (page 30).  <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64  <b>NB</b>  <i>D</i> : dot  <i>T</i> : triplets         </li> </ul>
<b>Feedback [AMOUNT]</b>	Quantity and phase of the signal that is sent back to the effect's input, determining how much the signal is enriched and modified. <b>Values:</b> between 0.0 and 10.0
<b>Manual</b>	Central frequency of the signal modulation. <b>Values:</b> between 0.0 and 10.0
<b>L/R Phase</b>	Phase between the right and left channel of the modulating signal. <b>Values:</b> between 0 and 180 deg (degrees). the value 0 deg corresponds to a monophonic signal. As the value increases, the signal becomes more and more stereophonic.
<b>Sync</b>	Synchronisation between the modulating signal and metronome tempo, as set through the <i>Master Clock</i> parameter of the <b>COMMON</b> section (page 30). <b>Values:</b> OFF, ON

<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Dry/Wet</b>	Balance between the effect's original input signal ( <i>Dry/Wet</i> =0.0) and the effected signal ( <i>Dry/Wet</i> =10.0). <b>Values:</b> between 0.0 and 10.0

## Wah

This effect is a filter that changes frequency, modulating the sound's brilliance. There are three kinds of Wah: *Control Wah* modulates the sound through a continuous control device, such as a pedal connected to the [FOOT CONTROLLER 1] or [FOOT CONTROLLER 2] ports, the modulation wheel or the [RATE] knob. *Auto Wah* automatically modulates the sound in a cycle. *Touch Wah* modulates the signal according to the signal level (a higher level sweeps up the effect it's open sound, corresponding to the "rocked forward" position).

Parameter name	Description
<b>Switch [FX ON]</b>	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config FX Out Routing Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Wah Type</b>	Wah type. <b>Values:</b> Control, Auto, Touch
<b>Top</b>	Maximum filter frequency. <b>Values:</b> between 0.0 and 10.0
<b>Bottom</b>	Minimum filter frequency. <b>Values:</b> between 0.0 and 10.0
<b>Resonance [AMOUNT]</b>	Resonance of the filter determining the boost of the frequencies surrounding the cutoff frequency. <b>Values:</b> between 0.0 and 10.0
<b>Filter Type</b>	Filter type. <b>Values:</b> LP (low-pass), BP (Band-pass), HP (high-pass)
<b>LFO Speed (Auto Wah) [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ <b>If the Sync parameter = OFF</b> Modulation frequency. <b>Values:</b> between 0.0 and 10.0</li> <li>▪ <b>If the Sync parameter = ON</b> Time signature used to calculate the modulation frequency, based on metronome tempo set through the <i>Master Clock</i> parameter on the <i>COMMON</i> section (page <a href="#">30</a>).   <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64           </li> </ul> <p><b>NB</b>  <i>D</i> : dot  <i>T</i> : triplets       </p>
<b>Sensitivity (Touch Wah) [RATE]</b>	Sensitivity to the keyboard velocity (and therefore signal level). <b>Values:</b> between 0.0 and 10.0
<b>Control (Control Wah) [RATE]</b>	Continuous control position. <b>Values:</b> between 0.0 and 10.0
<b>Sync (Auto Wah)</b>	Synchronisation between the modulating signal and metronome tempo, as set through the <i>Master Clock</i> parameter of the <i>COMMON</i> section (page <a href="#">30</a> ). <b>Values:</b> OFF, ON
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB

**NB**

When using the Control Wah the function FX1 or FX2 RATE (page [29](#)) must be assigned to the pedal that controls the Wah.

## Amp

This effect simulates an amplifier.

Parameter name	Description
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Amp Type</b>	Type of amplifier. <b>Values:</b> Suit76, Wr200, Sweet, Vintage, '59 Clean, Twin, Small, Twin Punch, Lo-Fi, Punch Stack, Fuzz Drive, Bass Stack, Sub Bass
<b>Drive</b> [AMOUNT]	Quantity of distorted signal. <b>Values:</b> between 0.0 and 10.0
<b>Output Level</b> [RATE]	Effect output level. <b>Values:</b> between 0.0 and 10.0
<b>Bass</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Middle</b>	Set the gain (positive value) or attenuation (negative values) of the middle frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Treble</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB

**NB**

The Amp category type does not have presets.

## Delay

This effect repeats the signal to create rhythmic or ambience effects.

*Mono Delay* generates monophonic repetitions, despite the currently selected Sound (stereo or mono). *Stereo Delay* generates stereophonic repetitions, to be used with a stereo sound.

*PingPong Delay* repetitions can be distributed alternatively on the left and right channel.


Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Delay Type</b>	Delay type. <b>Values:</b> Mono, Stereo, PingPong
<b>Time / bpm</b> [RATE]	<ul style="list-style-type: none"> <li>▪ If the <b>Sync</b> parameter = <b>OFF</b> Time passing between two repetitions; can be adjusted either in milliseconds or bpm (beats per minute). <b>Values:</b> between 20 mses and 1.5 sec / between 40 and 750 bpm</li> <li>▪ If the <b>Sync</b> parameter = <b>ON</b> Time signature used to calculate the time span between one repetition and the following, based on the metronome tempo set through the <i>Master Clock</i> parameter (indicated by the <i>bpm</i> parameter) of the <i>COMMON</i> function (page <a href="#">30</a>). <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <p><b>NB</b>  <i>D</i> : dot  <i>T</i>: triplets</p>
<b>Feedback</b>	Quantity and phase of the signal that is sent back to the input, determining the effect's duration. <b>Values:</b> between 0.0 and 10.0
<b>High Dump</b>	High frequency attenuation speed of signal repetitions. <b>Values:</b> between 0.0 and 10.0

<b>Sync</b>	Synchronisation of the time between repetitions and the metronome tempo, set through the <i>Master Clock</i> parameter of the <i>COMMON</i> function (page 30). <b>Values:</b> OFF, ON
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>Dry/Wet [AMOUNT]</b>	Balance between the original input signal ( <i>Dry/Wet</i> =0.0) and the effected signal ( <i>Dry/Wet</i> =10.0). <b>Values:</b> between 0.0 and 10.0

## Others

### Others Type: PEQ3 – PEQ5

Parametric 3-band (PEQ3) and 5-band (PEQ5) equalizer.




Parameter name	Description
<b>Switch [FX ON]</b>	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page 32.
<b>Low Freq</b>	Central frequency of the low frequency band. <b>Values:</b> between 40 and 400 Hz
<b>Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies band, set through the <i>Low Freq</i> parameter. <b>Values:</b> between -12.0 and +12.0 dB
<b>Mid Freq</b> (solo PEQ3) [RATE]	Central frequency of the mid frequencies band. <b>Values:</b> between 60 and 8000 Hz
<b>Mid Gain</b> (solo PEQ3) [AMOUNT]	Set the gain (positive value) or attenuation (negative values) of the middle frequencies band, set through the <i>Mid Freq</i> parameter. <b>Values:</b> between -12.0 and +12.0 dB
<b>Mid Q</b> (solo PEQ3)	Bandwidth of middle frequencies. High Q values narrow the filter band. <b>Values:</b> between 0.5 and 8.0
<b>Mid1 Freq</b> (solo PEQ5) [AMOUNT]	Central frequency of band 1 in the middle frequency range. <b>Values:</b> between 60 and 8000 Hz
<b>Mid1 Gain</b> (solo PEQ5) [RATE]	Set the gain (positive value) or attenuation (negative values) of the middle frequencies band 1, set through the <i>Mid1 Freq</i> parameter. <b>Values:</b> between -12.0 and +12.0 dB
<b>Mid1 Q</b> (solo PEQ5)	Bandwidth of band 1 in the middle frequencies range. High Q values narrow the filter band. <b>Values:</b> between 0.5 and 8.0
<b>Mid2 Freq</b> (solo PEQ5)	Central frequency of band 2 in the middle frequency range. <b>Values:</b> between 60 and 8000 Hz
<b>Mid2 Gain</b> (solo PEQ5)	Set the gain (positive value) or attenuation (negative values) of the middle frequencies band 2. <b>Values:</b> between -12.0 and +12.0 dB
<b>Mid2 Q</b> (solo PEQ5)	Bandwidth of band 2 in the middle frequencies range. High Q values narrow the filter band. <b>Values:</b> between 0.5 and 8.0

<b>Mid3 Freq</b> (solo PEQ5)	Central frequency of band 3 in the middle frequency range. <b>Values:</b> between 60 and 8000 Hz
<b>Mid3 Gain</b> (solo PEQ5)	Set the gain (positive value) or attenuation (negative values) of the middle frequencies band 3. <b>Values:</b> between -12.0 and +12.0 dB
<b>Mid3 Q</b> (solo PEQ5)	Bandwidth of band 3 in the middle frequencies range. High Q values narrow the filter band. <b>Values:</b> between 0.5 and 8.0
<b>High Freq</b>	Central frequency of the high frequency band. <b>Values:</b> between 2000 and 160000 Hz
<b>High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies band. <b>Values:</b> between -12.0 and +12.0 dB

## Others

### Others Type: GEQ5

5-band graphic equalizer.



Parameter name	Description
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>EQ1 Gain</b>	Set the gain (positive value) or attenuation (negative values) of band 1, with central frequency at 100 Hz. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ2 Gain</b> [AMOUNT]	Set the gain (positive value) or attenuation (negative values) of band 2, with central frequency at 335 Hz. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ3 Gain</b>	Set the gain (positive value) or attenuation (negative values) of band 3, with central frequency at 1000 Hz. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ4 Gain</b> [RATE]	Set the gain (positive value) or attenuation (negative values) of band 4, with central frequency at 3350 Hz. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ5 Gain</b>	Set the gain (positive value) or attenuation (negative values) of band 5, with central frequency at 8000 Hz. <b>Values:</b> between -12.0 and +12.0 dB

## Others

### Others Type: Compressor

Compressor effect that limits and compresses the signal dynamic. It can be used to create a powerful sound with a more constant level, or to increase the notes' sustain.

Parameter name	Description
<b>Switch</b> [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Threshold</b> [AMOUNT]	Level above which the signal is compressed. <b>Values:</b> between -48.0 and 0.0 dB

<b>Ratio</b>	Compress ratio. <b>Values:</b> 1.5:1, 2:1, 3:1, 4:1, 6:1, 8:1, 10:1, 20:1
<b>Attack</b>	Attack time: the time it takes for the compression to start, after the signal has crossed the threshold. <b>Values:</b> between 0 and 200 ms
<b>Release</b>	The time it takes for the compression to end, after the signal has returned below the threshold. <b>Values:</b> between 25 and 2000 ms
<b>Output Level [RATE]</b>	Effect output level. <b>Values:</b> between 0.0 and 10.0
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB

## Others

### Others Type: Rotary

This effect simulates an amplifier with rotating speakers, typically used with electromechanical organs.

Parameter name	Description
<b>Switch [FX ON]</b>	Activate / deactivate effect. <b>Values:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Same function of the parameters described at page <a href="#">32</a> .
<b>Brake</b>	Gradual stop of the speakers rotation. <b>Values:</b> OFF, ON
<b>Speed [RATE]</b>	Speakers rotation speed. <b>Values:</b> Slow – Fast
<b>Drive [AMOUNT]</b>	Quantity of distorted signal. <b>Values:</b> between 0.0 and 10.0
<b>D/H Balance</b>	Balance between the sound of the bass speaker ( <i>D/H Balance</i> =0.0) and the treble horn ( <i>D/H Balance</i> =10.0). <b>Values:</b> between 0.0 and 10.0
<b>Drum Slow</b>	Rotation speed of the bass speaker drum when the speed is set to Slow. <b>Values:</b> between 30.0 and 60.0 RPM
<b>Drum Fast</b>	Rotation speed of the bass speaker drum when the speed is set to Fast. <b>Values:</b> between 360.0 and 420.0 RPM
<b>Drum Rise/Fall</b>	Time it takes for the bass speaker to switch speed. <b>Values:</b> between 0.0 and 10.0
<b>Horn Slow</b>	Rotation speed of the treble horn when the speed is set to Slow. <b>Values:</b> between 30.0 and 60.0 RPM
<b>Horn Fast</b>	Rotation speed of the treble horn when the speed is set to Fast. <b>Values:</b> between 360.0 and 420.0 RPM
<b>Horn Rise/Fall</b>	Time it takes for the treble horn to switch speed. <b>Values:</b> between 0.0 and 10.0
<b>EQ Low Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
<b>EQ High Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB

## REVERB section

Reverb is a sum of the various acoustic reflections of a sound in a space. A great number of factors determine the acoustic effects of a reverberation, such as the size and shape of the ambient, the material of which the walls are made, and much more.

The *REVERB* menu contains the parameters of the REVERB section on the main panel (see page 8).

To access this menu, enter the *EDIT PROGRAM* screen (page 28) place the cursor on the *REVERB* field, then press the data entry dial, or hold down the reverb category knob for a short while (see point 3, page 8).

### Reverb types

There are several available reverb effects on *Legend '70s*, divided into categories, according to the type of ambient or reverb device they simulate. To select a category, use the dedicated knob (see point 3, page 8) or access the *Category* parameter under the *REVERB* menu.

Each reverb category contains different variants, called types. To choose one, press the selection knob then select the reverb type; alternatively, you can access the *Type* parameter under the *REVERB* menu.

The following table shows all the available reverb types:

Category	Type
Room	<ul style="list-style-type: none"> <li>• Small Room: reverb of a small room with highly absorbing walls.</li> <li>• Large Room: reverb of a large room with low sound absorption.</li> </ul>
Hall	<ul style="list-style-type: none"> <li>• Small Hall: reverb of a small concert hall, with rather reflective walls</li> <li>• Medium Hall: reverb of a medium sized concert halls, with rather reflective walls.</li> <li>• Large Hall: reverb of a large concert hall, with highly reflective walls.</li> </ul>
Stage	<ul style="list-style-type: none"> <li>• Stage1, Stage2: simulate the acoustics of a concert stage in a live context.</li> </ul>
Plate	<ul style="list-style-type: none"> <li>• Medium Plate: reverb produced by the vibration of a medium sized plate.</li> <li>• Large Plate: reverb produced by the vibration of a large sized plate.</li> </ul>
Spring	<ul style="list-style-type: none"> <li>• Spring 1, Spring 2: two variants simulating the spring reverb used in amplifiers during the '70s.</li> </ul>
Tape	<ul style="list-style-type: none"> <li>• Tape 1, Tape 2: two variants simulating the reverb created by an analogic tape recorder and a reverberation chamber.</li> </ul>

### Reverb parameters

Parameter name	Description
Switch [FX ON]	Activate / deactivate effect. <b>Values:</b> OFF, ON
Time	Reverb duration. <b>Values:</b> between 0.0 and 10.0
High Damp	High frequencies attenuation time of the reverberated signal. <b>Values:</b> between 0.0 and 10.0
EQ Low Gain	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
EQ High Gain	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the effect. <b>Values:</b> between -12.0 and +12.0 dB
Dry/Wet [DRY/WET]	Balance between the effect's original input signal ( <i>Dry/Wet</i> =0.0) and the effected signal ( <i>Dry/Wet</i> =10.0). <b>Values:</b> between 0.0 and 10.0


## E.PIANO section

The *E.PIANO* menu includes all the configuration parameters of the *E.PIANO* module (page 11).

To access this menu, enter the *EDIT PROGRAM* screen (page 28), place the cursor on the *E.PIANO* field and press the data entry dial or, alternatively, hold down the sound selection knob of the module for a short while (point 4, page 11).


**NB**

The following table includes all the available parameters of the *E.PIANO* module. The knob or button that allows direct control of the parameter through the panel is written below the parameter name.

Parameter name	Description
<b>Timbre</b> [timbre selector]	Name of the selected timbre. There are 8 electric piano timbres, differing in their electrical and mechanical characteristics. Use the <i>Legend '70s Editor</i> application to modify the selected timbre. Changes made through this application affect all Programs. <b>Values:</b> <ul style="list-style-type: none"><li>• <b>Rhod 1, Rhod 2, Rhod 3, Rhod 4, Rhod 5:</b> “tine” type electric piano (Rhodes).</li><li>• <b>Wurli 1, Wurli 2:</b> “reed” type electric piano (Wurlitzer).</li><li>• <b>E.Grand:</b> Grand electro-acoustic piano (CP-80).</li></ul>
<b>Switch</b> [ON/OFF]	Activate / deactivate the module <b>Values:</b> OFF, ON
<b>Volume</b> [VOLUME]	Level of the module generated signal. <b>Values:</b> between 0 and 127
<b>Output Routing</b>	Assign the module audio output. <b>Values:</b> <ul style="list-style-type: none"><li>• <b>Main L-R:</b> AUDIO OUT [MAIN L/MONO] and [MAIN R] connectors on the rear panel (stereo signal)</li><li>• <b>FX1:</b> input of the EFFECTS section FX1</li><li>• <b>FX2:</b> input of the EFFECTS section FX2</li><li>• <b>FX1+FX2:</b> inputs of both FX1 and FX2 of the EFFECTS section.</li><li>• <b>Aux1 Mono:</b> AUDIO OUT [AUX 1] connector on the rear panel (mono signal).</li><li>• <b>Aux2 Mono:</b> AUDIO OUT [AUX 2] connector on the rear panel (mono signal).</li><li>• <b>Aux1-2:</b> AUDIO OUT [AUX 1] and [AUX 2] connectors on the rear panel (stereo signal).</li></ul> 
<b>Reverb Send</b>	Level of the audio signal generated by the module and sent to the Reverb effect. <b>Values:</b> between 0 and 127  <b>NB</b> This parameter only works if the audio output selected through the Output Routing parameter is MAIN L-R.
<b>Detune</b>	Tuning of the sound generated by the module, expressed in hundredths of semitone (or cent). <b>Values:</b> between -50 and +50 semitone cents.
<b>Note Shift</b>	Module sound transposition (in semitones). <b>Values:</b> between -48 and +48 half-tones.  <b>NB</b> When transposition is applied, the [TRANSPOSE] module Led is on.

<b>Velocity Sens</b>	Sensitivity of the signal level to the pressure exerted on the keyboard (velocity). When a certain pressure is applied the signal level is increased (positive values) or decreased (negative values). <b>Values:</b> between -5 and +5
	<p><b>NB</b></p> <ul style="list-style-type: none"> <li>- The graph above refers to the Normal velocity curve (page 54).</li> <li>- The Velocity Sens parameter has no effect with the Fixed velocity curve (page 54).</li> </ul>
<b>Pitch Bend</b>	Enable the <b>1</b> wheel for this module (See <i>Wheels</i> section, page 5) <b>Values:</b> OFF, ON
<b>Mod.Wheel</b>	Enable the <b>2</b> wheel for this module (See <i>Wheels</i> section, page 5) <b>Values:</b> OFF, ON
	<p><b>NB</b></p> <p>The function associated to the modulation wheel is determined by the COMMON menu, parameter Mod.Wheel Dest (page 29) and affects all modules.</p>
<b>Sustain Pedal</b>	Enable the Sustain pedal (connected to the [SUSTAIN] connector on the rear panel) for this module. <b>Values:</b> OFF, ON
<b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Enable the pedals connected to the connectors PEDAL [FOOT SWITCH 1], [FOOT SWITCH 2], [FOOT CONTROLLER 1] and [FOOT CONTROLLER 2] (rear panel) for this module. <b>Values:</b> OFF, ON
	<p><b>NB</b></p> <ul style="list-style-type: none"> <li>- The function assigned to these pedals is defined by the section COMMON, parameters FS1 Dest, FS2 Dest, FC1 Dest, FC2 Dest (page 29) and the setting affects all modules.</li> <li>- The parameters Foot Switch 1 and Foot Switch 2 also enable (respectively) the left and central pedal of a triple pedal connected to the PEDAL [SUSTAIN] connector.</li> </ul>
<b>Trem Switch</b> [TREM ON]	Enable / disable the Tremolo effect on the E.PIANO module. <b>Values:</b> OFF, ON
<b>Trem Intensity</b> [INTENSITY]	Modulation depth of the Tremolo effect on the E.PIANO module. <b>Values:</b> between 0.0 and 10.0
<b>Trem Speed</b> [SPEED]	<ul style="list-style-type: none"> <li>▪ <b>If the parameter Trem Sync = OFF</b> Modulation frequency of the Tremolo effect of the E.PIANO module. This control also has a LED light that blinks at the same frequency set on the parameter. <b>Values:</b> between 0.0 and 10.0</li> <li>▪ <b>If the parameter Trem Sync = ON</b> Time signature used to calculate the modulation frequency of the Tremolo effect, based on metronome tempo set through the Master Clock parameter section (indicated by the bpm parameter) on the COMMON (page 30). <b>Values:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <p><b>NB</b></p> <p>D : dot T: triplets</p>
<b>Trem Wave</b>	Modulating signal waveform. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Triangle:</b> triangular waveform.</li> <li>• <b>Sine:</b> sinusoid waveform.</li> <li>• <b>Square:</b> pulse wave.</li> <li>• <b>Suit76:</b> Rhodes Suitcase 76 Tremolo.</li> <li>• <b>Wr200:</b> Wurlitzer 200 Tremolo.</li> </ul>

<b>Trem Sync</b>	Enable / disable the synchronisation of the Tremolo effect of the E.PIANO module with the <i>Master Clock</i> parameter. When the <i>Tremolo Sync</i> parameter is enabled ( <i>Tremolo Sync: ON</i> ), the Tremolo modulation frequency is determined by the <i>Master Clock</i> and the <i>Tremolo Speed</i> parameter determines the multiplier factor of the <i>Master Tempo</i> parameter (COMMON section) or of the received MIDI Clock (page 30). <b>Values:</b> OFF, ON
<b>Trem Stereo</b>	Enable / disable the Stereo mode of the Tremolo effect of the E.PIANO module. When this parameter is disabled ( <i>Tremolo Stereo: OFF</i> ), the Tremolo output signal is centered in the stereo image. When the parameter is enabled ( <i>Tremolo Stereo: ON</i> ), the output signal moves left and right on the stereo image. <b>Values:</b> OFF, ON
<b>Amp Switch [AMP ON]</b>	Enable / disable the Amplifier effect on the E.PIANO module. <b>Values:</b> OFF, ON
<b>Amp Model</b>	Amplifier effect model on the E.PIANO module. There are 13 amplifier models, differing in pre-amplifier, power amplifier, cabinet and speakers. <b>Values:</b> Suit76, Wr200, Sweet, Vintage, '59 Clean, Twin, Small, Twin Punch, Lo-Fi, Punch Stack, Fuzz Drive, Bass Stack, Sub Bass
<b>Amp Drive</b>	Saturation (distortion) of the output Amplifier signal of the E.PIANO module. <b>Values:</b> between 0.0 and 10.0
<b>Bass Gain</b>	Set the gain (positive value) or attenuation (negative values) of the low frequencies generated by the E.PIANO module. <b>Values:</b> between -5.0 and +5.0
<b>Treble Gain</b>	Set the gain (positive value) or attenuation (negative values) of the high frequencies generated by the E.PIANO module. <b>Values:</b> between -5.0 and +5.0

## A.PIANO section

The A.PIANO menu includes all the configuration parameters of the A.PIANO module (described at page 12). To access this menu, enter the *EDIT PROGRAM* screen (page 28) place the cursor on the A.PIANO field and press the data entry dial, or hold down the sound selection knob of the module for a while (point 4, page 13).


**NB**


The following table includes all the available parameters of the A.PIANO module. The knob or button that allows direct control of the parameter through the panel, is written under the parameter name.

Parameter name	Description
<b>Timbre [timbre selector]</b>	Name of the selected timbre. There are 8 acoustic piano timbres, differing in their acoustic and mechanical characteristics. Use the <i>Legend '70s Editor</i> application to modify the selected timbre. Changes made through this application affect all Programs. <b>Values:</b> Piano 1, Piano 2, Piano 3, Piano 4, Piano 5, Piano 6, Piano 7, Piano 8
<b>Switch Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Same function of the parameters described at page 42.
<b>Dynamic [DYNAMIC]</b>	Dynamic range of the acoustic piano. Reduce (negative values) or increase (positive values) the level difference between pianissimo and fortissimo. <b>Values:</b> between -5.0 and +5.0
<b>Brilliance [BRILLIANCE]</b>	Sound brilliance. When the value is 0 the sound is perfectly balanced. Negative values enhance the bass frequencies and dampen the trebles: the result is a less brilliant sound. Positive values enhance the treble frequencies and dampen the bass: the result is a more brilliant sound <b>Values:</b> between -5.0 and +5.0

## CLAVI section

The *CLAVI* menu includes all the configuration parameters of the CLAVI module (described at page 13).

To access this menu, enter the *EDIT PROGRAM* screen (page 28) place the cursor on the *CLAVI* field and press the data entry dial or, alternatively, hold down either the [Clavi 1] or [Clavi 2] buttons for a short while (point 6, page 14).


**NB**


The following table includes all the available parameters of the *CLAVI* module. The knob or button that allows direct control of the parameter through the panel is written under the parameter name.

Parameter name	Description
<b>Timbre</b> [Clav 1] [Calv 2]	Name of the selected timbre. The timbres simulates the two most famous models of the Clavinet piano. Use the <i>Legend '70s Editor</i> application to adjust the selected timbre. Changes made through this application affect all Programs. <b>Values:</b> Clavi 1 (D6 model), Clavi 2 (E7 model)
<b>Switch</b> <b>Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Same function of the parameters described at page 42.
<b>Brilliant Control</b> [BRILLIANT]	Enable / disable the high-pass filter, that starkly increases the sound brilliance. <b>Values:</b> OFF, ON
<b>Treble Control</b> [TREBLE]	Activate / deactivate the band-pass filter, very rich on the treble frequencies. <b>Values:</b> OFF, ON
<b>Medium Control</b> [MEDIUM]	Activate / deactivate the low-pass filter, with cutoff frequency on the middle frequencies . <b>Values:</b> OFF, ON
<b>Soft Control</b> [SOFT]	Enable / disable the low-pass filter, for a more closed or muffled sound. <b>Values:</b> OFF, ON
<b>C D Control</b> [C D]	Pickup configuration. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>C:</b> activate a single pickup.</li> <li>• <b>D:</b> activate both pickups.</li> </ul>
<b>A B Control</b> [A B]	Pickup configuration. <ul style="list-style-type: none"> <li>▪ <b>If the parameter C D = C</b> Select pickup.           <ul style="list-style-type: none"> <li>• <b>A:</b> lower pickup</li> <li>• <b>B:</b> higher pickup</li> </ul> </li> <li>▪ <b>If the parameter C D = D</b> Phase selection.           <ul style="list-style-type: none"> <li>• <b>A:</b> pickups in same phase.</li> <li>• <b>B:</b> pickups in opposite phase</li> </ul> </li> </ul> <b>NB</b> <i>Combining the values of the parameters C D Control and A B Control there are 4 possible sound configurations. For further information, read point 4, page 13.</i>
<b>Mute</b>	Activate / deactivate the sliding damper. <b>Values:</b> OFF, ON
<b>Mute Value</b>	Maximum position of the mute (sliding damper), than decreases the sound decay time. <b>Values:</b> between 30 and 127


## SOUND COLLECTION section

The **SOUND COLLECTION** menu includes all the configuration parameters of the **SOUND COLLECTION** module (described at page 14). The **SOUND COLLECTION** module is comprised of two independent parts, that can be recalled through the buttons [1] or [2] on the main panel. The screen shows the selected part in the menu heading, represented by the numbers [1] or [2], and the parameter values of the said part.

To access this menu, enter the **EDIT PROGRAM** screen (page 28) place the cursor on the **SOUND COLLECTION** field and press the data entry dial or, alternatively, hold down the sound selection knob of the module for a while (point 4, page 14).


**NB**

*The following table lists all the available parameters of the SOUND COLLECTION module. The knob or button that allows direct control of the parameter through the panel is written under the parameter name.*

Parameter name	Description
<b>Category</b> [category selector]	Selected timbre type. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Pad:</b> synth pads.</li> <li>• <b>Strings:</b> bowed instruments, acoustic or synthesized.</li> <li>• <b>Choir:</b> choirs.</li> <li>• <b>Brass:</b> acoustic or synthesized brass instruments.</li> <li>• <b>Keys:</b> acoustic and electronic pianos, synths, accordions.</li> <li>• <b>Organ:</b> electric, electromechanic and pipe organs.</li> <li>• <b>Bass:</b> acoustic, electric and synthesized bass.</li> <li>• <b>Others:</b> various kinds of instruments.</li> </ul>
<b>Timbre</b> [timbre selector]	Selected timbre type. Different sound categories (selected through the <i>Category</i> parameter) may have a different number of timbres.  <b>NB</b> <i>A complete list of sounds is available on table Lists of Sound Collection Sounds at page 65.</i>
<b>Switch</b> <b>Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Same function of the parameters described at page 42.
<b>[parameter 1]</b> [KNOB 1] <b>[parameter 2]</b> [KNOB 2] <b>[parameter 3]</b> [KNOB 3]	Main sound generation parameters of the selected sound. The three available parameters depend on the selected sound, and are described below: <ul style="list-style-type: none"> <li>• <b>Attack Time:</b> sound attack time, i.e. the time it takes to reach the signal level peak after the key is pressed.</li> <li>• <b>Decay Time:</b> the time the sound takes to decay after the key has been pressed.</li> <li>• <b>Release Time:</b> sound decay time after a key has been released.</li> </ul>  <ul style="list-style-type: none"> <li>• <b>Filter CutOff:</b> filter cutoff frequency, modifies the sound's brilliance.</li> <li>• <b>Efx Send:</b> effect input level.</li> </ul>

- |  |   |
|--|---|
|  | <ul style="list-style-type: none"> <li>• <b>Efx Rate:</b> effect modulation speed.</li> <li>• <b>Efx Depth:</b> effect modulation depth.</li> <li>• <b>High Bars:</b> signal level of the treble drawbars.</li> <li>• <b>Percussion:</b> percussion level (for electromechanical organs).</li> <li>• <b>Rotary:</b> enable / disable the Rotary effect, simulating the classic rotating speaker used with electromechanical organs.</li> <li>• <b>Vibrato Depth:</b> modulation depth of the vibrato effect.</li> </ul> |
|--|---|

## EXTERNAL section

The *EXTERNAL* menu contains all the configuration parameters of the EXTERNAL module (described at page 15).

The EXTERNAL module is comprised of two independent parts, that can be recalled through the buttons [1] and [2] on the main panel.

The EXTERNAL section is always present in the Program, even when the EXTERNAL module is not installed on the instrument. If there is no EXTERNAL module on your instrument, the parts [1] and [2] can be recalled by pressing the buttons [SET 1] or [SET 2] (respectively) on the main panel. To access this menu, enter the *EDIT PROGRAM* screen (page 28) place the cursor on the *EXTERNAL* field and press the data entry dial, or hold down the MIDI message or function selection knob for a short while (point 4, page 15).

**EXTERNAL [1]** 3/21  
Output Port:  
**USB**

**NB**

The following table lists all the available parameters of the EXTERNAL module. The knob or button that allows direct control of the parameter through the pane, is written under the parameter name.

Parameter name	Description
<b>Switch [ON/OFF]</b>	Same function of the parameters described at page 42.
<b>Volume [VOLUME]</b>	Volume of the transmitted MIDI message value (Control Change 7). <b>Values:</b> between 0 and 127
<b>Output Port [VALUE]</b>	MIDI data transmission port. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Port. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>MIDI:</b> MIDI [OUT] connector.</li> <li>• <b>USB:</b> USB [TO HOST] connector.</li> </ul>
<b>Channel [VALUE]</b>	MIDI channel transmitting MIDI data. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Channel. <b>Values:</b> between 1 and 16
<b>Note Shift</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Same function of the parameters described at page 42.
<b>Program Change [VALUE]</b>	Program Change message transmission. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Program. <b>Values:</b> between 0 and 127
<b>Bank Select MSB [VALUE]</b>	Bank Select MSB message transmission. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Bank MSB. <b>Values:</b> between 0 and 127
<b>Bank Select LSB [VALUE]</b>	Bank Select LSB message transmission. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Bank LSB. <b>Values:</b> between 0 and 127
<b>Ctrl 1 CC</b> <b>Ctrl 2 CC</b> <b>Ctrl 3 CC</b> <b>[VALUE]</b>	Control Change assigned to the [CTRL 1], [CTRL 2] and [CTRL 3] knobs. The value can be also modified through the [VALUE] control of the module, when the MIDI message/function selector is set on Ctrl 1 CC, Ctrl 2 CC and Ctrl 3 CC. <b>Values:</b> between 0 and 127
<b>Ctrl 1 Value</b> <b>[CTRL 1]</b> <b>Ctrl 2 Value</b> <b>[CTRL 2]</b> <b>Ctrl 3 Value</b> <b>[CTRL 3]</b>	Control Change value assigned to the [CTRL 1], [CTRL 2] and [CTRL 3] knobs, sent when the Program is recalled. The value can also be modified through the above mentioned knobs <b>Values:</b> between 0 and 127

## SONG MODE

The Song mode allows the user to select 4 Programs to be quickly recalled, regardless of their location in the memory banks and without the need to scroll through locations.

To select the Song mode press the [SONG MODE]/[SYSTEM] button: the Led light will turn on and the display will show the last selected Song.

The following fields appear on the screen:



**1 Song number.**

Displays the currently selected Song number.

**2 Song name.**

Songs can be assigned a name when they are saved (for further information see page 49).

**3 List number.**

Displays the currently selected List number.

**4 Program within the Song.**


This section displays the Programs that are inside the current Song, indicated by their memory bank (letter) and location (digit). The current Program is indicated by the inverted color rectangle.

Press the [SONG MODE]/[SYSTEM] button or [EXIT] to return to Program mode.

## What is a Song

The Song mode allows the user to create a group of 4 Programs, for example according to instrument type, music genre or the musician's future performance. The Programs in this group can be recalled quickly, without scrolling through Program locations, as one would normally when in Program mode.

For an extended range of combinations, the user can create a maximum of 9 Lists, each containing 40 Songs.



## Song selection

To select a Song, use the data entry dial. Rotate the dial clockwise to select the next Song. Rotate the dial counter-clockwise to select the previous Song.

**SONG SELECTION SEQUENCE**

...SNG 39 ← SNG 40 ← **SNG 01** → SNG 02 → ...SNG 40 → SNG 01...

When a Song is selected, the system loads the first Program in the Song.

Songs can be selected in the main video page of the Song mode. The display shows the Song name and number. To select a different Program, press [<] or [>] or one of the [SET] buttons. While selecting, the display temporarily shows the new Program name in the same field that normally displays the Song name.

Programs can also be selected through the pedals connected to the PEDAL [PROGRAM + / -] port on the rear

panel.

Hold down [EXIT] and press [<] or [>] to select a List. Alternatively, use the LISTS function (page 52).

According to the current configuration of the *Confirm Program* parameter (page 57) a Song (or Program within a Song) can be recalled immediately, or only after the data entry dial is pressed. In the latter case, the Program location blinks until the dial is pressed.

**NB**

*Please note that Songs do not contain copies of Programs and/or their data. This means that when a Program is modified and saved, all the Songs that contain the said Program will then use the new, modified version of that Program.*

## Saving a Song

Changes made to Songs are temporary and will be deleted when a different Song is selected or the instrument is switched off. To avoid that, Songs must be made permanent by saving them. When saving a Song, you can give it a name and store it in its current location or select a different location (number) so as not to overwrite the previous version of that Song.

To save a song, follow this procedure:

1. Make sure that the the Program mode is NOT selected; if it is, press the [SONG MODE]/[SYSTEM] button.
2. Press the [EDIT]/[STORE] button for a short while. This will recall the STORE function. The button Led light will start blinking; the following page will appear on screen:
3. Press the data entry dial or the [EDIT]/[STORE] button to confirm the Song name, or write a new name. Press the [<] or [>] button to move the cursor (highlighted character) and turn the dial to select a character. The bottom part of the display shows the available characters to write the Song name.  
Hold down [EXIT] and press [>] to insert a character before the currently selected one.  
Hold down [EXIT] and press [<] to delete the selected character.  
Once the Song name has been composed, press the data entry dial or the [EDIT]/[STORE] button to continue, or [EXIT] to cancel.
4. Press the data entry dial or the [EDIT]/[STORE] button to overwrite the current Song location, or select a new location with the dial.  
Press the button [<] or [>] to select a different Bank. While selecting the location, the display shows the name of the Song currently saved on that location.  
When you have selected the location, press the data entry dial or the [EDIT]/[STORE] button to confirm, or [EXIT] to abort.

**STORE AS**

One Night

IJKLMNOPQRST

**STORE TO**

LIST1: SNG 01

One Night

**NB**

*When you overwrite a Song, be it on the current location or to a different location, the data of that Song will be inevitably lost. To prevent that, all the current settings can be saved to an external USB drive and recalled when necessary. For further information on the subject, read about the Backup All function at page 59.*

*Furthermore, the instrument's factory settings can be recalled at any time. For further information on the subject, read about the Factory Reset function, page 60.*

## MODIFYING A SONG OR LIST

Press the [EDIT] button while the display is on Song mode to access the programming parameters of the current Song.

The main *EDIT SONG* menu provides all the programming functions of a Song, consisting of the following fields:



**1 Name of the menu.**

Shows that you currently are in the main page of the *EDIT SONG* menu.

**2 Page number.**

Shows the current page of the menu (for example "1/3" means that the current page is the first of the three available pages). "1/1" means that the current page is the only available page.

**3 Functions.**

Press the buttons [<] or [>] to place the cursor on one of these fields and press the data entry dial to access the functions to modify Songs or Lists. These functions are:


Field on the display	Description
PARTS	Assign a Program to the parts of the currently selected Song.
ORDER	Song order within the currently selected List.
COPY/PASTE	Copy a Song in the current List or copy the whole List.
LISTS	List selection.

Press [EXIT] or [EDIT]/[STORE] to return to the main Song mode page.

## PARTS function

Use the *Parts* function to assign Programs to the 4 parts of the Song. A Song part can be considered as a location on which the Program is placed. To access this function, access the *EDIT SONG* page and place the cursor on the *PARTS* field, then press the data entry dial.

The following fields appear on the screen:



**1 Function name.**

Shows that you currently are in the *Parts* function.

**2 Program name**

Name of the Program assigned to the selected part.

**3 Selected Part and Programs in the Parts.**

Shows the selected part, indicated by the inverted colour rectangle, and the Programs of the current Song's parts (identified by the memory bank character and location digit).

Press the button [<] or [>] to select a part to which you wish to assign a Program. To assign a new Program to the part, rotate the data entry dial.

## ORDER function

Use the *Order* function to move a Song within the current List. To access this function, enter the *EDIT SONG* page and place the cursor on the *ORDER* field, then press the data entry dial.

The following fields appear on the screen:

**1 Function name.**

Shows that you are in the *Order* function and the name of the List you are modifying.

**2 Song number.**

Shows the number of the currently selected Song (to be moved).

**3 Song name.**

Shows the name of the currently selected Song (to be moved).

**4 Page number.**

Shows the current page number, and the total number of pages on the List.



To move a Song within a List, follow this procedure:

1. Use the data entry dial or the [<] and [>] buttons to place the cursor on the field corresponding to the Song you wish to move.
2. Press the data entry dial. Two arrows will appear on screen, meaning that you can now move the Song.
3. Turn the data entry dial or press the button [<] or [>] to move the Song.
4. Press the data entry dial to confirm the new location.

It is also possible to add a new Song, to the List, called "Init Song". To do so, follow the procedure:

1. Use the data entry dial or the [<] and [>] buttons to place the cursor on the field corresponding to the List to which you wish to add the new Song.
2. Press [EXIT] and [>] at the same time to add the "Init Song" to the current position. All Songs, beginning with the selected one, are shifted to the next location in the List.
3. To modify the "Init Song", use the *Parts* function described above.

You can also delete a Song from a List. To do so, follow the procedure:

1. Use the data entry dial or the [<] and [>] buttons to place the cursor on the field corresponding to the Song you wish to delete.
2. Press [EXIT] and [<] at the same time to delete the Song from the current position. All Songs following the deleted Song will be moved one step back.

## COPY/PASTE function

Use the *Copy/Paste* function to copy a Song to a different position on the List, or all the Songs on the List to another List. The procedure is comprised of two steps. The first step is *Copy From*, where you select a Song you wish to copy; the second is *Paste To*, where you choose the position to which the Song will be copied.

To access this function, enter the *EDIT SONG* page, place the cursor on the *COPY/PASTE* field and press the data entry dial.


The first page represents the *COPY FROM* step and is comprised of the following fields:

**1 Current COPY/PASTE step.**

Shows that you currently are in the *Copy From* step.

**2 List number.**

Shows the number of the List you will copy from.



**③ Song number.**

Displays the number of the Song you will copy.

**④ Song name.**

Shows the name of the Song that will be copied.

To copy one or all Songs, follow the procedure:

1. Press the buttons [<>] to select the List from which you wish to copy a Song. To copy all Songs, select "ALL".

**LIST SELECTION SEQUENCE**

...LIST9:SGN 01 ← **LIST1:SGN 01** → LIST2:SGN 01...

2. Use the data entry dial to select the name of the Song you wish to copy.

**SONG SELECTION SEQUENCE**

...LIST1:SGN 40 ← LIST1:ALL ← **LIST1:SGN 01** → LIST1:SGN 02 → ...LIST1:ALL...

3. Press the data entry dial to confirm the Song selection; then, the screen will show the *Paste To* page. To select a position to which you wish to copy a Song, follow the same procedure described in the *Copy From*, step, points 1 and 2. If you wish to copy all the Songs to a List, in the *Paste To* step you can select the target List (from *LIST1:ALL* to *LIST9:ALL*).
4. Press the data entry dial to confirm the copy or [EXIT] to cancel.

## LISTS function

The *Lists* function allows you to select a Song List. To access this function, enter the EDIT SONG page and place the cursor on the LISTS field, then press the data entry dial.

The following fields appear on the screen:

**① Function name.**

Shows that you currently are in the *Lists* function.

**② List number.**

Indicates the currently selected List.

To select a List, turn the data entry dial or press the button [<>] or [<]. To confirm, press the dial, or press [EXIT] to abort.



## SYSTEM MENU

The **SYSTEM** menu provides the parameters that affect the whole instrument. All changes made on the **SYSTEM** menu are immediately applied and saved, until modified again or until a Factory Reset is performed.

To access the System parameters, press the [SONG MODE]/[SYSTEM] button for a short while. The **SYSTEM** menu will appear on screen, with the following fields:



**1 Menu name.**

Shows that you currently are in the main page of the **SYSTEM** menu.

**2 Page number.**

Shows the current page and total pages of the menu (for example “1/2” means that the current page is the first of two available pages).

**3 Submenu.**

Press the button [<] or [>] or turn the data entry dial to move the cursor on one of these fields, then press the dial to access the menu. Available menus are:

Field on the display	Description
<b>KEYBOARD</b>	Keyboard settings.
<b>EQUALIZER</b>	General equalizer settings.
<b>MIDI SETTINGS</b>	MIDI interface settings.
<b>PEDAL SETUP</b>	Connected pedals settings.
<b>PREFERENCES</b>	Instrument customisation settings.
<b>UTILITY</b>	Modules settings, save/load data, Factory Reset, operating system update.

Press [EXIT] or [SONG MODE]/[SYSTEM] to return to the Program or Song mode.

The following fields appear on the screen:



**1 Submenu name.**

Indicates the current **SYSTEM** menu section.

**2 Page number.**

Shows the current page and total page number of the menu (for example “1/4” means that the current page is the first of the four available pages).

**3 Parameter name**

The name of the parameters currently being modified.

**4 Parameter value.**

Indicates the parameter value.

Press the buttons [<] or [>] to scroll through the menu parameters. To set a value, rotate the data entry dial. To leave a submenu and return to the **SYSTEM** menu, press [EXIT]. Press [SONG MODE]/[SYSTEM] instead to return to the Program or Song mode.

## KEYBOARD section

The **KEYBOARD** menu contains the general parameters of the keyboard.



To access this menu, enter the **SYSTEM** page and place the cursor on the **KEYBOARD** field, then press the dial.

Parameter name	Description
<b>Transpose</b>	General instrument transposition by semitones. <b>Values:</b> between -12 and +12 semitones  <b>NB</b> <i>Transposition is also shown on the main video page, in the T field.</i>
<b>Fine Tuning</b>	General fine tuning, in semitone hundredths (cents) and in Hertz. <b>Values:</b> between -50 and +50 / between 427.5 and 452.9 dB
<b>Velocity Curve</b>	Curves that determine the keyboard's sensitivity to the touch. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Hard1</b> and <b>Hard2</b>: with these curves it is hard to reach high velocity values. Hard 2 is harder than Hard1.</li> <li>• <b>Normal</b>: a standard curve, the velocity value is directly proportional to the pressure exerted on the keyboard.</li> <li>• <b>Soft1</b> and <b>Soft2</b>: soft curves that allow to reach the high velocity range easily. Soft 2 is softer than Soft 1.</li> <li>• <b>Fixed</b>: a fixed curve that always produces the same velocity value despite the pressure exerted on the keyboard. The value is set through the <i>Fixed Velocity</i> parameter.</li> </ul>
<b>Fixed Velocity</b>	Velocity value of the Fixed curve of the <i>Velocity Curve</i> parameter. <b>Values:</b> between 1 and 127  <b>NB</b> <i>When the Velocity Curve parameter is not Fixed, the Fixed Velocity parameter cannot be modified. Its value will appear as "—".</i>

## EQUALIZER section

The **EQUALIZER** menu contains all the general equalizer settings (see point 2, page 8).

To access this menu, enter the **SYSTEM** page and place the cursor on the **Keyboard** field, then press the data entry dial.

Parameter name	Description
<b>Filter Type</b>	LOW and HIGH bands filter. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>Shelving</b>: enhance or attenuation the signal below (LOW band) or above (HIGH band) the selected frequency.</li> <li>• <b>Peaking</b>: enhance or attenuation the signal around the central frequency of each band.</li> </ul> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>SHELVING</b></p>  <p><b>NB</b> The MID band always uses a Peaking type filter.</p> </div> <div style="text-align: center;"> <p><b>PEAKING</b></p>  </div> </div>
<b>Low Freq</b>	Central frequency of the LOW band. <b>Values:</b> between 60 and 250 Hz

<b>Low Q</b>	Width of the bell-shaped curve of the LOW band filter. The central frequency is defined by the <i>Low Freq</i> parameter. High values correspond to a narrower curve, so the sound is strongly affected around the central frequency. Low values correspond to a broader curve, so the filter affects a larger band of frequencies, and the sound changes more gradually around the central frequency. <b>Values:</b> between 0.5 and 4.0  <b>NB</b> <i>This parameter is only available with Filter Type: Peaking.</i>
<b>Mid Freq</b>	MID band central frequency. <b>Values:</b> between 250 and 2500 Hz
<b>Mid Q</b>	Width of the bell-shaped curve of the MID band filter. The central frequency is defined by the <i>Mid Freq</i> parameter. This parameter works exactly like the <i>Low Q</i> parameter described above. <b>Values:</b> between 0.5 and 4.0
<b>High Freq</b>	HIGH band central frequency <b>Values:</b> between 250 and 2500 Hz
<b>High Q</b>	Width of the bell-shaped curve of the HIGH band filter. The central frequency is defined by the <i>High Freq</i> parameter. This parameter works exactly like the <i>Low Q</i> parameter described above. <b>Values:</b> between 0.5 and 4.0  <b>NB</b> <i>This parameter is only available with Filter Type: Peaking.</i>

## MIDI section

The *MIDI* menu provides all the general MIDI settings of the instrument.

To access this menu, enter the *SYSTEM* page and place the cursor on the *MIDI SETTINGS* field, then press the data entry dial.

Parameter name	Description
<b>Control Port</b>	This port sends and receives instrument control messages, such as keyboard events, pedals, wheels and panel controls. <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>OFF:</b> no message is sent or received.</li> <li>• <b>USB:</b> control messages are sent and received through the USB [TO HOST] connector on the rear panel.</li> <li>• <b>MIDI:</b> control messages are sent by the MIDI [OUT] connector and received through the MIDI [IN] connector on the rear panel.</li> </ul>
<b>Global Channel</b>	MIDI channel sending and receiving instrument control messages <b>Values:</b> between 1 and 16
<b>Local Control</b>	Enable the transmission of keyboard events, panel and pedal controls, to the instrument's internal sound generation. We suggest to set this parameter as OFF while the instrument is connected to a computer via USB with the Thru function active (thus sending back all data to <i>Legend '70s</i> ) to avoid double notes and MIDI loops. <b>Values:</b> OFF, ON  <b>NB</b> <i>MIDI events are sent and received through the MIDI and USB ports according to the Control Port parameter value, as described above.</i>
<b>Tx/Rx Program</b>	Enable sending and receiving MIDI Bank Select and Program Change messages through the control port. <b>Values:</b> OFF, ON
<b>Tx/Rx CC</b>	Enable sending and receiving MIDI Control Change messages through the control port. <b>Values:</b> OFF, ON
<b>Soft Thru</b>	Transmission of MIDI messages sent by <i>Legend '70s</i> . <b>Values:</b> <ul style="list-style-type: none"> <li>• <b>OFF:</b> no MIDI message is sent.</li> <li>• <b>MidiIn&gt;MidiOut:</b> messages received through the MIDI [IN] connector are sent to the MIDI [OUT] connector.</li> <li>• <b>MidiIn&gt;USB:</b> messages received through the MIDI [IN] connector are sent to the USB [TO HOST] connector.</li> <li>• <b>USB&gt;MidiOut:</b> messages received through the USB [TO HOST] connector are sent to the MIDI [OUT] connector.</li> </ul>



### NB

For a thorough description of MIDI messages sent and received by *Legend '70s* refer to the MIDI Informations, page *MIDI - 1*.

## PEDAL SETUP section

The *PEDAL SETUP* menu provides the parameters to configure the pedals connected to the PEDAL jack on the rear panel.

To access this menu, enter the *SYSTEM* page and place the cursor on the *PEDAL SETUP* field, then press the data entry dial.

Parameter name	Description
Sustain Type	<p>Type of pedal connected to the PEDAL [SUSTAIN] connector.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>Half-Damper:</b> continuous control sustain pedal, to be used with the half-pedaling technique.</li> <li>• <b>Switch:</b> foot switch.</li> <li>• <b>Triple:</b> Studiologic SLP-3D triple pedal.</li> </ul>
Sustain Polarity	<p>Polarity of the pedal connected to the PEDAL [SUSTAIN] connector.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> polarity is automatically detected when switching on the instrument.</li> <li>• <b>Open</b> (when Sustain Type: Switch): Normally open pedal (N.O.)</li> <li>• <b>Closed</b> (when Sustain Type: Switch): Normally closed pedal (N.C.).</li> <li>• <b>Type1</b> (with Sustain Type: Half-Damper): pedal such as Yamaha FC3A.</li> <li>• <b>Type2</b> (with Sustain Type: Half-Damper): pedal such as Roland DP-10.</li> </ul> <p><b>NB</b></p> <ul style="list-style-type: none"> <li>- <i>Do not press the pedal while switching on the instrument and when selecting polarity.</i></li> <li>- <i>This parameter has no effect if Sustain Type is set to Triple.</i></li> </ul>
Sustain Range	<p>Position and range covered by the pedal connected to the PEDAL [SUSTAIN] connector. This page also allows the user to calibrate the sustain pedal (page 57).</p> <p><b>Values:</b> between 0 and 100%</p>
FS1 Polarity FS2 Polarity	<p>Polarity of the foot switch connected to PEDAL [FOOT SWITCH 1] and [FOOT SWITCH 2].</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> polarity is automatically detected when switching on the instrument.</li> <li>• <b>Open:</b> normally open pedal (N.O.).</li> <li>• <b>Closed:</b> normally closed pedal (N.C.).</li> </ul> <p><b>NB</b></p> <p><i>Do not press the pedal while switching on the instrument and when selecting polarity.</i></p>
FC1 Type FC2 Type	<p>Type of foot controller connected to PEDAL [FOOT CONTROLLER 1] and [FOOT CONTROLLER 2].</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>Type1:</b> pedal with RTS connector, such as Yamaha FC7.</li> <li>• <b>Type2:</b> pedal with TRS connector, such as Fatar VP/25.</li> </ul> <div style="text-align: center;"> <p><b>TYPE 1</b></p>  <p><b>TYPE 2</b></p>  </div>
FC1 Range FC2 Range	<p>Position and range covered by the pedal connected to PEDAL [FOOT CONTROLLER1] and [FOOT CONTROLLER 2].</p> <p>This page also allows the user to calibrate the foot controller (page 57).</p> <p><b>Values:</b> between 0 and 100%</p>
Prog +/- Polarity	<p>Polarity of the two-switch foot switch connected to PEDAL [PROGRAM + / -].</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> polarity is automatically detected when switching on the instrument.</li> <li>• <b>Open:</b> normally open pedal (N.O.).</li> <li>• <b>Closed:</b> normally closed pedal (N.C.).</li> </ul> <p><b>NB</b></p> <ul style="list-style-type: none"> <li>- <i>When using a two-switch foot switch with opposite polarities, select the Auto setting.</i></li> <li>- <i>Do not press the pedal while switching on the instrument and when selecting polarity.</i></li> </ul>

<b>Prog +/- Type</b>	Functioning mode of the two-switch foot switch connected to PEDAL [PROGRAM + / -]. <b>Values:</b> <ul style="list-style-type: none"><li>• <b>Normal:</b> the right switch is assigned to PROGRAM + function, the left switch to PROGRAM –.</li><li>• <b>Inverted:</b> the right switch is assigned to the PROGRAM – function, the left switch to PROGRAM +.</li></ul> <b>NB</b> <i>When using a single-switch pedal, this parameter can be used to choose between the PROGRAM + and PROGRAM – functions .</i>
----------------------	--

## Pedal calibration

When connecting pedals to PEDAL [SUSTAIN], PEDAL [FOOT CONTROLLER 1] and [FOOT CONTROLLER 2] it might be useful to perform a calibration, if the functioning range is incorrect (see the parameters *Sustain Range*, *FC1 Range* and *FC2 Range* under the *PEDAL SETUP* menu). To calibrate the pedal, follow this procedure:

1. Scroll until you see the *Sustain Range*, *FC1 Range* or *FC2 Range* parameter, according to the pedal you wish to calibrate.
2. To start the calibration, press the data entry dial.
3. Move the pedal to its maximum and minimum positions, checking that the *MIN* and *MAX* field show the right percentage value.
4. Press the data entry dial to save the new calibration (“Calibration stored!” message) or [EXIT] to cancel (“Calibration aborted!” message).

## PREFERENCES section

The *PREFERENCES* menu allows the user to customise some instrument functions.

To access this menu, enter the *SYSTEM* page and place the cursor on the *PREFERENCES* field, then press the data entry dial.

Parameter name	Description
<b>Confirm Prg</b>	Enable / disable the need for confirmation when loading a Program. When the parameter value is OFF, a Program is loaded immediately when selected. When the parameter value is ON, the user must select a Program and then press the data entry dial to load it. <b>Values:</b> OFF, ON
<b>All Notes Off</b>	Turn off, changing Program, of any notes. <b>Values:</b> Disabled, Enabled
<b>Leds Intensity</b>	Brightness of all the Leds on the panel. <b>Values:</b> between 1 and 8
<b>Display Contrast</b>	Set the OLED display contrast. <b>Values:</b> between 1 and 8
<b>USB to Device</b>	Functioning mode of the [USB TO DEVICE] port. <b>Values:</b> <ul style="list-style-type: none"><li>• <b>Flash Drive:</b> for the use with a USB flash drive.</li><li>• <b>Charger:</b> to charge a tablet or smartphone.</li></ul>
<b>USB Audio Level</b>	Signal level of the USB stereo Audio received through the [USB TO HOST] connector. <b>Values:</b> between 1 a 127
<b>Memory Lock</b>	Prevents from saving Programs and Songs, together with loading backup files, so as to avoid undesired memory overwriting. <b>Values:</b> OFF, ON
<b>Auto Power Off</b>	How long the instrument has to be idle before it shuts down automatically. <b>Values:</b> Disabled, 30 min, 120 min

**NB**

- *To switch on the instrument after it was shut down by the Auto Power Off function, set the [POWER] switch to “0” (OFF), wait 10 seconds, then set the switch to “1” (ON).*
- *All unsaved data is lost when the instrument shuts down automatically. To prevent that, always save the changes you don't want to lose.*

## UTILITY MENU

The *UTILITY* menu provides some useful parameters that affect the whole instrument. The display shows the following fields:

**1 Submenu name.**

Shows that you currently are in the *UTILITY* menu.

**2 Page number.**

Shows the current page number and the total of pages on the menu (for example “1/5” means that the current page is the first out of the five available pages).

**3 Function name.**

The name of the function that will be recalled. Available functions are:

Field on the display	Description
<b>Identify Modules</b>	Modify the position of modules on the display.
<b>Backup All</b>	Save the instrument data to a USB flash drive.
<b>Restore All</b>	Load the instrument data from a USB flash drive.
<b>Factory Reset</b>	Restore the factory settings.
<b>Version</b>	Current version and update of the operating system.

**4 Operations to recall the function.**

Tells you to press the data entry dial to start the selected function.

Press the buttons [<>] or [<>] to scroll through the menu functions. Press the data entry dial to access the function. Press [EXIT] to quit the function and return to the SYSTEM menu. Press [SONG MODE]/[SYSTEM] instead to return to the Program or Song mode.

## IDENTIFY MODULES function

The *Identify Modules* function can be used to identify the actual position of modules in the instrument's slots, so that they appear in the correct order on the main video page and under the *EDIT PROGRAM* menu.

To access this function, access the *UTILITY* page under the *SYSTEM* menu, then place the cursor on *Identify Modules* and press the data entry dial. The display shows the following fields:



**1 Function name.**


Shows that you currently are in the *Identify Modules* function.

**2 Slot number.**

Shows the slot where you wish to identify the module.


**3 Module name.**

Shows the name of the module installed on the slot at point 2.



To identify the module installed on each slot of the instrument, follow this procedure.

1. Turn the data entry dial to select the module currently installed on the slot.
2. Press the dial to confirm and move to the following slot. Press [EXIT] instead to quit the function and return to the *UTILITY* page.
3. Repeat the operations at point 1 and 2 for all the instrument's slots. At the end of the procedure, the confirmation screen will appear,



here you will find the module icons for a quick check of the modules positions. If the positioning of each module is correct, press the data entry dial to confirm. The message “Allocation Completed!” will appear on screen. Press [EXIT] instead to cancel and return to the *UTILITY* page.

**NB**

If one of the slots has no module installed, during the identification procedure you must select the “empty” field for that slot.

## BACKUP ALL function

The *Backup All* function is used to save all the instrument's data to a USB flash drive plugged in the USB [TO DEVICE] connector. The data will appear as “BACKUP-XX.L7B” files (where XX is a progressive number between 01 and 99) in the “Legend'70s\BackUp” folder of the flash USB drive.

To back up your data, follow this procedure:

1. Access the *UTILITY* page under the *SYSTEM* menu, then place the cursor on *Backup All* field and press the data entry dial.



2. Turn the dial to select a backup number, that will be the name of the .L7B file, then press the dial. The message “Executing Backup...” will appear on screen.  
If the USB flash drive already contains a file with the same name, the screen will show the message: “*BACKUP-XX already exists. Overwrite?*” asking you if you wish to overwrite the file. Press the data entry dial to confirm or [EXIT] to cancel.
3. When the file is successfully saved, the message “*Backup Completed!*” appears on screen.

**NB**

When a backup file is overwritten, all data contained in the file is lost.

## RESTORE ALL function

The *Restore All* function is used to reload all the instrument data previously saved through the *Backup All* function to a USB flash drive (connected to USB [TO DEVICE]).

To load the backup data, follow this procedure:

1. Access the *UTILITY* page under the *SYSTEM* menu, then place the cursor on the *Restore* field and press the data entry dial.



2. Turn the dial to select a backup file among those available on the USB drive and press the dial to load the file. The system will ask for a confirmation with the following message: “*Reset all data in internal mem. Are you sure?*”. If you accept, all the data on the instrument will be irreparably lost. Press the data entry dial to confirm or [EXIT] to abort.
3. While loading the data, the system will show the following message on screen: “*Executing Restore...*”. When the procedure is complete, you will see the message “*Restore Completed!*”

**NB**

To avoid losing the data on the instrument, first make a backup of the data through the Backup All function (page 59) and only then load the data from the USB drive.

## FACTORY RESET function

The Factory Reset function restores all the original Programs, Songs and system parameters of the instrument's factory settings.

To perform a Factory Reset, follow this procedure:

1. Access the *UTILITY* screen of the *SYSTEM* menu, then select the *Factory Reset* function and press the data entry dial. The system will ask for a confirmation: "Reset all data in internal mem. Are you sure?". If you accept, all the user customisations on the instrument will be irreparably lost. Press the dial to confirm or [EXIT] to abort.
2. During the procedure the message "*Executing Factory Reset...*" will appear on screen. When the procedure is over, the instrument restarts automatically.

**NB**

To avoid losing the data on the instrument, first make a backup of the data through the Backup All function (page 59) and only then perform the factory reset.

## RELEASE/UPDATE function

The *Release/Update* function can be used to check the operating system version currently running on the instrument. Each time an update file is released it will be made available on the website: <http://www.viscountinstruments.com>. Update files are named L70S-XXX.L7U, where XXX stands for the update version. After the file has been downloaded, copy it to the main folder (root) of a USB flash drive.

To check the currently running operating system version, access the *UTILITY* page under the *System* menu and select the *Release* field:



To update the operating system, follow this procedure:

1. Save the update file to a USB flash drive, then connect the drive to the USB [TO DEVICE] connector.
2. Open the above mentioned video page, then press the data entry dial. The screen will show the name of the update file found in the USB drive in the field "File":



3. Make sure that this is the correct file, then press the data entry dial to start the update or press [EXIT] to abort the operation. Once the update has started, the system checks the file integrity and shows the message: "*Checking update...*". Then it loads the file, while showing the message: "*Updating...*" and the progress percentage. When the operation is over the message "*Update successful [Turn on/off]*".

## Updating the instrument's modules

It is possible to update not only the operating system, but each single module. When a new update is released, the update file will be made available on the website <http://www.viscountinstruments.com>. To update a module follow the same procedure described above for the operating system, with one difference: at point 2 turn the data entry dial in order to select the name of the module you wish to update, instead of the *Release* field.

**IMPORTANT NOTE!**

- *Do not disconnect the USB flash drive or switch off the instrument during the update procedure.*
- *Please make sure that the root folder of the USB flash unit contains only one .L7U file or only one module update file (e.g. only one .L7A update file for the A.PIANO module).*
- *Please visit the website <http://www.viscountinstruments.com> periodically to check for updates.*

## APPENDIX

### Quick functions

The following table describes all the actions that can be performed through the front panel buttons, without the need to access menus and scroll through pages on the display. When there is a combination of two buttons, hold down the first button of the pair, and in the meanwhile press the second button.

Button combination	Function	Described at page
<b>Short push of the REVERB category selection knob</b>	Select a reverb type from the selected category.	<a href="#">41</a>
<b>Long push of the REVERB category selection knob</b>	Access the menu containing all the reverb parameters	<a href="#">41</a>
<b>Short push of the EFFECTS category selection knob</b>	Select an effect preset from the selected category.	<a href="#">32</a>
<b>Long push of the EFFECTS category selection knob</b>	Access the menu containing all the effect parameters	<a href="#">32</a>
<b>[FX ON] + [ON/OFF] on a module</b>	Assign the effect to a module	<a href="#">42</a>
<b>[SPLIT] + [ON/OFF] on a module</b>	Activate the Split function on a module, assign the module to the Lower or Upper parts in a cycle.	<a href="#">31</a>
<b>[SPLIT] + key</b>	Activates the Split mode, sets the Split point	<a href="#">31</a>
<b>[EXIT] + [&lt;] or [&gt;] in Song mode</b>	Select a Song List.	<a href="#">48</a>
<b>Long push of a knob or of a sound selection button on a module</b>	Access the menu containing all the parameters of the selected sound.	<a href="#">42</a> , <a href="#">44</a> , <a href="#">46</a> , <a href="#">45</a>
<b>Long push of the [TREM ON] button on the E.PIANO module</b>	Activate the Tremolo effect and show the <i>Trem Wave</i> parameter to select the waveform of the modulating signal.	<a href="#">43</a>
<b>Long push of the [AMP ON] button on the E.PIANO module</b>	Activate the Amplifier effect and show the <i>Amp Drive</i> parameter to set the distortion quantity.	<a href="#">44</a>
<b>Long press of the [MUTE] button on the CLAVI module</b>	Activate the Mute and show the <i>Mute Value</i> parameter to set the decay time.	<a href="#">45</a>
<b>Long push of the MIDI message selection knob on the EXTERNAL module</b>	Access the menu containing all the module configurations.	<a href="#">47</a>

### Error messages

**NB**

Besides the error messages, you will find the name of an effect selection knob (page 9). The Led light of this knob will turn on if the system is unable to show the error message on the display. If a Led light turns on but it is not on this list, then contact the technical support at the e-mail address [service@viscount.it](mailto:service@viscount.it).

**Backup aborted!**

The system cannot save the backup file to the USB flash drive. Check that the USB flash drive is not write-protected, that it is formatted with the FAT32 file system and that it is undamaged.

**Backup files not detected!**

The flash drive does not contain any compatible backup file.

**Corrupted update file! – [PHASER] or [WAH] Led**

The update file you are trying to load is corrupted. Try downloading the file again from the website [www.viscountinstruments.com](http://www.viscountinstruments.com) and copying it to the USB flash drive, then repeat the procedure.

**Error in reading file! – [DELAY] Led**

The system cannot read the selected file. Make sure that the USB flash drive is connected properly and that it is undamaged.

**INTERNAL ERROR #”X”**

These error messages are shown when the instrument is switched on, if one or more of its components aren't working properly. Instead of an "X" you will see a number, according to the type of device and of error, followed by the message [Update required] or [Contact service].

If you see the message: "[Update required]", the malfunctioning might be solved by installing the operating system again (page 60). If you still see the same message again after the update, or if it changes to [Contact service], you need to contact the technical support by writing an email to [service@viscount.it](mailto:service@viscount.it) indicating the error message and the number that appears on screen.

**Memory is protected!**

Programs or Songs cannot be saved and backup files cannot be loaded, because the *Memory Lock* function is active (page 57).

**Not recognized as backup file.**

The file you are trying to load is not a *Legend '70s* compatible backup file.

**Restore aborted!**

The backup file you are loading is corrupted. Try copying the file again to the USB drive, then repeat the procedure.

**Too many update files!**

The USB flash drive contains more than one update file. The root folder of the flash drive should contain only one system update file.

**Update Failed. Error #”X”. [Please retry]**

The operating system or module update failed. Restart the instrument (switch off, then on again), leaving the USB drive connected to the port: the instrument will try to update again. If the same error message appears after the new update, contact the technical support by writing an email to [service@viscount.it](mailto:service@viscount.it), including the error message and the number that appears on screen.

**Update file not detected! – 3 blinking leds**

No update file was detected in the USB flash drive currently connected to the instrument.

**USB charger active**

You are trying to update the system despite the fact that the USB [TO DEVICE] port is currently set so as to power/charge an external device (page 57).

**USB charger OVERCURRENT [Extract device]**

The external device you are trying to charge through the USB [TO DEVICE] port requires too much power. To avoid malfunctions, the port is deactivated for 10 seconds. Disconnect the device and check that it is undamaged.

**USB flash drive DAMAGED [Extract drive]**

The flash drive connected to the USB [TO DEVICE] port is not working properly. To avoid malfunctions, the port is deactivated for 10 seconds. Disconnect the USB drive and check that it is undamaged.

**USB flash drive not detected!**

The system does not detect the USB flash drive that is necessary for the current operation. If the correct USB flash drive is connected to the instrument, disconnect it then connect it again. Also check that the flash drive is formatted correctly with the FAT32 file system and that it is undamaged.

**USB flash drive not detected! – 3 blinking leds**

The system does not detect the USB flash drive that is necessary for the operating system update. If the correct USB flash drive is connected to the instrument, disconnect it then connect it again.

**Wrong backup file!**

The backup file you are trying to load is not compatible with the instrument.

**Wrong format. Newer software is required**

The backup file you are trying to load was generated with an operating system that is more recent than the version currently running on your instrument. Update the instrument to the latest available operating system version.

**Wrong update file!**

The backup file you are trying to load is not compatible with the instrument. Try downloading the file again from the website [www.viscountinstruments.com](http://www.viscountinstruments.com) and copy it to the USB flash drive, then repeat the procedure.

## Troubleshooting

**The instrument does not switch on.**

- Check that the external power supply is connected to the instrument and the power cable is properly plugged to the socket.
- Make sure that the power socket is working.

**The instrument shut down by itself.**

- The *Auto Power Off* function is active. To disable the function, see page [57](#).

**The instrument makes no sound.**

- Make sure that the [MASTER VOLUME] knob is not in its minimum position (to the far left).
- The external speaker system is switched off or its volume is too low.
- Check that the connected foot controller assigned to the Expression function (page [29](#)) is not on its minimum position (fully raised).
- Make sure that the modules are not all off, or that their [VOLUME] knob is not on its minimum position (to the far left).
- The volume or MIDI expression was set to minimum by an external MIDI controller.

**The sound is distorted.**

- Lower the volume.
- A distortion effect was applied by one of the Amp category effects. If you do not wish any distortion, set the *Drive* parameter to 0 (page [37](#) and [44](#)).

**No effect can be heard.**

- Make sure that the module you are playing is assigned to an effect (page [42](#)) and that the effect is active (page [10](#)).

**The data exchange with a connected computer is not working properly.**

- Make sure that the computer port settings are correct.
- Make sure that the *MIDI Control Port* function (page [55](#)) is set on the correct interface (MIDI or USB).

**The instrument can't save data on the connected USB drive.**

- Make sure that the USB flash unit is not write-protected.
- Only use flash drives using the FAT or FAT32 file system (no NTFS or other).

## List of effect presets

REVERB categories	Preset
Room	Small Room, Large Room
Hall	Small Hall, Medium Hall, Large Hall
Stage	Stage 1, Stage 2
Plate	Medium Plate, Large Plate
Spring	Spring 1, Spring 2
Tape	Tape 1, Tape 2

EFFECTS categories	Preset
Tremolo	Custom, Opto Tremolo, 1960s Tremolo, Light Tremolo, Wide Tremolo, Stereo Pan, Slicer Tremolo, Psych Tremolo, 1970s Vibrato, Modern VB-Z, 1960s Vibrato, Light Vibrato, Ghost Vibrato, Badoon Vibrato
Chorus	Custom, 1970s Chorus, St. Slow Chorus, Stereo Chorus, Modern CH-Z, Light Chorus, Wide Chorus, Dream Chorus
Flanger	Custom, Stress-me I, Stress-me II, Gentle Flanger, Color Flanger, Dry Flanger
Phaser	Custom, Stage Phaser, PH90, Modern Phaser, Deep Phaser, PH DeluxePhaser, Spread Phaser

<b>Wah</b>	Custom, Cry Wah, Gun Wah, UK Wah, Drop Wah, AutoWah-1, AutoWah-2, AutoWah-3, AutoWah-4, Stage T-Wah, Q-Wah, LT-Wah
<b>Delay</b>	Custom, Short Tail, Long Tail, Neverending, Ping Pong, One Shot, Double Shot,
<b>Others - PEQ3</b>	Custom, Mid Boost, Mid Scoop, More Mids, Bass Eq, Ultra Bass
<b>Others - PEQ5</b>	Custom, Bright Eq, Dark Eq, AGuit Eq, Piano Eq, Funky Eq
<b>Others - GEQ5</b>	Custom, V-Mid, Hi Smooth, Bass Cut, Huge Bass, Light Eq
<b>Others - Comp</b>	Custom, Generic, Gentle, Acoustic, Precise, LeadGtr, Punchy, Loud, Brute
<b>Others - Rotary</b>	Custom, Clean, Jazz, Blues, Rock, Horn Mic, Basic, Fat Drum

## List of Sound Collection sounds

Category	#	Sound	Knob 1	Knob 2	Knob 3
<b>Pad</b>	1	Warm Pad	Filter Cutoff	Attack Time	Release Time
	2	Reso Pad	Filter Cutoff	Attack Time	Release Time
	3	Square Pad	Filter Cutoff	Attack Time	Release Time
	4	Poly Pad	Filter Cutoff	Attack Time	Release Time
	5	Sweep Pad	Filter Cutoff	Attack Time	Release Time
	6	Dark Pad	Filter Cutoff	Attack Time	Release Time
	7	DSS Pad	Filter Cutoff	Attack Time	Release Time
	8	DSS Octa Pad	Filter Cutoff	Attack Time	Release Time
	9	DSS Smooth	Filter Cutoff	Attack Time	Release Time
	10	LFO Pad	Filter Cutoff	Attack Time	Release Time
	11	Slow ResoPad	Filter Cutoff	Attack Time	Release Time
<b>Strings</b>	1	Str Ensemble	Filter Cutoff	Attack Time	Release Time
	2	Dyna Strings	Filter Cutoff	Attack Time	Release Time
	3	Octa Strings	Filter Cutoff	Attack Time	Release Time
	4	Med Ensemble	Filter Cutoff	Attack Time	Release Time
	5	Pizzicato	Filter Cutoff	Decay Time	Release Time
	6	Trio Concert	Filter Cutoff	Attack Time	Release Time
	7	Solina Violin	Filter Cutoff	Attack Time	Release Time
	8	Solina Duo	Filter Cutoff	Attack Time	Release Time
	9	Crumar Perf.	Filter Cutoff	Attack Time	Release Time
	10	PWM Strings	Filter Cutoff	Attack Time	Release Time
<b>Choir</b>	1	Choir Oohs	Filter Cutoff	Attack Time	Release Time
	2	Soft Aahs	Filter Cutoff	Attack Time	Release Time
	3	Choir Oohs	Filter Cutoff	Attack Time	Release Time
	4	Gregorian	Filter Cutoff	Attack Time	Release Time
	5	Boys Aahs	Filter Cutoff	Attack Time	Release Time
	6	Gospel Aahs	Filter Cutoff	Attack Time	Release Time
	7	Gospel Uhhs	Filter Cutoff	Attack Time	Release Time
	8	Gospel Dooh	Filter Cutoff	Attack Time	Release Time
	9	Gospel Bah	Filter Cutoff	Attack Time	Release Time
	10	Soul Uhhs	Filter Cutoff	Attack Time	Release Time
	11	Soul Mmh	Filter Cutoff	Attack Time	Release Time
<b>Brass</b>	1	Big Band	Filter Cutoff	Attack Time	Release Time
	2	Brass Band	Filter Cutoff	Attack Time	Release Time
	3	Brass Falls	Filter Cutoff	Attack Time	Release Time
	4	Soul Horns	Filter Cutoff	Attack Time	Release Time
	5	Vintage Horns	Filter Cutoff	Attack Time	Release Time
	6	Brass Section	Filter Cutoff	Attack Time	Release Time
	7	Soft Horns	Filter Cutoff	Attack Time	Release Time
	8	Sax Section	Filter Cutoff	Attack Time	Release Time
	9	Symp Brass	Filter Cutoff	Attack Time	Release Time
	10	Mellow Horns	Filter Cutoff	Attack Time	Release Time
	11	French Horns	Filter Cutoff	Attack Time	Release Time
	12	SynBrass '82	Filter Cutoff	Attack Time	Release Time
	13	SynBrass '84	Filter Cutoff	Attack Time	Release Time
	14	OB Brass	Filter Cutoff	Attack Time	Release Time
	15	OB Smooth	Filter Cutoff	Attack Time	Release Time
	16	PWM Brass	Filter Cutoff	Attack Time	Release Time
	17	Fat Brass	Filter Cutoff	Attack Time	Release Time

<b>Keys</b>	1	Grand Piano	Attack Time	Decay Time	Release Time
	2	Bright Piano	Attack Time	Decay Time	Release Time
	3	House Piano	Filter Cutoff	Attack Time	Release Time
	4	Electric Grand	Attack Time	Release Time	Efx Send
	5	Digital '80	Filter Cutoff	Release Time	Efx Send
	6	Mark 73	Filter Cutoff	Efx Rate	Efx Depth
	7	Wurl 140B	Filter Cutoff	Efx Rate	Efx Depth
	8	DX Memories	Filter Cutoff	Attack Time	Release Time
	9	Full Tines	Filter Cutoff	Attack Time	Release Time
	10	Crystal EP	Filter Cutoff	Attack Time	Release Time
	11	Harpsichord	Filter Cutoff	Attack Time	Release Time
	12	Clavinet	Filter Cutoff	Attack Time	Release Time
	13	Velo Duck	Filter Cutoff	Attack Time	Release Time
	14	Accordion	Filter Cutoff	Attack Time	Release Time
	15	Bandeon	Filter Cutoff	Attack Time	Release Time
	16	Musette	Filter Cutoff	Attack Time	Release Time
<b>Organ</b>	1	Jazz Organ	Percussion	Rotary Speed	Rotary
	2	Even Bars	Percussion	Rotary Speed	Rotary
	3	Bright Organ	Percussion	Rotary Speed	Rotary
	4	Full Bars	Percussion	Rotary Speed	Rotary
	5	Gospel Organ	Percussion	Rotary Speed	Rotary
	6	Lower Man	Percussion	Rotary Speed	Rotary
	7	Vox Organ 1	High Bars	Release Time	Vibrato Depth
	8	Vox Organ 2	High Bars	Release Time	Vibrato Depth
	9	Transistor	Filter Cutoff	Release Time	Vibrato Depth
	10	Bourdon 8'	Filter Cutoff	Attack Time	Release Time
	11	Principal 8'	Filter Cutoff	Attack Time	Release Time
	12	Voce Umana	Filter Cutoff	Attack Time	Release Time
	13	Principal 8'+4'	Filter Cutoff	Attack Time	Release Time
	14	Plenum 8'	Filter Cutoff	Attack Time	Release Time
	15	Plenum 16'	Filter Cutoff	Attack Time	Release Time
<b>Bass</b>	1	Acoustic Bass	Attack Time	Release Time	Efx Send
	2	Fingered Bass	Filter Cutoff	Release Time	Release Noise
	3	Picked Bass	Filter Cutoff	Attack Time	Release Time
	4	Fretless Bass	Filter Cutoff	Attack Time	Release Time
	5	Sting Bass	Filter Cutoff	Attack Time	Release Time
	6	Slap Bass	Filter Cutoff	Attack Time	Release Time
	7	Synth Bass 1	Filter Cutoff	Attack Time	Release Time
	8	Synth Bass 2	Filter Cutoff	Attack Time	Release Time
	9	Synth Bass 3	Filter Cutoff	Attack Time	Release Time
	10	Synth Bass 4	Filter Cutoff	Attack Time	Release Time
	11	Synth Bass 5	Filter Cutoff	Attack Time	Release Time
	12	Synth Bass 6	Filter Cutoff	Attack Time	Release Time
<b>Others</b>	1	Nylon Guitar	Filter Cutoff	Attack Time	Release Time
	2	Ac. Guitar	Filter Cutoff	Attack Time	Release Time
	3	Steel Guitar	Filter Cutoff	Attack Time	Release Time
	4	12 Strings	Filter Cutoff	Attack Time	Release Time
	5	Jazz Guitar	Filter Cutoff	Release Time	Efx Send
	6	Clean Guitar	Filter Cutoff	Release Time	Efx Send
	7	Neck Pickup	Filter Cutoff	Release Time	Efx Send
	8	Muted Guitar	Filter Cutoff	Decay Time	Release Time
	9	Vibes	Filter Cutoff	Decay Time	Release Time
	10	Marimba	Filter Cutoff	Decay Time	Release Time
	11	Xylophone	Filter Cutoff	Attack Time	Release Time
	12	Steel Drum	Filter Cutoff	Attack Time	Release Time
	13	Celesta	Filter Cutoff	Decay Time	Release Time
	14	Bells	Filter Cutoff	Decay Time	Release Time
	15	Wood Bells	Filter Cutoff	Decay Time	Release Time
	16	Glockenspiel	Filter Cutoff	Decay Time	Release Time

**Disposal of old Electrical & Electronic Equipment (Applicable throughout the European Union and other European countries with separate collection programs)**



Dir. 2002/95/CE, 2002/96/CE e 2003/108/CE

This symbol, found on your product or on its packaging, indicates that this product should not be treated as household waste when you wish to dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment

and human health, which could otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resources. For more detailed information about the recycling of this product, please contact your local city office, waste disposal service or the retail store where you purchased this product.



This product complies with the requirements of EMCD 2004/108/EC and LVD 2006/95/EC.

## FCC RULES

**NOTE:** This equipment has been tested and found to comply with the limits for a **Class B** digital Device, pursuant to Part 15 if the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determinated by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio/Tv technician for help.

The user is cautioned that any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## INFORMATIONS FCC

**NOTE :** Cet instrument a été contrôlé et il est garanti pour être en conformité avec les spécifications techniques établies pour les dispositifs numériques de la « **Classe B** » selon les normes de protection contre les interférences avec d'autres dispositifs électroniques environnants. Cet appareil produit et utilise des fréquences radio. S'il n'est pas installé et utilisé selon les instructions contenues dans le mode d'emploi, il peut générer des interférences. L'observation des normes FCC ne garantit pas qu'il y aura aucune interférence. Si cet appareil est la cause d'interférences avec une réception Radio ou TV, il est possible de le vérifier en éteignant puis en allumant l'instrument : Vous pouvez alors résoudre le problème en suivant les procédures suivantes :

- déplacer ou orienter l'antenne de l'appareil avec lequel se manifeste l'interférence.
- déplacer cet instrument ou l'appareil avec lequel se produit l'interférence
- connecter cet instrument à une prise de courant différente afin de mettre les deux appareils sur deux circuits différents.
- consulter le revendeur ou un technicien radio/tv pour d'autres renseignements.

D'éventuelles modifications non approuvées par le constructeur peuvent annuler votre garantie de l'appareil.


# ATTENZIONE: LEGGERE ATTENTAMENTE!



Questo simbolo indica che all'interno dell'apparecchio è presente un'alta tensione non isolata, sufficientemente alta da causare il rischio di shock elettrico alle persone



Questo simbolo indica che la documentazione acclusa all'apparecchio contiene importanti istruzioni per l'uso e la manutenzione.



## "ISTRUZIONI RELATIVE AL RISCHIO DI FUOCO, SHOCK ELETTRICO O DANNI ALLE PERSONE"

### IMPORTANTI ISTRUZIONI DI SICUREZZA

#### ATTENZIONE:

- 1) Leggete queste istruzioni.
- 2) Conservate queste istruzioni.
- 3) Osservate tutte le avvertenze.
- 4) Seguite tutte le istruzioni.
- 5) Non usate questo apparecchio vicino all'acqua. Non esponetelo a sgocciolamenti o spruzzi. Non collocate su di esso oggetti pieni di liquidi, come ad esempio vasi da fiori.
- 6) Pulite l'apparecchio solo con un panno asciutto.
- 7) Non ostruite nessuna apertura per l'aria di raffreddamento. Installate l'apparecchio seguendo le istruzioni del produttore.
- 8) Non installate l'apparecchio accanto a fonti di calore, come radiatori, aperture per l'efflusso di aria calda, forni o altri apparecchi (compresi amplificatori) che generano calore.
- 9) Non modificate la spina con spinotto di protezione in modo da non dover usare quest'ultimo; esso ha lo scopo di tutelare la vostra incolumità. Se la spina in dotazione non è adatta alla presa di corrente, rivolgetevi a un elettricista per fare eseguire le modifiche necessarie.
- 10) La presa di corrente deve essere installata vicino all'apparecchio e deve essere facilmente accessibile.
- 11) Evitate che si cammini sul cavo di alimentazione o che esso sia compresso, specialmente in corrispondenza della spina, della presa di corrente e del punto di uscita dall'apparecchio.
- 12) Usate solo i dispositivi di collegamento e gli accessori specificati dal produttore
- 13) Usate l'apparecchio con carrelli, sostegni, treppiedi, staffe o tavoli specificati dal produttore o venduti insieme all'apparecchio stesso. Se usate un carrello, fate attenzione durante gli spostamenti per prevenire che si ribalti.
- 14) Durante i temporali o se non userete l'apparecchio per un lungo periodo, scollegatelo dalla presa di corrente.
- 15) Per qualsiasi intervento, rivolgetevi a personale di assistenza qualificato. È necessario intervenire sull'apparecchio ogniqualvolta venga danneggiato, in qualsiasi modo; per esempio se la spina o il cavo di alimentazione sono danneggiati, si è versato liquido sull'apparecchio o sono caduti oggetti su di esso, l'apparecchio è stato esposto alla pioggia o all'umidità, non funziona normalmente o è caduto.



**CONSERVARE QUESTE ISTRUZIONI**

# SOMMARIO

NOTE IMPORTANTI.....	2
Cura del prodotto .....	2
Note riguardanti il manuale .....	2
INTRODUZIONE .....	3
Caratteristiche principali.....	3
PANNELLO FRONTALE .....	5
Descrizione generale .....	5
Installazione dei moduli.....	6
Pannello principale .....	8
Controlli comuni a tutti i moduli .....	11
Modulo E.PIANO .....	11
Modulo A.PIANO .....	13
Modulo CLAVI.....	13
Modulo SOUND COLLECTION .....	14
Modulo EXTERNAL .....	15
PANNELLO POSTERIORE .....	17
ACCENSIONE ED OPERAZIONI DI BASE .....	19
Collegamento con dispositivi audio.....	19
Collegamento con dispositivi MIDI .....	20
Utilizzo con un computer.....	21
Utilizzo con un lettore audio portatile .....	21
Collegamento dei pedali .....	22
Utilizzo dei suoni.....	23
Utilizzo degli effetti.....	23
MODALITA' PROGRAM.....	25
Cosa e' un Program.....	25
Selezione di un Program .....	26
Memorizzazione di un Program .....	27
MODIFICA DI UN PROGRAM.....	28
Sezione COMMON .....	29
Sezione KEY RANGE .....	30
Sezione EFFECTS .....	32
Sezione REVERB .....	41
Sezione E.PIANO .....	42
Sezione A.PIANO .....	44
Sezione CLAVI .....	45
Sezione SOUND COLLECTION .....	46
Sezione EXTERNAL .....	47
MODALITA' SONG .....	49
Cosa è una Song .....	49
Selezione di una Song .....	49
Memorizzazione di una Song.....	50
MODIFICA DI UNA SONG O LIST.....	51
Funzione PARTS .....	51
Funzione ORDER .....	52
Funzione COPY/PASTE .....	52
Funzione LISTS .....	53
MENU SYSTEM.....	54
Sezione KEYBOARD .....	55
Sezione EQUALIZER.....	55
Sezione MIDI .....	56
Sezione PEDAL SETUP .....	57
Sezione PREFERENCES .....	58
MENU UTILITY .....	59
Funzione IDENTIFY MODULES .....	59
Funzione BACKUP ALL .....	60
Funzione RESTORE ALL .....	60
Funzione FACTORY RESET .....	61
Funzione RELEASE/UPDATE .....	61
APPENDICE.....	63
Funzioni rapide .....	63
Messaggi di errore .....	63
Risoluzione ai problemi più comuni .....	65
Lista dei preset degli effetti .....	65
Lista dei suoni Sound Collection .....	66
MIDI Informations .....	MIDI - 1

## NOTE IMPORTANTI

### Cura del prodotto

- Non applicate eccessiva forza alle strutture ed ai comandi dello strumento (manopole, pulsanti, tastiera ecc...).
- Non collocare, quando possibile, lo strumento in prossimità di unità che producano forti interferenze come apparecchi radio – TV, monitor, ecc...
- Evitate di posizionare lo strumento in prossimità di fonti di calore, in luoghi umidi o polverosi o nelle vicinanze di forti campi magnetici.
- Evitate di esporre lo strumento all'irradiazione solare diretta.
- Non introdurre per nessuna ragione oggetti estranei o liquidi di qualsiasi genere all'interno dello strumento.
- Per la pulizia usate solo un pennello morbido od aria compressa, non usate mai detergenti, solventi od alcool.
- Per il collegamento con impianti di amplificazione e diffusione utilizzate sempre cavi schermati di buona qualità. Quando scollegate i cavi dalle prese abbiate cura di afferrarli per il connettore e non per il cavo stesso; avvolgendoli, inoltre, evitate nodi e torsioni.
- Prima di effettuare i collegamenti accertatevi che le altre unità (in particolar modo sistemi di amplificazione e di diffusione) che state per collegare siano spente. Eviterete rumorosi se non pericolosi picchi di segnale.
- Collegate il cavo di alimentazione ad una presa di corrente provvista di contatto di terra.
- Accertatevi che la tensione di rete corrisponda a quella indicata sulla targhetta matricola dell'apparato.
- In caso di lunghi periodi di inutilizzo dello strumento scollegate la spina della presa di corrente.
- Non posizionare il cavo di alimentazione in prossimità di fonti di calore. Non piegarlo eccessivamente, né danneggiarlo.

### Note riguardanti il manuale

- Conservate con cura questo manuale.
- Il presente manuale costituisce parte integrante dello strumento. Le descrizioni e le illustrazioni contenute nella presente pubblicazione si intendono non impegnative.
- Ferme restando le caratteristiche essenziali dello strumento, il costruttore si riserva il diritto di apportare eventuali modifiche di parti, dettagli ed accessori che riterrà opportune per il miglioramento del prodotto o per esigenze di carattere costruttivo o commerciale, in qualunque momento e senza impegnarsi ad aggiornare tempestivamente questa pubblicazione.
- Tutti i diritti sono riservati, è vietata la riproduzione di qualsiasi parte di questo manuale, in qualsiasi forma, senza l'esplicito permesso scritto del costruttore.
- Tutti i marchi citati all'interno del manuale sono di proprietà delle rispettive case produttrici.
- Leggete attentamente tutte le informazioni descritte. Eviterete inutili perdite di tempo ed otterrete le migliori prestazioni dallo strumento.
- Le sigle od i numeri riportati tra parentesi quadre ([ ]) stanno ad indicare i nomi dei pulsanti, potenziometri e connettori presenti sullo strumento. Per esempio la scritta [ON/OFF] indica il pulsante con scritto ON/OFF in serigrafia.
- Le illustrazioni sono puramente a scopo informativo e possono differire dal vostro prodotto.
- Le informazioni descritte nel presente manuale fanno riferimento alla versione del sistema operativo dello strumento presente quando il documento è stato redatto e potrebbero non rispecchiare le funzionalità della versione che state utilizzando. Pertanto consultate il sito internet [www.viscountinstruments.com](http://www.viscountinstruments.com) per conoscere l'ultima versione del sistema operativo e la disponibilità di un manuale più aggiornato.

**Il presente manuale d'uso è aggiornato alla versione 1.00 del sistema operativo dello strumento.**

# INTRODUZIONE

## Caratteristiche principali

*Legend '70s* è uno strumento che nasce con l'intento di ricordare nel design gli storici pianoforti elettrici degli anni settanta e allo stesso tempo di fornire al musicista tutte quelle sonorità che hanno caratterizzato la scena musicale di questo fantastico periodo. Oltre a ciò unisce all'aspetto vintage le funzionalità tipiche dello stage piano di concezione moderna e la capacità di adattarsi facilmente alle differenti esigenze dei musicisti e ai mutevoli contesti musicali nei quali viene impiegato.

Ma *Legend '70s* non è solo una rielaborazione di strumenti famosi del passato. Questo prodotto introduce nel panorama degli stage piano, per la prima volta in assoluto, il concetto di modularità e scalabilità, offrendo al musicista, diversamente da tutti gli altri pianoforti digitali presenti sul mercato, la possibilità di scegliere la configurazione più adatta alle proprie esigenze, nei tempi e nei modi desiderati.

### • Il feeling del piano vintage

*Legend '70s* propone nelle forme il caratteristico aspetto vintage degli anni passati, che rende lo strumento immediatamente riconoscibile sul palco. Il pannello in stile retrò, con la finitura nera e liscia, combinato agli elementi decorativi in alluminio, rende omaggio al pianoforte elettrico per eccellenza, diventato protagonista delle scene musicali a partire dai primi anni settanta.

Non di meno, l'ampia superficie piana offerta dallo strumento può essere utilizzata come superficie di appoggio per altri dispositivi, come ad esempio una tastiera, un computer, un tablet o persino tutti e tre. Questa peculiarità, appositamente studiata in fase di progetto, è un valore aggiunto che risponde ad una reale esigenza del musicista e rende *Legend '70s* ancora più interessante rispetto a prodotti simili, senza penalizzare in alcun modo la portabilità e il peso complessivo dello strumento.

Lo stand nero opzionale, con gambe in alluminio regolabili, completa il quadro di uno strumento che di certo non farà rimpiangere i suoi predecessori, neppure ai musicisti più nostalgici.

### • La potenza del piano stage

*Legend '70s* si presenta come un piano elettrico vintage, ma ha tutte le caratteristiche tipiche di uno piano stage moderno. Lo strumento dispone infatti di una molteplicità di suoni di vario genere che comprendono piani elettrici, piani acustici, strings, pads, bassi, chitarre, brass, organi, cori, e molti altri, grazie ai moduli di generazione aggiuntivi installati nello strumento. Questi suoni possono essere combinati tra loro in zone di tastiera diverse, secondo il range definito per ciascuno di essi, o possono essere associati alla parte Lower e Upper della tastiera, utilizzando la più semplice funzionalità di Split. Tutto questo, elaborato da una catena effetti di altissima qualità, permette di ricreare sonorità di qualunque genere.

*Legend '70s* fornisce le funzionalità tipiche del pianoforte da palco, come la trasposizione generale e di parte, l'accordatura fine, la possibilità di scegliere la curva dinamica più adatta e di modificare la sensibilità del suono al tocco per ciascuno dei suoni utilizzati. Lo strumento è dotato, inoltre, di funzioni avanzate di master-keyboard, che permettono il controllo di dispositivi esterni collegati alle prese MIDI e USB.

Inoltre, il numero elevato di controlli disponibili a pannello permette al musicista di accedere immediatamente alle funzioni principali dello strumento durante l'esecuzione del brano e la presenza delle ruote di pitch bend e modulation wheel rendono la performance ancora più incredibile.

### • La flessibilità del piano modulare

*Legend '70s* introduce, per la prima volta, il concetto di piano modulare, offrendo al musicista, come mai nessuno aveva fatto prima, la possibilità di comporre il proprio strumento, scegliendo i moduli di generazione più adatti alle proprie esigenze.

Lo strumento si presenta con un ampio pannello frontale, composto da una sezione principale e da alcune sezioni mobili, da installare in appositi slot, detti "moduli". Grazie ad un progetto meccanico mirato il musicista può accedere con grande facilità ed in qualsiasi momento ai singoli slot, installando i moduli da lui scelti nella posizione che più desidera, rendendo lo strumento completamente personalizzabile e aggiornabile nel tempo.

Questi moduli sono dotati di generazione sonora allo stato dell'arte e di una interfaccia dedicata in grado di offrire la massima espressione tecnologica per ciascuna tipologia timbrica. Ogni modulo è progettato per consentire al musicista un accesso facile e veloce e i controlli principali, posizionati in maniera ergonomica, garantiscono una regolazione del suono veloce ed intuitiva.

## • Suoni ed effetti di eccellente qualità

I suoni di *Legend '70s* sono stati sviluppati studiando tutti i meccanismi dello strumento originale al fine di garantire il massimo realismo possibile. I suoni di pianoforte elettronico rappresentano la più alta espressione della tecnologia a modelli fisici **Viscount PM (Physical Modeling)**, che permette di generare il suono in base a modelli matematici che tengono conto di come lo strumento originale è realmente costruito ed in che maniera genera il suono. Altri suoni, come i pianoforti acustici, gli strumenti a fiato, gli archi, gli organi, i bassi, ecc... utilizzano la tecnologia **Viscount HDS (High Definition Sampling)** che, avvalendosi delle più evolute tecniche di multi-campionamento, permette in tempo reale di riprodurre la forma d'onda corretta in funzione dell'altezza e della dinamica di ogni singola nota. Questo e l'utilizzo di una tecnologia di filtri di alta qualità, applicati ai campioni audio, assicurano allo strumento suoni ricchi, autentici e dall'elevato realismo sonoro.

Oltre ai suoni di eccellente qualità, *Legend '70s* mette in campo una sezione effetti di tutto rispetto, appositamente studiati per questo prodotto, tra i quali si possono trovare effetti classici di modulazione come tremolo, vibrato, chorus, flanger, phaser, wah, oltre agli immancabili effetti di riverbero, delay, equalizzazione, compressore e ad un'ampia varietà di amplificatori. Tutti gli effetti sono stati progettati per ricreare quelli più famosi dell'epoca, che è possibile ritrovare in brani leggendari che hanno fatto la storia della musica di tutti i tempi.

## • Tastiera e curva di dinamica

Tutti i modelli sono equipaggiati con tastiera pesata con hammer action di elevata qualità in grado di garantire una risposta al tocco precisa e fedele agli strumenti originali. I 3 sensori di contatto, sotto ogni tasto, sono in grado di rilevare il movimento corrispondente con la massima precisione.

Per il musicista più esigente, il modello *Artisit-W* offre una disposizione dei martelli graduata in cui il loro peso diventa più leggero nelle zone alte della tastiera. Inoltre, come nel tradizionale pianoforte acustico a coda, la tastiera dell'*Artist-W* è arricchita da tasti di pianoforte in vero legno. Questi tasti sono realizzati in legno accuratamente selezionato e stagionato per eliminare eventuali difetti o deformazioni e fornire la massima uniformità e stabilità nel tempo.

Grazie alla disponibilità di diverse curve di dinamica è possibile personalizzare ulteriormente la risposta del suono alla forza impressa sui tasti. E' possibile sovrapporre i suoni su tutta l'estensione della tastiera, oppure dividere la stessa in più zone assegnando ad ognuna un suono, così da poter essere suonato dalla mano destra, dalla sinistra od entrambe.

## • Elevato livello di connettività

Lo strumento è dotato di quattro uscite audio di linea analogiche ed un ingresso audio analogico. Dispone di un'interfaccia USB Audio/MIDI che, con un singolo cavo USB, permette di ricevere e quindi riprodurre la sorgente audio del dispositivo collegato o di un virtual instrument controllato da *Legend '70s*. I collegamenti MIDI con dispositivi esterni sono inoltre garantiti dai classici connettori DIN a 5 poli.

E' possibile controllare lo strumento con un massimo di 6 pedali, uno con funzione di selezione dei Program, uno con funzione Sustain ed altri quattro la cui funzione è programmabile. E' altresì presente l'utilizzo di una unità flash USB per il salvataggio e caricamento delle proprie programmazioni e per l'aggiornamento del sistema operativo dello strumento. Con la stessa connessione USB è possibile alimentare e ricaricare dispositivi multimediali come smartphone e tablet.

## • Software di editing


A supporto del *Legend '70s* è disponibile un software di editing che consente la programmazione di tutti i parametri dello strumento in modo più agevole ed immediato. Inoltre permette agli utenti più esigenti di agire su parametri che non sono disponibili a pannello, ottenendo così la regolazione fine dei suoni e degli effetti. E' altresì possibile salvare su computer e ricaricare quando desiderato le proprie programmazioni.

Il software è disponibile in ambiente Windows, Mac Os e iOS, e può essere scaricato gratuitamente dal sito ufficiale Viscount [www.viscountinstruments.com](http://www.viscountinstruments.com).

# PANNELLO FRONTALE

## Descrizione generale

Il pannello frontale è costituito da una sezione principale e dai moduli installati nello strumento, come descritto a pagina 3.



### NOTE

- Il disegno di cui sopra fa riferimento ai modelli Artist-W ed Artist equipaggiati con tutti i moduli. I moduli sono comunque identici per tutti i modelli, con l'unica differenza sul numero di quelli installabili ovvero 5 nei modelli Artist-W ed Artist e 4 nel Compact.
- La disposizione ed il numero dei moduli presenti nelle illustrazioni e nelle videate a display riportati nel manuale sono puramente a scopo informativo in quanto possono essere liberamente modificati in base alle necessità dell'utilizzatore.

### 1 Sezione principale (pag. 8).

In questa sezione sono raccolti i controlli del volume e dell'equalizzazione generale dello strumento, degli effetti, della selezione dei Program e delle Song e di tutti i parametri ed impostazioni dello strumento.

### 2 Modulo E.PIANO (pag. 11).

Modulo di selezione e controllo dei suoni di piano elettrico.

### 3 Modulo A.PIANO (pag. 13).

Modulo di selezione e controllo dei suoni di pianoforte acustico.

### 4 Modulo CLAVI (pag. 13).

Modulo di selezione e controllo dei suoni Clavinet.


### 5 Modulo SOUND COLLECTION (pag. 14).

Modulo di selezione e controllo dei suoni pad, archi, cori, fiati, tastiere, organi, bassi ed altri di vario genere.

### 6 Modulo EXTERNAL (pag. 15).

Modulo per il controllo di dispositivi MIDI esterni.

## Ruote




A sinistra della tastiera sono presenti due ruote per il controllo in tempo reale dei suoni.

La ruota 1 è dotata di ritorno in posizione centrale e viene utilizzata per il controllo in maniera continua dell'intonazione dei suoni (Pitch Bend).

La ruota 2, seppur di norma assegnata al controllo della modulazione, è programmabile ed assegnabile a diverse funzioni (vedi parametro *Mod.Wheel Dest* a pagina 29).

## Connessione cuffie



Sulla sinistra, sotto la tastiera, è presente un connettore jack da 1/4" per il collegamento di un set di cuffie.

### NOTE

- Al fine di evitare danni all'udito si consiglia di non utilizzare le cuffie con livelli di volume elevati.
- Il collegamento delle cuffie non ha alcun effetto sui segnali presenti sulle uscite AUDIO OUT MAIN [L/MONO], [R] e AUX [1], [2] presenti nel pannello posteriore (pag. 17).


## Installazione dei moduli

Come abbiamo visto, il pannello frontale di *Legend '70s* è costituito di una sezione principale preinstallata in fabbrica più altri moduli aggiuntivi. In mancanza di questi moduli sono presenti dei pannelli senza alcun controllo. Questi sono gli slot in cui è possibile posizionare i moduli.





Per procedere con l'installazione di un modulo seguire questa procedura:

1. Assicurarsi che lo strumento sia spento e scollegare il cavo di alimentazione.
2. Svitare le viti poste sulla barra di copertura, posizionata tra il top dello strumento ed il pannello frontale e rimuovere la barra. Conservare le viti in quanto dovranno essere riutilizzate per fissare la barra (Fig. A).


Fig. A



3. Svitare le due viti poste sullo slot in cui si desidera installare il modulo ed estrarre il pannello di copertura dello slot. Conservare le viti in quanto dovranno essere riutilizzate per fissare il modulo (Fig. B).
4. Collegare il cavo flat-cable presente nell'imballo del modulo ai connettori (1) dello slot e (2) del modulo (Fig. C).
5. Posizionare il modulo sul pannello frontale dello strumento inserendo prima i denti presenti nel lato inferiore dello stesso nelle guide della base interna del pannello (Fig. D).
6. Fissare il modulo al pannello frontale utilizzando le viti svitate al punto 3 (Fig. E).



7. Riposizionare la barra di copertura sul top e sul pannello frontale e bloccarla con le viti svitate al punto 2.




#### NOTA

- Ogni qualvolta si modifica la disposizione dei moduli, si consiglia di eseguire la funzione Identify Modules descritta a pagina 59.
- Non è possibile installare più di un modulo dello stesso tipo.

## Pannello principale

Il pannello principale costituisce la sezione fissa dello strumento, nella quale è possibile trovare il controllo di volume generale, una sezione di equalizzazione a tre bande, una sezione per il controllo del riverbero, una sezione di controllo degli effetti ed una sezione per la programmazione di tutti i parametri visualizzati a display, utilizzati per la regolazione dei suoni, degli effetti e dei parametri di sistema del *Legend '70s*.



### Controllo di volume e sezione EQUALIZER

#### 1 Manopola [MASTER VOLUME].

Manopola per la regolazione del volume generale dello strumento.

#### 2 Slider EQUALIZER [LOW], [MID] e [HIGH].

Slider per l'equalizzazione del segnale generale dello strumento. Ogni slider ha un range di regolazione del guadagno da -12 dB a +12 dB delle frequenze basse [LOW], medie [MID] ed alte [HIGH].

L'equalizzatore agisce complessivamente sui segnali stereo delle uscite MAIN [L/MONO] ed [R] e dell'uscita cuffia, mentre le due uscite AUX [1] e [2] non vengono influenzate. A display sono disponibili diversi parametri di regolazione dell'equalizzatore, per maggiori informazioni consultare la *Sezione Equalizer* (pag. 55).

### Controlli della sezione REVERB

Questa sezione del pannello principale raccoglie i controlli principali dell'effetto di riverbero dello strumento.

L'effetto di riverbero agisce complessivamente sui segnali stereo delle uscite MAIN [L/MONO] ed [R] e dell'uscita cuffia, mentre le due uscite AUX [1] e [2] non vengono influenzate dall'effetto.

A display sono disponibili diversi parametri di regolazione dell'effetto di riverbero, per maggiori informazioni consultare la *Sezione Reverb* (pag. 41).

#### 3 Manopola per la selezione della categoria di riverbero.

Le categorie di riverbero sono:

Riverbero	Descrizione
Room	Simulazione dell'acustica di una stanza.
Hall	Simulazione dell'acustica di una sala da concerto.
Stage	Simulazione di un ambiente live.
Plate	Simulazione della vibrazione di una piastra metallica, molto in voga negli anni '70.
Spring	Simulazione del riverbero elettro-mecanico a molla, utilizzato negli amplificatori degli anni '70.
Tape	Simulazione del riverbero prodotto utilizzando un registratore a nastro e una camera riverberante.

#### NOTA

- Premere questa manopola per selezionare il tipo di riverbero della categoria selezionata.
- Tenere premuta per qualche istante la manopola per visualizzare i parametri di regolazione del riverbero.

**4 Manopola [DRY / WET].**

Permette il bilanciamento tra segnale diretto e segnale riverberato.

**5 Pulsante [REV ON].**

Pulsante di accensione/spegnimento dell'effetto di riverbero.

## Controlli della sezione EFFECTS

La sezione EFFECTS comprende i controlli principali degli effetti dello strumento. Gli effetti disponibili sono due, indipendenti, con lo stesso set di controlli ma ciascuno con i propri valori. Alla selezione di uno dei due effetti, i Led dei controlli di questa sezione vengono aggiornati in base alle impostazioni dell'effetto al momento selezionato.

A display sono disponibili diversi parametri di regolazione dell'effetto, per maggiori informazioni consultare la *Sezione Effects* (pag. 32).

**6 Manopola per la selezione della categoria di effetto.**

Le categorie di effetto sono:

Effetto	Descrizione
Tremolo	Effetto di tremolo o vibrato. Ruotare la manopola [AMOUNT] per regolare la profondità dell'effetto e la manopola [RATE] od il pulsante [TAP] per la velocità di modulazione.
Chorus	Effetto di chorus. Ruotare la manopola [AMOUNT] per regolare la quantità di effetto e la manopola [RATE] od il pulsante [TAP] per la velocità di modulazione.
Flanger	Effetto di flanger. Ruotare la manopola [AMOUNT] per regolare la quantità di effetto e la manopola [RATE] od il pulsante [TAP] per la velocità di modulazione.
Phaser	Effetto di phaser. Ruotare la manopola [AMOUNT] per regolare il feedback dell'effetto e la manopola [RATE] od il pulsante [TAP] per la velocità di modulazione.
Wah	Effetto di wah-wah. Ruotare la manopola [AMOUNT] per regolare la risonanza del filtro. Il parametro controllato dalla manopola [RATE] od il pulsante [TAP] dipende dal tipo di Wah selezionato.
Amp	Effetto di amplificatore. Ruotare la manopola [AMOUNT] per regolare la quantità di distorsione e la manopola [RATE] per il livello in uscita dall'effetto.
Delay	Effetto di delay. Ruotare la manopola [AMOUNT] per regolare la quantità di effetto e la manopola [RATE] od il pulsante [TAP] per il tempo tra le ripetizioni del segnale.
Others	Effetti di vario genere (equalizzatori, compressori, Rotary, ecc..). Per una descrizione dettagliata consultare la <i>Sezione Effects</i> (pag. 32).

**NOTA**

- Premere questa manopola per selezionare il preset di effetto della categoria selezionata.
- Tenere premuta per qualche istante la manopola per visualizzare i parametri di regolazione dell'effetto.

**7 Pulsanti di selezione dell'effetto.**

Come descritto nelle note introduttive di questa sezione, gli effetti disponibili sono due. Per selezionare l'effetto desiderato, così da controllarne i parametri principali tramite i controlli a pannello di questa sezione, utilizzare i pulsanti [1] e [2]. Alla selezione di uno o dell'altro effetto i Led dei controlli vengono aggiornati in base alle impostazioni dell'effetto al momento selezionato. Il Led lampeggiante del pulsante [1] o [2] indica che l'effetto non selezionato è comunque acceso.

**8 Manopola [AMOUNT].**

Utilizzare questa manopola per regolare la profondità dell'effetto selezionato. Per maggiori informazioni sui parametri regolati da questo controllo consultare il punto 6 di questa sezione o la *Sezione Effects* (pag. 32).

**9 Pulsante [TAP].**

Utilizzare questo pulsante per impostare manualmente il tempo o la frequenza di modulazione. Premendo a tempo il pulsante per almeno quattro volte viene impostato il valore desiderato e il Led della manopola [RATE] (vedi punto 10) lampeggia alla frequenza calcolata. Per maggiori informazioni sui parametri regolati da questo controllo consultare il punto 6 di questa sezione o la *Sezione Effects* (pag. 32).

#### 10 Manopola [RATE].

Regola la velocità di modulazione dell'effetto selezionato. Per questo controllo è presente un indicatore a Led che lampeggia con frequenza pari alla velocità impostata. Per maggiori informazioni sui parametri regolati da questo controllo consultare il punto 6 di questa sezione o la *Sezione Effects* (pag. 32).

##### NOTA

- Il Led della manopola [RATE] rimane inattivo quando l'effetto è spento e per alcune categorie di effetti.
- Con l'effetto Rotary il Led lampeggia a velocità lenta o veloce rispettivamente in base alla posizione Slow – Fast dell'effetto, mentre non lampeggia in posizione Brake.

#### 11 Pulsante [FX ON].

Utilizzare questo pulsante per accendere o spegnere l'effetto selezionato.

##### NOTA

Tenere premuto il pulsante [FX ON] e premere il pulsante [ON/OFF] di un modulo per assegnare l'uscita del modulo all'effetto selezionato. L'assegnazione del modulo agli effetti viene indicata dai Led [FX 1] e [FX 2] di ciascun modulo.

#### 12 Led di configurazione degli effetti FX1 e FX2 (pagina 32, parametro Effects Config).

- [PAR]: gli effetti FX1 e FX2 sono collegati in parallelo.
- [SER]: gli effetti FX1 e FX2 sono collegati in serie (l'uscita di FX1 entra in ingresso a FX2).

## Controlli della sezione PROGRAM

La sezione PROGRAM permette il richiamo e la memorizzazione dei programmi, l'accesso alla modalità Song e alla funzione di split di tastiera. In questa sezione si trovano inoltre i menù per la modifica di tutti i parametri dello strumento e di configurazione di sistema.

#### 13 Pulsanti [SET].

Pulsanti per la selezione immediata di quattro Program a propria scelta (pag. 26) o delle quattro parti della Song (pag. 49).

#### 14 Pulsante [SONG MODE] / [SYSTEM].

Con la pressione singola di questo pulsante viene richiamata la modalità Song. Per maggiori informazioni si rimanda alla sezione *Modalità Song* (pagina 49).

Tenendo premuto per qualche istante questo pulsante il display visualizza il menu *SYSTEM* contenente tutte le impostazioni generali dello strumento. Per maggiori informazioni si rimanda alla sezione *Menu System* (pagina 54).

#### 15 Pulsante [EDIT] / [STORE].

Con una pressione singola di questo pulsante viene richiamato il menu *EDIT* del modo operativo (Song o Program) corrente. In questo menu è possibile modificare tutti i parametri di configurazione di un Program o una Song.

Tenendo premuto per qualche istante questo pulsante si accede alla funzione di memorizzazione dei Program o Song.

#### 16 Pulsanti [<] o [>].

Pulsanti per selezionare il banco dei Program nella videata principale o per muovere il cursore rispettivamente in alto o a sinistra ed in basso o a destra e rispetto alla posizione corrente.

#### 17 Pulsante [SPLIT].

Pulsante per abilitare la funzione split di tastiera che permette di dividere la tastiera in due parti per suonare timbri diversi con la mano sinistra e la mano destra (pagina 29, parametro *Split Mode*). Il punto in cui viene divisa la tastiera viene definito Split Point e può essere impostato liberamente (vedi parametro *Split Point* a pagina 29).

##### NOTA

- Tenere premuto il pulsante [SPLIT] e premere il pulsante [ON/OFF] di un modulo per assegnare il modulo alla parte Lower o Upper (selezione ciclica ad ogni pressione).
- Tenere premuto il pulsante [SPLIT] e premere un tasto della tastiera per impostare lo Split Point.

**18 Pulsante [EXIT].**

Premere questo pulsante per abbandonare la videata corrente o annullare eventuali richieste inoltrate dal sistema.

**19 Display.**

Display OLED monocromatico da 128x64 pixel per la visualizzazione di tutte le impostazioni dello strumento.

**20 Dial data entry e pulsante di accesso o conferma.**

Utilizzare questo dial per selezionare il Program o Song desiderato, muovere il cursore nei menu, regolare i valori dei parametri, selezionare il carattere nella composizione dei nomi dei Program o Song.


Premere invece il dial per accedere alle videate o confermare eventuali richieste inoltrate dal sistema.

## Controlli comuni a tutti i moduli

Tutti i moduli disponibili presentano un'area comune, posizionata sempre nella parte sinistra del modulo, nella quale si trovano il pulsante di accensione/spegnimento, la manopola del volume ed i Led di stato.

**1 Pulsante [ON/OFF].**

Pulsante di accensione/spegnimento del suono generato del modulo (o di una parte del modulo, nel caso in cui siano presenti più parti). Quando il Led del pulsante è acceso il modulo è abilitato e in grado di ricevere le note della tastiera.

**2 Manopola [VOLUME].**

Permette la regolazione del volume del suono generato dal modulo (o di una parte del modulo, nel caso in cui siano presenti più parti).

**3 Led di stato.**


Questi Led permettono di monitorare lo stato di alcuni parametri principali del timbro generato dal modulo. Il Led acceso sta ad indicare che:

- **[■■■]**: è abilitata la funzione di split (pagina 29, parametro *Split Mode*) ed il suono è assegnato alla parte Lower della tastiera. E' possibile abilitare lo funzione split ed assegnare il suono alla sezione Lower tenendo premuto il pulsante **[SPLIT]** e premendo il pulsante **[ON/OFF]** del modulo. Un volta effettuata l'assegnazione, ripremendo **[SPLIT]** e **[ON/OFF]** del modulo, il suono viene assegnato alla parte Upper.
- **[■■]**: al suono è stata impostata una trasposizione di nota (pagina 42, parametro *Note Shift*).
- **[FX1]**: l'uscita del segnale generato dal modulo è assegnata all'effetto FX1 (pagina 42, parametro *Output Routing*). E' possibile effettuare l'assegnazione selezionando l'effetto FX1 (se non è già selezionato premere il pulsante **[FX 1]** della sezione **EFFECTS**) quindi, tenendo premuto il pulsante **[FX ON]**, premere il pulsante **[ON/OFF]** del modulo. Un volta effettuata l'assegnazione, ripremendo **[FX ON]** e **[ON/OFF]** del modulo, l'assegnazione viene annullata.
- **[FX2]**: l'uscita del segnale generato dal modulo è assegnata all'effetto FX2 (pagina 42, parametro *Output Routing*). E' possibile effettuare l'assegnazione selezionando l'effetto FX2 (se non è già selezionato premere il pulsante **[FX 2]** della sezione **EFFECTS**) quindi, tenendo premuto il pulsante **[FX ON]**, premere il pulsante **[ON/OFF]** del modulo. Un volta effettuata l'assegnazione, ripremendo **[FX ON]** e **[ON/OFF]** del modulo, l'assegnazione viene annullata.

## Modulo E.PIANO

Il modulo E.Piano mette a disposizione la modellazione dei suoni di piano elettrico di Rhodes, Wurlitzer e di CP80. Questo modulo rappresenta la più alta espressione della tecnologia a modelli fisici **Viscount PM (Physical Modeling)** che, attraverso complessi algoritmi matematici, è in grado di riprodurre con assoluta fedeltà i fenomeni dinamici e fisico-acustici del piano elettrico, restituendo il suono autentico dello strumento originale in tutte le sue sfumature.

Il modulo è anche dotato di effetti dedicati di Tremolo,



che simula il classico effetto modulante, e di Amplificatore che simula l'amplificazione e diffusione del suono con diversi modelli di amplificatore.

In aggiunta ai controlli a pannello, sono disponibili numerosi parametri di configurazione e personalizzazione del modulo, accessibili dal menu *EDIT PROGRAM* (vedi Sezione *E.Piano* a pag. 42) e dall'applicazione *Legend '70s Editor*.

**NOTA**

*I controlli ai punti 1, 2 e 3 sono descritti nella sezione Controlli comuni a tutti i moduli a pag. 11.*

**4 Selettori dei suoni.**

Utilizzare questo controllo per selezionare il suono di piano elettrico desiderato.

Posizione	Descrizione
Rhod 1, Rhod 2, Rhod 3, Rhod 4, Rhod 5	Simulazione dei piani elettrici Rhodes.
Wurli 1, Wurli 2	Simulazione dei piani elettrici Wurlitzer.
E.Grand	Simulazione del piano elettrico a coda CP-80.

**NOTA**

*Tenere premuta per qualche istante la manopola per accedere ai parametri di configurazione del modulo.*

**5 Manopola [BASS].**

Regola il guadagno (valori positivi) o l'attenuazione (valori negativi) delle basse frequenze del suono generato dal modulo E.PIANO.

**6 Manopola [TREBLE].**

Regola il guadagno (valori positivi) o l'attenuazione (valori negativi) delle alte frequenze del suono generato dal modulo E.PIANO.

**7 Manopola [INTESITY].**

Regola la profondità di modulazione dell'effetto Tremolo applicato al suono generato dal modulo E.PIANO.

**8 Manopola [SPEED].**

Regola la velocità di modulazione dell'effetto Tremolo applicato al suono generato dal modulo E.PIANO. Per questo controllo è inoltre presente un indicatore a Led che lampeggia con frequenza pari a quella impostata con la manopola.

**NOTA**

*Il Led della manopola [SPEED] non è attivo quando l'effetto Tremolo è spento.*

**9 Pulsante [TREM ON].**

Pulsante di accensione/spegnimento dell'effetto Tremolo.

**NOTA**

*Tenere premuto per qualche istante il pulsante [TREM ON] per attivare l'effetto Tremolo e visualizzare a display il parametro di selezione della forma d'onda del segnale modulante.*

**10 Pulsante [AMP ON].**

Pulsante di accensione/spegnimento dell'effetto Amplificatore.


**NOTA**

*Tenere premuto per qualche istante il pulsante [AMP ON] per accedere ai parametri di regolazione dell'effetto Amplificatore.*

## Modulo A.PIANO

Il modulo A.PIANO offre una collezione di suoni di pianoforte acustico, che comprendono pianoforti a coda, pianoforti a mezza coda e pianoforti verticali. Questo modulo utilizza la tecnologia **Viscount HDS (High Definition Sampling)**, che si avvale delle più evolute tecniche di multi-campionamento, garantendo la massima fedeltà ed autenticità espressiva del suono originale.

Nel modulo sono presenti anche i controlli di range dinamico e di brillantezza, che permettono al musicista di aggiustare il suono in tempo reale durante l'esecuzione. In aggiunta ai controlli a pannello, sono disponibili numerosi parametri di configurazione e personalizzazione del modulo, accessibili dal menu *EDIT PROGRAM* (vedi Sezione A.Piano a pag. 44) e dall'applicazione *Legend '70s Editor*.


**NOTA**

I controlli ai punti 1, 2 e 3 sono descritti nella sezione Controlli comuni a tutti i moduli a pag. 11.

**4 Selettore dei suoni.**

Utilizzare questo controllo per selezionare il suono di pianoforte acustico desiderato.

**NOTA**

Tenere premuta per qualche istante la manopola per visualizzare a display i parametri di configurazione del modulo.

**5 Manopola [DYNAMIC].**

Regola il range dinamico del pianoforte acustico in modo da ridurre (valori negativi) o aumentare (valori positivi) la differenza di livello tra il pianissimo ed il fortissimo.

**6 Manopola [BRILLIANCE].**


Regola la brillantezza del suono. Impostando la manopola in posizione centrale si ottiene un suono perfettamente bilanciato. Ruotando la manopola in senso antiorario (valori negativi) si ottiene un'attenuazione degli alti, di conseguenza il suono risulta meno brillante. Ruotare invece la manopola in senso orario (valori positivi) per enfatizzare gli alti così da rendere il suono sempre più brillante.

## Modulo CLAVI

Il modulo CLAVI è dedicato ai suoni di uno dei più famosi pianoforti elettrici degli anni '70: il piano Clavinet. Questo modulo utilizza la tecnologia a modelli fisici **Viscount PM (Physical Modeling)** per riprodurre nei minimi dettagli l'inconfondibile suono brillante e incisivo di questo strumento, icona assoluta della musica funky.

Il modulo permette di scegliere tra i due modelli più famosi di questo strumento, sono altresì presenti i tipici controlli per l'equalizzazione e la configurazione dei pickup.

In aggiunta ai controlli a pannello, sono disponibili numerosi parametri di configurazione e personalizzazione del modulo, accessibili dal menu *EDIT PROGRAM* (vedi Sezione Clavi a pag. 45) e dall'applicazione *Legend '70s Editor*.


**NOTA**

I controlli ai punti 1, 2 e 3 sono descritti nella sezione Controlli comuni a tutti i moduli a pag. 11.

#### 4 Pulsanti di attivazione dei filtri di equalizzazione.

Pulsante	Descrizione
[BRILLIANT]	Filtro passa-alto che rende il suono molto brillante.
[TREBLE]	Filtro passa-banda molto ricco sulle alte frequenze.
[MEDIUM]	Filtro passa-basso con frequenza di taglio sulle medie frequenze.
[SOFT]	Filtro passa-basso che rende il suono più chiuso ed ovattato.

#### 5 Pulsanti di selezione dei pickup.

A Led acceso corrispondono le posizioni D e B. Come nello strumento originale, il pulsante [A B] seleziona il pickup, mentre [C D] ne seleziona la messa in fase tra i due. Di seguito una descrizione delle quattro combinazioni possibili:

Combinazione	Descrizione
C A	Solo pickup basso, per un suono pieno.
C B	Solo pickup alto, per un suono sottile e percussivo.
D B	Entrambi i pickup, per un suono molto ricco.
D A	Entrambi i pickup ma in controfase, per un suono sottile e nasale

#### 6 Pulsanti di selezione dei modelli.

Permettono la selezione dei due modelli Clavinet.

Pulsante	Descrizione
[Clavi 1]	Simulazione del Clavinet D6.
[Clavi 2]	Simulazione del Clavinet E7.

##### NOTA

Tenere premuto per qualche istante uno dei due pulsanti per accedere ai parametri di configurazione del modulo.

#### 7 Pulsante [MUTE].

Selezione la posizione massima del feltro smorzatore (Sliding Damper) che permette, a Led acceso, di diminuire il tempo di decadimento del suono.


##### NOTA

Tenere premuto per qualche istante il pulsante per attivare il Mute e visualizzare a display il parametro di regolazione del tempo di decadimento.

## Modulo SOUND COLLECTION

Il modulo SOUND COLLECTION fornisce una vasta gamma di suoni di generi diversi, che rappresentano gli strumenti più utilizzati nella scena musicale, indispensabili per qualunque musicista. Grazie alla tecnologia **Viscount HDS (High Definition Sampling)**, ciascuno degli strumenti è stato accuratamente campionato per i diversi livelli dinamici, in modo da riprodurre le variazioni dinamico-timbriche caratteristiche dello strumento originale, ottenendo in questo modo suoni ricchi di dettagli e di straordinario realismo. Questi suoni sono raccolti in 8 tipologie: Pad, Strings, Choir, Brass, Keys, Organ, Bass e Others.

Il modulo mette a disposizione due parti indipendenti, che possono essere richiamate tramite due appositi pulsanti di selezione. In aggiunta ai controlli a pannello, sono disponibili numerosi parametri di configurazione e personalizzazione del modulo, accessibili dal menu **EDIT PROGRAM** (vedi Sezione Sound Collection a pag. 46) e dall'applicazione *Legend '70s Editor*.



##### NOTA

I controlli ai punti 1, 2 e 3 sono descritti nella sezione Controlli comuni a tutti i moduli a pag. 11.

#### 4 Selettori della tipologia di suono.

Utilizzare questo controllo per selezionare la tipologia del suono richiamabile con la manopola descritta al punto 6.

Posizione	Descrizione
Pad	Pad sintetizzati.
Strings	Strumenti ad arco, acustici o sintetizzati.
Choir	Cori.
Brass	Ottoni, acustici o sintetizzati.
Keys	Pianoforti acustici ed elettronici, sintetizzatori, fisarmoniche.
Organ	Organi elettromeccanici, elettrici e a canne.
Bass	Bassi acustici, elettrici e sintetizzati.
Others	Strumenti di diverse tipologie.

**NOTA**

Tenere premuta per qualche istante la manopola per accedere ai parametri di configurazione del modulo.

#### 5 Pulsanti di selezione delle parti.

Come descritto nelle note introduttive, questo modulo dispone di due parti indipendenti. Per selezionare la parte, così da controllarne i parametri principali tramite i controlli a pannello, utilizzare i pulsanti [1] e [2]. Alla selezione di una delle due parti i Led dei controlli ed i parametri regolabili vengono aggiornati in base alle impostazioni della parte selezionata.

**NOTA**

Il Led lampeggiante del pulsante [1] o [2] indica che la parte non selezionata è comunque accesa.

#### 6 Selettori dei suoni.

Utilizzare questo controllo per richiamare il suono della tipologia selezionata con la manopola descritta al punto 4. Il numero del suono selezionato viene visualizzato dal display indicato al punto 7, mentre il nome viene indicato dal display del pannello principale.

#### 7 Display di visualizzazione del suono selezionato.

Visualizza il numero del suono selezionato con la manopola indicata al punto 6.


#### 8 Manopole per la regolazione dei parametri di generazione.

Tramite queste tre manopole è possibile regolare altrettanti parametri di generazione sonora. Il tipo di parametro regolato da ogni manopola è in funzione del suono selezionato. Per maggiori informazioni sui parametri che è possibile regolare, consultare la pagina 46.

## Modulo EXTERNAL

Il modulo EXTERNAL permette il controllo in tempo reale di dispositivi MIDI esterni collegati allo strumento tramite i connettori MIDI o USB [TO HOST] e può essere attivato/disattivato e assegnato alle zone della tastiera proprio come gli altri moduli di generazione. Con questo modulo è possibile accedere facilmente alle funzioni avanzate di master keyboard di cui è dotato lo strumento.

Il modulo fornisce due parti indipendenti, che possono essere richiamate tramite due pulsanti a pannello. Queste parti possono essere attive contemporaneamente e possono essere combinate in layer o split. In aggiunta ai controlli a pannello, sono disponibili numerosi parametri di configurazione del modulo, accessibili dal menu *EDIT PROGRAM* (vedi Sezione External a pag. 47) e dall'applicazione *Legend*



### '70s Editor.

Indipendentemente dalla presenza o meno del modulo, tutte le funzionalità di master keyboard dello strumento sono comunque disponibili, in quanto la sezione External è sempre presente nello strumento. In assenza del modulo la configurazione per il controllo dei dispositivi esterni è possibile solamente dal menù **EDIT PROGRAM**.

#### **NOTE**

I controlli ai punti 1, 2 e 3 sono descritti a pag. 11. Per quanto concerne i Led al punto 3, in questo modulo non sono presenti gli [FX 1] e [FX 2] non essendo questo un modulo adibito alla generazione sonora interna.

#### **4 Manopola per la selezione del parametro MIDI.**

Utilizzare questa manopola per selezionare il parametro MIDI da trasmettere o impostare regolando il valore con la manopola descritta al punto 6.

Parametro	Descrizione
Port	Porta di trasmissione dei messaggi MIDI
Channel	Canale di trasmissione dei messaggi MIDI
Bank LSB	Trasmissione del messaggio di Bank Select LSB
Bank MSB	Trasmissione del messaggio di Bank Select MSB
Prg Change	Trasmissione del messaggio di Program Change
Ctrl 1 CC	Control Change 1 assegnato alla manopola [CTRL 1]
Ctrl 2 CC	Control Change 2 assegnato alla manopola [CTRL 2]
Ctrl 3 CC	Control Change 3 assegnato alla manopola [CTRL 3]

#### **NOTA**

Tenere premuta per qualche istante la manopola per accedere ai parametri di configurazione del modulo.

#### **5 Pulsanti di selezione della parte.**

Permettono la selezione di una delle due parti del modulo. Alla selezione di una delle due parti i controlli di questo modulo vengono aggiornati in base alle impostazioni della parte selezionata. Il Led lampeggiante del pulsante [1] o [2] indica che la parte non selezionata è comunque accesa.

#### **6 Display di visualizzazione del valore selezionato.**

Visualizza il valore del parametro MIDI regolato con la manopola indicata al punto 7.


#### **7 Manopola per la regolazione del valore.**

Manopola per la regolazione del parametro MIDI selezionato con la manopola descritta al punto 4.

#### **8 Manopole per la trasmissione dei messaggi di Control Change.**

Agendo su queste manopole è possibile trasmettere il Control Change assegnato tramite il controllo descritto al punto 4.

## PANNELLO POSTERIORE



### 1 Mini jack [AUDIO IN].

Ingresso audio mini jack stereo standard da 1/8" per il collegamento di dispositivi esterni come smartphone, tablet o computer. Il segnale presente in questo ingresso viene ridistribuito inviato all'uscita cuffie e alle uscite AUDIO OUT MAIN [L/MONO] ed [R] e non viene regolato dalla manopola [MASTER VOLUME] del pannello frontale. Tramite questa manopola pertanto, è possibile effettuare un missaggio tra suono del *Legend '70s* e suono dei dispositivi esterni.

### 2 Jack AUDIO OUT [AUX 1] e [AUX 2].


Uscite audio ausiliari jack mono standard da 1/4" per la diffusione dei segnali trasmessi dal *Legend '70s*. E' possibile indirizzare l'uscita dei moduli o degli effetti alle uscite audio ausiliari, in alternativa alle uscite main, in configurazione stereo o mono (vedi parametro *Output Routing* a pagina 33 e 42).

### 3 Jack AUDIO OUT [MAIN L/MONO] e [MAIN R].

Uscite audio jack mono standard da 1/4" per la diffusione dei segnali trasmessi dal *Legend '70s*. Le uscite dei moduli e degli effetti vengono inviate di default alle uscite main, ma possono essere indirizzate, in alternativa, alle uscite ausiliari (vedi parametro *Output Routing* a pagina 33 e 42). In caso di utilizzo di un impianto di diffusione monofonico, collegare solo il jack [MAIN L/MONO].

#### NOTE SULLE USCITE AUDIO

- Il segnale presente sulle uscite AUDIO OUT AUX non è trattato dall'equalizzatore generale (vedi punto 2 a pagina 8) e dall'effetto Reverb (vedi punto 3 a pagina 8).
- Effettuare i collegamenti con i diffusori e lo strumento spenti. Dopodiché accendere prima lo strumento e successivamente i diffusori.
- Per il collegamento delle uscite audio si raccomanda l'utilizzo di cavi bilanciati.



### 4 Jack PEDAL [PROGRAM + / -].

Collegare a questo connettore un foot switch a due pulsanti con jack stereo per selezionare il Program successivo e precedente. Il pedale a due pulsanti permette la selezione del Program successivo e precedente (anche all'interno delle Song). E' comunque possibile collegare un foot switch a singolo pulsante con jack mono, in questo caso sarà possibile selezionare solo il Program successivo o precedente in base alla modalità selezionata (vedi parametro *Program +/- Type* a pagina 58).

### 5 Jack PEDAL [SUSTAIN].

Collegare a questo connettore un foot switch con jack mono per controllare l'effetto di Sustain od un pedale Half-Damper per suonare con la tecnica di mezzo pedale od il triplo pedale Studiologic SLP3-D per disporre dei classici tre pedali del pianoforte acustico. Per assicurare la corretta funzionalità del pedale collegato è necessario selezionare il tipo di pedale utilizzato (vedi parametro *Sustain Type* a pagina 57).

**6 Jack PEDAL [FOOT SWITCH 1] e [FOOT SWITCH 2].**

Collegare a questi connettori foot switch con jack mono per controllare una funzione assegnabile (vedi parametri *FS1 Dest* e *FS2 Dest* a pagina 29).

**7 Jack PEDAL [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2].**

Collegare a questi connettori foot controller per controllare in modo una funzione assegnabile (vedi parametri *FC1 Dest* e *FC2 Dest* a pagina 29).

**NOTE SUI PEDALI**

- Per i pedali foot switch è necessario impostare la polarità del pedale utilizzato (vedi parametri *Sustain Polarity*, *FS1 Polarity*, *FS2 Polarity* e *Progr +/- Polarity* a pagina 57).
- Per i pedali foot controller è necessario impostare il tipo del pedale utilizzato (vedi parametri *FC1 Type* e *FC2 Type* a pagina 57).
- Per maggiori informazioni sul collegamento ed utilizzo dei pedali consultare la sezione Collegamento dei pedali a pagina 22.

**8 Connettore MIDI [OUT].**

Connettore utilizzato per la trasmissione dei dati MIDI generati dal *Legend '70s*. Collegare questo connettore all'ingresso MIDI del dispositivo ricevente.

**9 Connettore MIDI [IN].**

Connettore di ingresso per la ricezione dei dati trasmessi da un'unità MIDI esterna tramite la quale suonare e controllare il *Legend '70s*. Collegare questa presa all'uscita MIDI del dispositivo trasmittente (per es. tastiera, master controller, sequencer).

**NOTA**

Per maggiori informazioni sull'interfaccia MIDI del *Legend '70s* consultare la sezione *MIDI Informations* a pagina *MIDI - 1*.

**10 Connettore USB [TO HOST].**

Questo connettore permette di collegare lo strumento ad un tablet o ad un computer utilizzando un cavo USB. Tramite questa connessione è possibile ricevere e trasmettere dati USB MIDI, comunicare con l'applicazione *Legend '70s Editor* e ricevere un segnale USB Audio stereo che può essere ascoltato dalle uscite audio *AUDIO OUT MAIN [L/MONO]* ed *[R]*.

**NOTA**

- Utilizzare cavi USB di tipo A/B.
- Lo strumento è in grado di ricevere un segnale audio tramite cavo USB su 2 canali (1 canale stereo) con una frequenza di campionamento di 44.1 kHz.
- Computer dotati di sistema operativo Microsoft Windows necessitano di un driver USB. Questo driver viene installato automaticamente alla prima connessione con il computer. Seguire le istruzioni riportate sul computer per completare l'installazione.

**11 Connettore USB [TO DEVICE].**

Utilizzare questo connettore per collegare un'unità flash USB allo strumento. In questo modo è possibile salvare le proprie programmazioni e ricaricarle all'occorrenza, ed effettuare l'aggiornamento del sistema operativo.

**NOTA**

- Utilizzare unità flash USB formattate con file system FAT o FAT32 (no NTFS o altri).
- Tramite questo connettore è possibile ricaricare dispositivi multimediali come tablet e smartphone. La funzione di ricarica è attivabile a display tramite il parametro *USB to Device* descritto a pagina 58.

**12 Interruttore [POWER].**

Interruttore di accensione / spegnimento dello strumento.

**13 Connnettore [MAINS AC-IN]**

Utilizzare questo connettore per collegare il cavo di alimentazione fornito con lo strumento.

## ACCENSIONE ED OPERAZIONI DI BASE

Per l'accensione dello strumento attenersi a queste semplici regole:

1. Accertarsi che l'interruttore [POWER] posto nel pannello posteriore sia in posizione 0.
2. Accertarsi che eventuali amplificatori o altoparlanti amplificati collegati siano spenti.
3. Collegare il cavo di alimentazione in dotazione con lo strumento.
4. Posizionare la manopola [MASTER VOLUME] completamente a sinistra (volume chiuso).
5. In caso di utilizzo delle cuffie, non indossarle.
6. Accendere lo strumento tramite l'interruttore [POWER].
7. Accendere gli amplificatori o altoparlanti amplificati collegati.
8. Regolare il volume dello strumento con la manopola [MASTER VOLUME].

Per spegnere lo strumento, seguire questa procedura:

1. Posizionare la manopola [MASTER VOLUME] completamente a sinistra (volume chiuso).
2. Spegnere gli amplificatori o altoparlanti amplificati collegati.
3. Spegnere lo strumento tramite l'interruttore [POWER].

### NOTE

- Utilizzare soltanto il cavo CA fornito con il Legend '70s. L'utilizzo di un cavo sostitutivo non adeguato potrebbe provocare surriscaldamento o scosse elettriche.
- Il cavo in dotazione con il Legend '70s non deve essere utilizzato con altre apparecchiature elettriche. Se non si osserva questa precauzione, l'apparecchiatura potrebbe danneggiarsi o potrebbero verificarsi incendi.
- In caso di lunghi periodi di inutilizzo dello strumento, scollegare il cavo di alimentazione dalla presa di corrente.
- E' possibile fare in modo che lo strumento si spenga automaticamente dopo un determinato periodo di inattività. Per avvalersi di questa funzionalità attivare la funzione Auto Power Off descritta a pagina 58.


## Collegamento con dispositivi audio

Legend '70s non è equipaggiato con altoparlanti interni. Per ascoltare il suono riprodotto, quindi, è necessario collegare lo strumento ad altri dispositivi audio, come amplificatori e diffusori o utilizzare un set di cuffie collegate al jack posto sulla sinistra sotto la tastiera. Il collegamento del Legend '70s ai dispositivi di diffusione audio può essere effettuato in vari modi, di seguito vengono riportati due esempi. Basandosi sulle illustrazioni, effettuare il collegamento più adatto alle proprie esigenze.

### Collegamento con amplificatori o diffusori amplificati

Utilizzando una coppia di diffusori amplificati o amplificatori con ingresso audio di linea, è possibile riprodurre il suono del Legend '70s. Per effettuare questo collegamento è necessario utilizzare due cavi audio con connettori jack mono da 1/4" da collegare alle uscite AUDIO OUT MAIN [L/MONO] ed [R] presenti nel pannello posteriore e agli ingressi dell'amplificatore o diffusori amplificati come illustrato in figura. Se si preferisce la riproduzione mediante un unico diffusore amplificato o amplificatore per tastiere, è possibile utilizzare solo il connettore AUDIO OUT MAIN [L/MONO].


Legend '70s è dotato, inoltre, di altre due uscite audio ausiliarie AUDIO OUT AUX [1] e [2], che possono essere utilizzate in combinazione alle MAIN. E' possibile scegliere infatti, per ciascun modulo od effetto, l'uscita audio di destinazione (vedi parametro Output Routing a pagina 33 e 42).



## Collegamento con mixer

Nel caso di una registrazione o di una performance dal vivo può essere necessario collegare gli strumenti musicali ad un mixer, le cui uscite vengono dirette agli amplificatori o a diffusori amplificati. In questo caso, collegare le uscite AUDIO OUT MAIN [L/MONO] ed [R] presenti nel pannello posteriore agli ingressi dei canali del mixer, utilizzando due cavi audio con connettori jack mono da 1/4", come illustrato in figura. Per la ripresa monofonica dello strumento su un unico canale del mixer, è possibile utilizzare il solo connettore AUDIO OUT MAIN [L/MONO].

*Legend '70s* è dotato, inoltre, di due uscite audio ausiliari AUDIO OUT AUX [1] e [2], che possono essere utilizzate in combinazione alle uscite MAIN. È possibile scegliere infatti, per ciascun modulo od effetto, l'uscita audio di destinazione (vedi parametro *Output Routing* a pagina 33 e 42).



## Collegamento con dispositivi MIDI

Utilizzando cavi MIDI standard è possibile collegare il *Legend '70s* ad altri dispositivi MIDI, come sintetizzatori e moduli audio (expander). Utilizzando i connettori MIDI [IN] ed [OUT] del *Legend '70s* ed i terminali MIDI del dispositivo collegato, è possibile scambiare i dati MIDI tra i due strumenti.

**NOTA**


Per scambiare i dati MIDI attraverso i connettori MIDI [IN] ed [OUT] è necessario abilitare la relativa porta MIDI del *Legend '70s* (vedi parametro Control Port a pag. 56).

## Controllo di un generatore sonoro esterno

Collegando il connettore MIDI [OUT] del *Legend '70s* al terminale MIDI IN di un generatore di suoni MIDI esterno (sintetizzatore, expander, ecc.) tramite un cavo MIDI, è possibile riprodurre i suoni del generatore esterno con la tastiera del *Legend '70s*.

Utilizzando la sezione *EXTERNAL* (vedi pag. 15) è inoltre possibile suddividere la tastiera in due zone, con ciascuna delle quali riprodurre un suono diverso. Ciò consente di riprodurre più suoni generati da altri dispositivi MIDI insieme a quelle del *Legend '70s*.

Non utilizzando la sezione *EXTERNAL* i controlli e le note vengono comunque trasmessi sul canale generale (vedi parametro Global Channel a pag. 56) e lungo tutta l'estensione della tastiera.


**NOTA**


Per suonare un generatore di suoni esterni è necessario che il relativo canale di ricezione sia lo stesso di quello impostato in Global Channel (pag. 56) o nella sezione *EXTERNAL* (pag. 47).

## Controllo del Legend '70s tramite una tastiera esterna

Collegando il terminale MIDI OUT di una tastiera MIDI esterna al connettore MIDI [IN] del *Legend '70s* è possibile, tramite la tastiera, suonare, selezionare e modificare i suoni del *Legend '70s*.

### NOTA

*Per suonare i suoni del Legend '70s con un dispositivo MIDI esterno è necessario che il relativo canale di trasmissione sia lo stesso di quello impostato in Global Channel (pag. 56).*



## Utilizzo con un computer


Collegando il *Legend '70s* ad un computer è possibile utilizzare un'applicazione DAW per creare le proprie song, registrare e riprodurre le proprie esecuzioni, riprodurre file audio.

Di seguito sono riportate alcune delle applicazioni offerte dall'utilizzo del *Legend '70s* con un computer:

- Utilizzo del *Legend '70s* come sorgente sonora esterna per riprodurre sequenze MIDI (file .mid) lette con un'applicazione DAW.
- Registrazione e riproduzione delle proprie esecuzioni in formato MIDI con un'applicazione DAW.
- Riproduzione di file audio (file .mp3, .wav, .ogg, ecc...) letti con un'applicazione DAW.

Per collegare il *Legend '70s* ad un computer e scambiare dati seguire questa procedura:

1. Abilitare la porta USB tramite il parametro *Control Port* (vedi pag. 56).
2. Collegare il connettore USB [TO HOST] del *Legend '70s* ad un connettore USB del computer utilizzando un cavo USB.
3. Con computer dotati di sistema operativo Microsoft Windows, installare il corretto driver USB. Questo driver viene installato automaticamente alla prima connessione con il computer. Seguire le istruzioni riportate sul computer per completare l'installazione.



### NOTA


- DAW è l'abbreviazione di Digital Audio Workstation (workstation audio digitale) e le applicazioni DAW possono essere utilizzate per registrare, riprodurre, modificare e mixare audio e dati su un computer.
- Con il *Legend '70s* collegato al computer, le applicazioni DAW rilevano due dispositivi MIDI: *Legend '70s MIDI Port* e *MIDIIN2* (*Legend '70s MIDI Port*). Per l'utilizzo con le applicazioni DAW selezionare il dispositivo *Legend '70s MIDI Port*.

## Utilizzo con un lettore audio portatile

Con un lettore musicale portatile collegato al connettore [AUDIO IN], è possibile ascoltare i brani riprodotti dal lettore con le cuffie o le uscite audio del *Legend '70s* oppure suonarlo con i propri brani preferiti.

### NOTA

*Utilizzare il controllo del volume sul dispositivo collegato per bilanciarne il volume con quello del Legend '70s.*



## Collegamento dei pedali

Con il Legend '70s è possibile utilizzare diverse tipologie di pedali: i foot switch, ovvero pedali a pressione del tipo on-off che permettono di controllare funzione e/o parametri a due stati, pedale Sustain Half-Damper per avvalersi della funzione Half-Damper (mezzo pedale) dei pianoforti acustici, foot controller che hanno un controllo continuo del parametro assegnato, triplo pedale per disporre dei classici tre pedali presenti nei pianoforti acustici. I pedali vanno collegati ai connettori del pannello posteriore, tuttavia i jack utilizzati e le funzioni corrispondenti variano come descritto di seguito.

### Pedale di sustain

Il connettore dedicato PEDAL [SUSTAIN] consente di collegare vari tipi di pedali di sustain. E' possibile collegare un foot switch di tipo on-off per utilizzarlo come il pedale damper di un pianoforte acustico. Quando questo pedale viene premuto, le note della tastiera continuano a suonare con decadimento lungo, anche dopo essere state rilasciate.


A questo connettore è anche possibile collegare un pedale di sustain half-damper, per suonare il pianoforte acustico con la tecnica del "mezzo pedale". In tal caso, l'effetto damper varia in base al grado di pressione del pedale.

E' inoltre possibile utilizzare il gruppo pedali Studiologic SLP3-PD, per disporre dei classici tre pedali presenti nel pianoforte acustico. Il triplo pedale SLP3-D permette il controllo della funzione "Una Corda" o "Soft" tramite il pedale sinistro, del "Sostenuto" con il pedale centrale e del "Damper" o "Sustain" con il pedale destro, con funzione di "mezzo pedale" (half-damper).

E' comunque possibile assegnare le funzioni al pedale sinistro e al pedale centrale, così da utilizzare il triplo pedale anche con suoni diversi dal pianoforte acustico.

#### NOTE

- La pressione del pedale di sustain, nel modulo A.PIANO, è in grado di produrre la vibrazione per "simpatia" delle corde del pianoforte ed i rumori meccanici provocati dal movimento dello smorzatore.
- Nel caso di impiego del triplo pedale, il pedale sinistro e il pedale centrale utilizzano le stesse funzioni assegnate rispettivamente al pedale [FOOT SWITCH 1] e [FOOT SWITCH 2].
- Per il corretto utilizzo del pedale di sustain è necessario selezionare il tipo di pedale collegato (vedi parametro Sustain Type a pagina 57).




### Foot switch

Utilizzare i connettori PEDAL [FOOT SWITCH 1] e [FOOT SWITCH 2] per collegare i pedali di tipo foot switch, ai quali è possibile assegnare varie funzioni, come per esempio l'accensione e spegnimento di un modulo o di un effetto, il controllo del sostenuto o del soft dei pianoforti acustici, ed altri ancora.

Inoltre Legend '70s è dotato di un connettore PEDAL [PROGRAM + / -] per il collegamento di un pedale a due pulsanti, dedicato alla selezione del Program successivo o precedente. E' consentito anche il collegamento del foot switch a singolo pulsante, con la sola funzione di incremento o decremento della locazione del Program.

I pedali foot switch non vengono forniti con lo strumento. In commercio ne esistono di due tipi, N.O. (Normally Open) e N.C. (Normally Closed). E' necessario pertanto impostare la polarità del pedale utilizzato.




## Foot controller

Un foot controller, o pedale d'espressione, permette di controllare un parametro in maniera continuativa e non a due stati come con un foot switch.

Ai pedali collegati ai connettori PEDAL [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2] è possibile assegnare vari parametri, come per esempio il volume di un determinato suono, l'intonazione, la modulazione o l'effetto Wah-Wah ed altri ancora.

I pedali foot controller non vengono forniti con lo strumento. In commercio ne esistono di due tipi, RTS o TRS. E' necessario pertanto impostare la tipologia del pedale collegato al *Legend '70s*.



### NOTE

- Per impostare la polarità ed il tipo di pedali consultare la Sezione Pedal Setup a pagina 57.
- Per assegnare le funzioni ai pedali consultare la Sezione Common a pagina 29.
- Onde evitare comportamenti indesiderati si consiglia di collegare e scollegare i pedali a strumento spento.

## Utilizzo dei suoni

Il *Legend '70s* dispone di una grande varietà di suoni, in funzione anche del numero di moduli installati. Come già descritto ogni singolo modulo dispone di diverse tipologie di suoni, è possibile utilizzare un singolo suono o diversi contemporaneamente, per il massimo di tutti i moduli attivati.

Per utilizzare uno o più suoni procedere come segue:


1. Accendere il modulo del suono desiderato premendo il relativo pulsante [ON/OFF].
2. Ruotare la manopola di selezione per scegliere il suono o la tipologia di suoni nei moduli in cui queste sono previste (per es. SOUND COLLECTION).
3. Nei moduli in cui sono previste tipologie di suoni ruotare la manopola di selezione del suono per scegliere quello desiderato.
4. Agire sui controlli previsti dal modulo per regolare i parametri principali del suono.

Per la descrizione dettagliata dei parametri dei suoni si rimanda alle Sezioni di descrizione del modulo raggiungibili dal menù *EDIT* (da pag. 42) oppure tramite la pressione lunga della manopola di selezione del suono o della tipologia di suoni.

## Utilizzo degli effetti

Il *Legend '70s* dispone di una sezione effetti di elevata qualità, costituita da due processori effetti indipendenti FX1 e FX2, da una unità di riverbero e da una unità di equalizzazione a 3 bande. I parametri principali degli effetti possono essere controllati direttamente dal pannello principale mentre per la configurazione completa di tutti i parametri è necessario accedere alle sezioni dedicate nel menù *EDIT*. È possibile utilizzare i controlli dell'effetto FX1 o FX2 selezionando rispettivamente il pulsante [1] o [2] della sezione *EFFECTS* del pannello.

Il routing completo degli effetti è schematizzato in figura:



## Attivazione e selezione dell'effetto FX1 o FX2

---

Per utilizzare l'effetto FX1 o FX2 procedere come segue:

1. Selezionare l'effetto FX1 premendo il pulsante [1], oppure selezionare l'effetto FX2 premendo il pulsante [2].
2. Attivare l'effetto premendo il pulsante [FX ON].
3. Ruotare la manopola di selezione per scegliere la categoria dell'effetto.
4. Premere la manopola di selezione e ruotare la stessa od il dial data entry per scegliere il preset dell'effetto.
5. Agire sui controlli di [AMOUNT] e [RATE] per regolare i parametri principali dell'effetto.

Per la descrizione dettagliata dei parametri degli effetti si rimanda alla *Sezione Effects* raggiungibile dal menù *EDIT* (pag. 32) oppure tramite la pressione lunga della manopola di selezione della categoria di effetto.

## Assegnazione di un modulo all'effetto FX1 o FX2

---

Per assegnare l'uscita di un modulo all'effetto FX1 o FX2 procedere come segue:

1. Selezionare l'effetto FX1 premendo il pulsante [1], oppure selezionare l'effetto FX2 premendo il pulsante [2].
2. Tenendo premuto pulsante [FX ON] premere il pulsante [ON/OFF] del modulo da assegnare.

Il collegamento interno dello strumento permette di assegnare più moduli contemporaneamente allo stesso effetto FX1 o FX2. E' altresì possibile assegnare l'uscita di un modulo ad entrambi gli effetti FX1 e FX2.

## Attivazione e selezione dell'effetto di riverbero

---

Per utilizzare l'effetto di riverbero procedere come segue:

1. Attivare l'effetto premendo il pulsante [REV ON].
2. Ruotare la manopola di selezione per scegliere la categoria del riverbero.
3. Premere la manopola di selezione e ruotare la stessa od il dial data entry per scegliere il tipo di riverbero della categoria selezionata.
4. Agire sul controllo [DRY/WET] per regolare il livello generale del riverbero.

Nel caso in cui si voglia regolare la quantità di segnale inviato al riverbero separatamente per ciascun modulo, è possibile modificare il parametro *Reverb Send* presente nelle varie sezioni del menù EDIT.

Per la descrizione dettagliata dei parametri del riverbero si rimanda alla *Sezione Reverb* (pag. 41), raggiungibile dal menù *EDIT* oppure tramite la pressione lunga della manopola di selezione del riverbero.

## MODALITA' PROGRAM

La modalità Program è il modo operativo principale di funzionamento dello strumento, nel quale è possibile eseguire, selezionare e memorizzare un Program.

Nella modalità Program il display risulta diviso in 4 aree in cui sono presenti i seguenti campi:

**1 Locazione del Program.**

La lettera indica il banco dei Program, il numero ne indica la locazione.



**2 Nome del Program.**

Il nome del Program è assegnabile in fase di memorizzazione (pag. 27).

**3 Moduli attivi.**

In questa area del display vengono visualizzate le icone che indicano quali moduli sono attivi nel Program corrente.



Tutti i moduli accesi



Modulo acceso



Modulo spento

Modulo salvato acceso ma non installato

**4 Area di notifica.**

L'area di notifica visualizza le informazioni e gli eventi relativi a particolari condizioni di funzionamento, come ad esempio la trasposizione della tastiera o l'abilitazione della sezione EXTERNAL qualora non sia presente in modulo a pannello.

**NOTE**


- La sezione External è sempre presente, indipendentemente dalla presenza o meno del modulo. Con il modulo assente, se una delle due parti della sezione è attiva, nell'area di notifica viene visualizzato il campo EXT.
- La posizione delle icone viene stabilita con la funzione Identify Modules (pag. 59).

## Cosa e' un Program

Un Program contiene le impostazioni di tutte le sezioni di generazione, di controllo e di effetti dello strumento. Queste impostazioni riguardano:

- I parametri di generazione sonora e configurazione di ogni modulo.
- La configurazione della tastiera e delle parti.
- I parametri degli effetti (delle sezioni REVERB ed EFFECTS).
- Lo stato e l'assegnazione delle funzioni dei pedali collegabili alle porte del pannello posteriore.
- Lo stato e l'assegnazione delle funzioni delle ruote di pitch bend e modulazione.

Il Legend '70s contiene 256 Program, divisi in 16 banchi da 16 Program ciascuno. Ogni Program viene identificato dal banco, espresso in lettere dalla A alla P e dal numero di locazione, da 1 a 16. E' inoltre possibile assegnare un nome al Program.



NOTA: l'illustrazione si riferisce allo strumento con tutti i moduli installati.

## Selezione di un Program

La selezione dei Program può essere effettuata nella sezione PROGRAM del pannello principale, nel caso in cui lo strumento si trovi in Modalità Program, utilizzando il dial data entry sotto il display, i pulsanti di banco [<] [>] o i pulsanti [SET]. E' altresì possibile selezionare i Program con il foot switch collegato alla presa PEDAL [PROGRAM + / -] del pannello posteriore. In questo caso non è necessario che il display visualizzi la videata principale.

Per selezionare i Program utilizzare il dial data entry, ruotando in senso orario per selezionare la locazione successiva e in senso antiorario per selezionare la precedente. Quando è selezionata l'ultima locazione di un banco (es. A16), ruotando in senso orario viene selezionata la prima locazione del banco successivo (nell'esempio, B01). Allo stesso modo, quando si è nella prima locazione di un banco (es. B01), ruotando il dial in senso antiorario si seleziona l'ultima locazione del banco precedente (nell'esempio, A16).

### SEQUENZA DI SELEZIONE DEI PROGRAM

...O16 ← O01... ← P15 ← P16 ← **A01** → A02 → A03 →...A16 → B01...

Per cambiare direttamente banco utilizzare i pulsanti [<] (da P ad A) o [>] (da A a P). Quando è selezionato l'ultimo banco (P), premendo il pulsante [>] si seleziona il primo (A). Allo stesso modo, quando è selezionato il primo banco (A), premendo [<] si seleziona l'ultimo (P).

### SEQUENZA DI SELEZIONE DEI BANCHI DEI PROGRAM

...A01 ← B01... ← P01 ← **A01** → B01 →...P01 → A01...

In base all'impostazione di sistema *Confirm Program* (pag. 58) il nuovo Program può essere caricato immediatamente oppure in seguito a conferma da parte dell'utente, tramite la pressione del dial data entry. In questo caso la locazione del Program lampeggia sino alla pressione del dial. Premendo [EXIT] la nuova selezione viene annullata e si ritorna al Program corrente.

Il *Legend '70s* prevede, inoltre, la possibilità di selezionare direttamente quattro Program a propria scelta, utilizzando i pulsanti [SET]. Questi pulsanti permettono di richiamare velocemente un Program senza la necessità di scorrere tutte le locazioni con il dial data entry (per esempio se si desidera selezionare immediatamente il Program D-12 dopo il B-01) assegnandolo ad un pulsante [SET]).

Per assegnare un Program ad un pulsante [SET] selezionare il Program desiderato, dopodichè tenere premuto per qualche istante il pulsante [SET] con il quale si desidera richiamarlo. Ad assegnazione avvenuta il display visualizza la videata:

Durante l'esecuzione di un Program è possibile modificare in tempo reale i parametri più importanti andando ad agire sui controlli del pannello principale e dei moduli aggiuntivi. Ogni qualvolta si regola uno dei controlli a pannello viene visualizzato a display il nome del parametro corrispondente e il suo valore. Per esempio, regolando il [DRY/WET] dell'effetto Reverb, il display visualizza la videata:

**PROGRAM  
STORED IN  
SET 1**

**REVERB**  

---

**Dry/Wet:**  
**7.0**

I pulsanti per la navigazione e le operazioni a display sono descritti a pagina 10.

## Memorizzazione di un Program

Per rendere definitive le modifiche apportate ad un Program, così da non perderle selezionandone un altro o spegnendo lo strumento, è necessario memorizzare il Program. La procedura di memorizzazione prevede l'assegnazione del nome del Program ed il salvataggio nella locazione desiderata, così da non sovrascrivere quella corrente. Per memorizzare un Program, seguire questa procedura:



1. Predisporre lo strumento in modalità Program.
  2. Tenere premuto per qualche istante il pulsante [EDIT]/[STORE] per richiamare la funzione di STORE. Il led del pulsante inizia a lampeggiare e viene visualizzata la videa:
- STORE AS**

**E**Piano+Strings

**Z**A**C**D **E**F**G**H**I**J**K**
3. Premere il dial data entry od il pulsante [EDIT]/[STORE] per confermare il nome del Program, altrimenti comporre il nuovo nome. Utilizzare i pulsanti [<] o [>] per muovere il cursore (indicato dal carattere evidenziato) e ruotare il dial data entry per selezionare il carattere desiderato. La parte inferiore del display mostra tutti i caratteri disponibili per la composizione del nome del Program.
  - Tenendo premuto il pulsante [EXIT] e premendo [>] è possibile inserire un carattere prima di quello selezionato.
  - Tenendo premuto [EXIT] e premendo [<], invece, viene cancellato il carattere selezionato.
  - Una volta composto il nome del Program premere il dial data entry od il pulsante [EDIT]/[STORE] per continuare, oppure [EXIT] per annullare.
  4. Premere il dial data entry od il pulsante [EDIT]/[STORE] per sovrascrivere la locazione del Program corrente, altrimenti selezionare la nuova locazione utilizzando il dial data entry. Utilizzare i pulsanti [<] o [>] per cambiare banco. Durante la selezione della locazione il display mostra il nome del Program di destinazione.
  - Per confermare la memorizzazione premere il dial data entry od il pulsante [EDIT]/[STORE], oppure [EXIT] per annullare.

### NOTA

- Tutti i 256 Program del Legend '70s sono modificabili dall'utente e memorizzabili in una delle 256 locazioni presenti in memoria.
- Sovrascrivendo un Program, sia esso della locazione corrente o di un'altra locazione, i settaggi in esso contenuti vengono persi. Per evitare ciò è possibile salvare su un'unità flash USB tutte le impostazioni correnti da ricaricare quando necessario, evitando così la perdita dei dati. Per maggiori informazioni consultare la funzione Backup All a pagina 60. E' inoltre possibile ripristinare in qualsiasi momento tutte le impostazioni di fabbrica dello strumento. Per maggiori informazioni consultare la funzione Factory Reset a pagina 61.



## MODIFICA DI UN PROGRAM

Premendo il pulsante [EDIT] in modalità Program è possibile accedere a tutti i parametri di regolazione del Program corrente.

Il menù principale di *EDIT PROGRAM* raccoglie le sezioni principali di un Program ed è composto dai seguenti campi:



**1 Nome del menu.**

Indica la sezione corrente del menu *EDIT PROGRAM* in cui ci si trova.

**2 Numero della pagina.**

Indica la pagina corrente visualizzata e il numero totale delle pagine del menu (ad esempio "1/3" indica che ci si trova nella prima pagina delle tre previste).

**3 Lista delle sezioni del Program.**

Utilizzare i pulsanti [<] o [>] od il dial data entry per muovere il cursore sulla sezione del Program desiderata e premere il dial data per accedere ai parametri di modifica. Le sezioni disponibili sono:

Sezione	Descrizione
COMMON	Parametri generali del Program che determinano il funzionamento di tutte le sezioni.
KEY RANGE	Regolazione delle zone di tastiera assegnate a ciascuno modulo o delle parti Upper e Lower, in funzione dello stato della modalità Split.
EFFECTS	Parametri di configurazione della sezione REVERB del pannello principale.
REVERB	Parametri di configurazione della sezione EFFECTS del pannello principale.
E.PIANO	Parametri di configurazione del modulo E.PIANO.
A.PIANO	Parametri di configurazione del modulo A.PIANO.
CLAVI	Parametri di configurazione del modulo CLAVI.
SOUND COLLECTION	Parametri di configurazione del modulo SOUND COLLECTION.
EXTERNAL	Parametri di configurazione del modulo EXTERNAL.

**NOTE**

- Le sezioni E.PIANO, A.PIANO, CLAVI e SOUND COLLECTION vengono visualizzate solo se il relativo modulo è presente nello strumento. L'ordine delle sezioni nel menu *EDIT PROGRAM*, inoltre, segue la disposizione stabilita con la funzione Identify Modules (pag. 59).
- La sezione EXTERNAL è sempre presente nel Program, indipendentemente dalla presenza o meno del modulo.

Premere [EXIT] o [EDIT]/[STORE] per tornare alla videata principale della Modalità Program.

Premendo il dial data entry sulla sezione desiderata si accede ai parametri di modifica della sezione. Il display mostra i seguenti campi:



**1 Nome del sottomenu.**

Indica in quale sezione del menu *EDIT PROGRAM* ci si trova.

**2 Numero della pagina.**

Informa quale pagina si sta visualizzando tra quelle previste dal menu. (ad esempio "1/9" indica che ci si trova nella prima pagina delle nove previste).

**3 Nome del parametro.**

Indica il nome del parametro che si sta modificando.

**4 Valore del parametro.**

Indica il valore assegnato al parametro.

Ruotare il dial data entry per modificare il valore del parametro corrente ed utilizzare i pulsanti [<] o [>] per scorrere i parametri della sezione.

Per abbandonare il sottomenu e tornare al menu *EDIT PROGRAM*, premere il pulsante [EXIT]. Premere il pulsante [EDIT]/[STORE] per tornare direttamente alla videata principale del Program.

## Sezione COMMON

Il menù **COMMON** contiene i parametri generali del Program che determinano il funzionamento di tutte le sezioni da esse composto.

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo **COMMON** e premere il dial data entry.

Nome parametro	Descrizione
<b>Split Mode</b>	<p>Modalità di funzionamento della tastiera.  Con <i>Split Mode</i> = OFF ciascuno suono può essere assegnato liberamente a tutta o parte della tastiera. L'assegnazione viene effettuata tramite la funzione <i>KEY RANGE</i> (pag. 30).  Con <i>Split Mode</i> = ON la tastiera viene divisa in due parti e ciascun suono può essere assegnato alla parte Upper o alla parte Lower. Il punto di separazione tra le due parti viene definito dal parametro <i>Split Point</i>, che indica la nota più acuta compresa dalla parte Lower.  Lo Split Mode può essere controllato anche da pannello con il pulsante [SPLIT].</p> <p><b>Impostazioni:</b> OFF, ON</p>
<b>Split Point</b>	<p>Punto di separazione delle parti Lower e Upper quando è attiva la modalità Split.  E' anche possibile assegnare la nota di Split Point direttamente con la tastiera tenendo premuto il pulsante [SPLIT] e premendo la nota desiderata.</p> <p><b>Impostazioni:</b> da C-1 a G9</p>
<b>FS1 Dest</b> <b>FS2 Dest</b> <b>SoftPd/FS1Dest</b> <b>SostPd/FS2Dest</b>	<p>Funzione assegnata ai pedali collegati ai connettori PEDAL [FOOT SWITCH 1] (FS1) e [FOOT SWITCH 2] (FS2) del pannello posteriore.</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>OFF:</b> nessuna funzione assegnata.</li> <li>• <b>Sostenuto:</b> effetto Sostenuto (solo per i suoni dei moduli SOUND COLLECTION, A.PIANO ed E.Grand del modulo E.PIANO). Utilizzando questa funzione solo le note che sono premute nel momento in cui si preme il pedale vengono sostenute.</li> <li>• <b>Soft:</b> effetto Soft (solo per i suoni del modulo SOUND COLLECTION, A.PIANO ed E.Grand del modulo E.PIANO). Utilizzando questa funzione, quando si preme il pedale tutte le note suonate subiscono un leggero abbassamento di volume ed una timbrica più ovattata.</li> <li>• <b>FX1 ON:</b> accensione/spegnimento di FX1 della sezione EFFECTS.</li> <li>• <b>FX1 TAP:</b> parametro controllato dal pulsante [TAP] per FX1.</li> <li>• <b>FX2 ON:</b> accensione/spegnimento di FX2 della sezione EFFECTS.</li> <li>• <b>FX2 TAP:</b> parametro controllato dal pulsante [TAP] per FX2.</li> <li>• <b>REV ON:</b> accensione/spegnimento dell'effetto della sezione REVERB.</li> <li>• <b>Module ON:</b> accensione/spegnimento dei moduli. Questa funzione deve essere abilitata per ciascun modulo con i parametri <i>Foot Switch 1</i> e <i>Foot Switch 2</i> presenti nel menu del modulo interessato.</li> </ul> <p><b>NOTA</b></p> <ul style="list-style-type: none"> <li>- Il parametro assegnato al pulsante [TAP] varia in funzione dell'effetto attualmente selezionato. Per verificare quale parametro si controlla consultare la Sezione EFFECTS a pagina 32.</li> <li>- Quando il parametro Sustain Type (pag. 57) è impostato come Triple, questi campi vengono visualizzati rispettivamente come SoftPd/FS1Dest e SostPd/FS2Dest ed assegnano la funzione al pedale sinistro (Soft) e centrale (Sostenuto) del triplo pedale collegato al connettore PEDAL [SUSTAIN].</li> </ul>
<b>FC1 Dest</b> <b>FC2 Dest</b> <b>Mod.Wheel Dest</b>	<p>Funzione assegnata ai pedali collegati ai connettori PEDAL [FOOT CONTROLLER 1] (FC1) e [FOOT CONTROLLER 2] (FC2) del pannello posteriore ed alla ruota di modulazione (vedi sezione Ruote a pagina 5).</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>OFF:</b> nessuna funzione assegnata.</li> <li>• <b>Expression:</b> controllo continuo del volume durante l'esecuzione.</li> <li>• <b>Modulation:</b> controllo continuo della modulazione durante l'esecuzione.</li> <li>• <b>Aftertouch:</b> trasmissione del messaggio MIDI di Aftertouch sulle porte e canali MIDI impostati nella sezione EXTERNAL.</li> <li>• <b>FX1 Amount:</b> parametro controllato dalla manopola [AMOUNT] per FX1.</li> <li>• <b>FX1 Rate:</b> parametro controllato dalla manopola [RATE] per FX1.</li> <li>• <b>FX2 Amount:</b> parametro controllato dalla manopola [AMOUNT] per FX2.</li> <li>• <b>FX2 Rate:</b> parametro controllato dalla manopola [RATE] per FX2.</li> </ul>

	<ul style="list-style-type: none"> <li><b>Rev Dry/Wet:</b> bilanciamento tra segnale diretto e segnale riverberato.</li> <li><b>Module Par1:</b> controllo di un parametro del modulo (vedi tabella sottostante). Questa funzione deve essere abilitata in ciascun modulo con i parametri <i>Foot Controller 1</i> e <i>Foot Controller 2</i> presenti nel menu del modulo interessato.</li> <li><b>Module Par2:</b> controllo di un parametro del modulo (vedi tabella sottostante). Questa funzione deve essere abilitata in ciascun modulo con i parametri <i>Foot Controller 1</i> e <i>Foot Controller 2</i> presenti nel menu del modulo interessato.</li> </ul> <table border="1"> <thead> <tr> <th>Modulo</th><th>Par 1</th><th>Par 2</th></tr> </thead> <tbody> <tr> <td>E.PIANO</td><td>Trem Intensity</td><td>Trem Speed</td></tr> <tr> <td>A.PIANO</td><td>Dynamic</td><td>Brilliance</td></tr> <tr> <td>CLAVI</td><td>Mute</td><td>Mute</td></tr> <tr> <td>SOUND COLLECTION</td><td>[KNOB 1] parameter</td><td>[KNOB 2] parameter</td></tr> <tr> <td>EXTERNAL</td><td>[CTRL 1] Control Change</td><td>[CTRL 2] Control Change</td></tr> </tbody> </table>	Modulo	Par 1	Par 2	E.PIANO	Trem Intensity	Trem Speed	A.PIANO	Dynamic	Brilliance	CLAVI	Mute	Mute	SOUND COLLECTION	[KNOB 1] parameter	[KNOB 2] parameter	EXTERNAL	[CTRL 1] Control Change	[CTRL 2] Control Change
Modulo	Par 1	Par 2																	
E.PIANO	Trem Intensity	Trem Speed																	
A.PIANO	Dynamic	Brilliance																	
CLAVI	Mute	Mute																	
SOUND COLLECTION	[KNOB 1] parameter	[KNOB 2] parameter																	
EXTERNAL	[CTRL 1] Control Change	[CTRL 2] Control Change																	
<b>Master Clock</b>	<p><b>NOTA</b></p> <p>- I parametri assegnati alle manopole [AMOUNT] e [RATE] variano in funzione dell'effetto attualmente selezionato (sezione EFFECTS a pag. 32).</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li><b>Internal:</b> il tempo viene impostato con il parametro <i>Master Tempo</i>.</li> <li><b>External:</b> il tempo viene ricavato dai messaggi di MIDI Clock ricevuti dallo strumento.</li> </ul> <p><b>NOTA</b></p> <p>- Per abilitare o meno la sincronizzazione fare riferimento al parametro <i>Sync</i>, descritto nella sezione EFFECTS, di ogni effetto.</p> <p>- Quando il parametro <i>Master Clock</i> è configurato come External, se non vengono ricevuti i messaggi di MIDI Clock il tempo di sincronizzazione viene impostato a 120 bpm.</p>																		
<b>Master Tempo</b>	<p>Tempo in Beats per Minute (battiti al minuto) del Master Clock quando è configurato come Internal.</p> <p><b>Impostazioni:</b> da 25 a 250 bpm</p> <p><b>NOTA</b></p> <p>- Se il Master Clock è configurato come External il parametro <i>Master Tempo</i> risulta disabilitato ed il valore viene visualizzato come “---”.</p>																		

## Sezione KEY RANGE

Il menù *KEY RANGE* permette di assegnare ciascun modulo dello strumento ad una specifica zona della tastiera, oppure alla parte Upper e Lower nel caso sia attiva la modalità Split. La modalità Split può essere abilitata o disabilitata tramite il pulsante [SPLIT] presente nell'area PROGRAM del pannello principale.

Per accedere al menu *KEY RANGE*, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *KEY RANGE* e premere il dial data entry.

### Modalità Split disabilitata (SPLIT MODE = OFF)

Quando la modalità Split è disabilitata, è possibile definire una zona di tastiera diversa per ciascun modulo dello strumento. Nella parte superiore della videata è riportata una rappresentazione grafica della tastiera, mentre sotto di essa sono presenti le linee che indicano le zone di tastiera assegnate a ciascuno modulo, indicato dai seguenti acronimi:

- **EP:** E.PIANO
- **AP:** A.PIANO
- **CL:** CLAVINET
- **SC:** SOUND COLLECTION
- **EXT:** EXTERNAL




#### NOTA

Dato che i moduli SOUND COLLECTION ed EXTERNAL sono composti di due parti, la linea superiore indica la zona di tastiera assegnata alla parte 1, mentre la linea inferiore è quella assegnata alla parte 2.

Per definire i limiti della zona di tastiera di un modulo, posizionare tramite il dial data entry od i pulsanti [<] o [>] il cursore sulla linea del modulo interessato e premere il dial.

Come è facile intuire, *Low Key* definisce il tasto più basso della zona di tastiera mentre *Hi Key* definisce il tasto più alto. Tutti i tasti all'interno dell'intervallo produrranno una nota per il modulo selezionato.




Tenendo premuto il pulsante [<] e premendo un tasto della tastiera è possibile selezionare la nota *Lower Key*. Tenendo premuto [>] e premendo un tasto della tastiera si seleziona la nota *Upper Key*.

E' altresì possibile utilizzare il dial data entry per selezionare la nota ed i pulsanti [<] o [>] per muovere il cursore. Una volta effettuata la regolazione premere [EXIT] per tornare alla videata precedente.

### Modalità Split abilitata (SPLIT MODE = ON)

Quando la modalità Split è abilitata, la tastiera risulta divisa in due parti, la parte Lower e la parte Upper, e ciascun modulo può essere assegnato ad una delle parti. Il punto in cui la tastiera è diviso tra le due parti viene definito Split Point e può essere assegnato liberamente, come riportato nella sezione COMMON (pag. 29).

La schermata è simile a quella visualizzata nella modalità Split disabilitata, con la differenza però che la tastiera è divisa solamente in due zone. E' possibile assegnare ogni modulo alla parte Upper o alla parte Lower. Un modulo assegnato alla parte Upper è in grado di produrre una nota a partire dal tasto successivo allo Split Point, mentre un modulo assegnato alla parte Lower, può suonare i tasti più bassi di tastiera sino allo Split Point compreso.



Per assegnare un modulo ad una delle due parti, posizionare tramite il dial data entry od i pulsanti [<] o [>] il cursore sulla linea del modulo interessato e premere il dial. Il parametro *Split Part* indica la parte di tastiera assegnata al modulo selezionato. Per modificare il valore utilizzare il dial data entry. Una volta effettuata la selezione premere [EXIT] per tornare alla videata precedente.



#### NOTE

- Tenendo premuto il pulsante [SPLIT] e premendo la nota desiderata è possibile impostare la nota di Split Point direttamente con la tastiera .
- Tenendo premuto il pulsante [SPLIT] e premendo ripetutamente il pulsante [ON/OFF] di un modulo è possibile assegnare lo stesso ciclicamente alla parte Upper o Lower.

## Sezione EFFECTS

Il menù *EFFECTS* raccoglie i parametri di configurazione della sezione *EFFECTS* del pannello principale (descritto a pagina 9).

La sezione *EFFECTS* mette a disposizione due effetti indipendenti, che possono essere richiamati utilizzando i pulsanti [1] o [2] del pannello principale. Il valore del parametro visualizzato viene immediatamente aggiornato. L'effetto selezionato per l'editing viene indicato a display nell'intestazione del menu dai campi *FX1* o *FX2*.

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28)

posizionare il cursore sul campo *EFFECTS* e premere il dial data entry, oppure tenere premuta per qualche istante la manopola di selezione della categoria di effetto (punto 6 a pagina 9).

**FX1:Chorus** 5/15  
Category:  
**Chorus**

### Categorie degli effetti

Gli effetti disponibili in *Legend '70s* sono raggruppati in categorie. Per selezionare la categoria desiderata utilizzare l'apposita manopola (punto 6 a pagina 9) oppure il parametro *Category* presente nel menu *EFFECTS*. Ciascuna categoria di effetti mette a disposizione un adeguato numero di preset, che permettono di richiamare delle configurazioni preprogrammate, appositamente studiate per riprodurre con grande realismo il funzionamento tipico della unità effetti di riferimento. E' inoltre possibile modificare i parametri principali dell'effetto utilizzando le manopole *[AMOUNT]* e *[RATE]*, il pulsante *[TAP]* del pannello principale. Tuttavia gli utenti più esigenti possono utilizzare il preset *Custom*, che permette di accedere a tutti i parametri disponibili, per ottenere la completa personalizzazione dell'effetto.

Per selezionare la configurazione di effetto desiderata di una determinata categoria premere la manopola di selezione della categoria di effetto oppure utilizzare il parametro *Preset*.



#### NOTA

- Nelle tabelle a seguire sono riportati i parametri disponibili con il preset *Custom*. Sotto il nome del parametro è riportata la manopola e pulsante *[TAP]* che ne permette il controllo diretto da pannello.
- Per la lista completa dei preset disponibili si rimanda alla tabella *Lista dei Preset degli effetti* a pag 65.
- Per la categoria *Others*, dopo aver premuto la manopola di selezione della categoria per selezionare un preset, utilizzare i pulsanti *[<]* e *[>]* per passare ai *PEQ3*, *PEQ5*, *GEQ5*, *Comp* o *Rotary*.

### Tremolo e Vibrato

Il Tremolo modula ciclicamente l'ampiezza del segnale, ovvero il volume del suono così da renderlo tremolante.

Il Vibrato modula ciclicamente la frequenza del segnale, ovvero l'intonazione del suono.

Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b>	<p>Collegamento degli effetti FX1 e FX2 della sezione <i>EFFECTS</i>.</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Parallel:</b> collegamento parallelo. Il segnale in uscita a FX1 viene sommato a quello in uscita a FX2.</li> <li>• <b>Serial:</b> collegamento seriale. Il segnale in uscita a FX1 viene inviato all'ingresso di FX2.</li> </ul> <p><b>PARALLEL</b></p>  <p><b>SERIAL</b></p> 

<b>FX Out Routing</b>	<p>Assegnazione dell'uscita audio di FX1 o di FX2.</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Main L-R:</b> connettori AUDIO OUT [MAIN L/MONO] e [MAIN R] del pannello posteriore (segnale stereo).</li> <li>• <b>Aux1 Mono:</b> connettore AUDIO OUT [AUX 1] del pannello posteriore (segnale mono).</li> <li>• <b>Aux2 Mono:</b> connettore AUDIO OUT [AUX 2] del pannello posteriore (segnale mono).</li> <li>• <b>Aux1-2:</b> connettori AUDIO OUT [AUX 1] e [AUX 2] del pannello posteriore (segnale stereo).</li> </ul>
<b>Reverb Send</b>	<p>Livello del segnale audio in uscita all'effetto da inviare all'effetto Reverb.</p> <p><b>Impostazioni:</b> da 0 a 127</p> <p><b>NOTA</b> <i>In caso di collegamento seriale degli effetti FX1 ed FX2 (parametro FX Config), il livello del segnale inviato al REVERB è determinato dal Reverb Send di FX2.</i></p>
<b>Mod. Type</b>	<p>Tipo di modulazione.</p> <p><b>Impostazioni:</b> Tremolo, Vibrato</p>
<b>LFO Depth [AMOUNT]</b>	<p>Profondità di modulazione.</p> <p><b>Impostazioni:</b> da 0.0 a 10.0</p>
<b>LFO Speed [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Frequenza di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione in base al tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella Sezione COMMON (pag. 30). <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <p><b>NOTA</b> <i>D (dot): punto di valore T (triplet): terzino</i></p>
<b>LFO Wave</b>	<p>Forma d'onda del segnale modulante.</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Triangle:</b> triangolo.</li> <li>• <b>Sine:</b> sinusoida.</li> <li>• <b>Square:</b> impulso.</li> <li>• <b>Suit76:</b> tremolo del Rhodes Suitcase 76.</li> <li>• <b>Wr200:</b> tremolo del Wurlitzer 200.</li> </ul>
<b>L/R Phase</b>	<p>Fase tra il canale destro e sinistro del segnale modulante.</p> <p><b>Impostazioni:</b> da 0 a 180 deg (gradi). A 0 deg corrisponde un segnale modulante monofonico. Incrementando il valore si ottiene un segnale sempre più stereofonico.</p>
<b>Sync</b>	<p>Sincronizzazione del segnale modulante con il tempo metronomico impostato con il parametro <i>Master Clock</i> nella Sezione COMMON (pag. 30).</p> <p><b>Impostazioni:</b> OFF, ON</p>
<b>EQ Low Gain</b>	<p>Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto.</p> <p><b>Impostazioni:</b> da -12.0 a +12.0 dB</p>
<b>EQ High Gain</b>	<p>Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto.</p> <p><b>Impostazioni:</b> da -12.0 a +12.0 dB</p>

## Chorus

Effetto di modulazione che rende il suono più “corposo”, caldo e profondo.

Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Chorus Type</b>	Tipo di Chorus. <b>Impostazioni:</b> Chorus1, Chorus2, Chorus3, Chorus4,
<b>LFO Depth</b>	Profondità di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0
<b>LFO Speed</b> [RATE], [TAP]	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Frequenza di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione in base al tempo metronomico impostato con il parametro <i>Master Clock</i> nella Sezione COMMON (pag. 30). <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <p><b>NOTA</b>  <i>D</i> (dot): punto di valore  <i>T</i> (triplet): terzino</p>
<b>Pre Delay</b>	Offset di modulazione. <b>Impostazioni:</b> da 0.0 a 50.0 msec
<b>L/R Phase</b>	Fase tra il canale destro e sinistro del segnale modulante. <b>Impostazioni:</b> da 0 a 180 deg (gradi). A 0 deg corrisponde un segnale modulante monofonico. Incrementando il valore si ottiene un segnale sempre più stereofonico.
<b>Sync</b>	Sincronizzazione del segnale modulante con il tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella Sezione COMMON (pag. 30). <b>Impostazioni:</b> OFF, ON
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Dry/Wet</b> [AMOUNT]	Bilanciamento tra segnale originale in ingresso all'effetto ( <i>Dry/Wet</i> =0.0) e segnale elaborato dall'effetto ( <i>Dry/Wet</i> =10.0). <b>Impostazioni:</b> da 0.0 a 10.0

## Flanger

Effetto di modulazione che rende il suono circolare e metallico.

Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Flanger Type</b>	Tipo di Flanger. <b>Impostazioni:</b> Flanger1, Flanger 2, Flanger 3, Flanger 4,
<b>LFO Depth</b>	Profondità di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0
<b>LFO Speed</b> [RATE], [TAP]	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Frequenza di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione in base al tempo</li> </ul>

	metronomico impostato con il parametro <i>Master Clock</i> nella Sezione COMMON (pag. 30).
	<b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64 <b>NOTA</b> <i>D (dot): punto di valore</i> <i>T (triplet): terzinato</i>
<b>Feedback</b>	Quantità e fase del segnale che viene riportato all'ingresso dell'effetto e che pertanto determina di quanto il segnale viene rielaborato ed arricchito. A valori negativi corrisponde il segnale con fase invertita. <b>Impostazioni:</b> da -5.0 a +5.0
<b>Pre Delay</b>	Offset di modulazione. <b>Impostazioni:</b> da 0.0 a 50.0 msec
<b>L/R Phase</b>	Fase tra il canale destro e sinistro del segnale modulante. <b>Impostazioni:</b> da 0 a 180 deg (gradi). A 0 deg corrisponde un segnale modulante monofonico. Incrementando il valore si ottiene un segnale sempre più stereofonico.
<b>Sync</b>	Sincronizzazione del segnale modulante con il tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella Sezione COMMON (pag. 30). <b>Impostazioni:</b> OFF, ON
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Dry/Wet [AMOUNT]</b>	Bilanciamento tra segnale originale in ingresso all'effetto ( <i>Dry/Wet</i> =0.0) e segnale elaborato dall'effetto ( <i>Dry/Wet</i> =10.0). <b>Impostazioni:</b> da 0.0 a 10.0

## Phaser

Effetto che aggiunge al segnale originale una copia a cui viene modulata la fase.

Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Phaser Type</b>	Tipo di Phaser. <b>Impostazioni:</b> 4-Stage, 6-Stage, 8-Stage, 12-Stage
<b>LFO Depth</b>	Profondità di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0
<b>LFO Speed [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Frequenza di modulazione.  <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione in base al tempo metronomico impostato con il parametro <i>Master Clock</i> nella Sezione COMMON (pag. 30).  <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <b>NOTA</b> <i>D (dot): punto di valore</i> <i>T (triplet): terzinato</i>
<b>Feedback [AMOUNT]</b>	Quantità di segnale che viene riportato all'ingresso dell'effetto e che pertanto determina di quanto il segnale viene rielaborato ed arricchito. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Manual</b>	Frequenza centrale della modulazione del segnale. <b>Impostazioni:</b> da 0.0 a 10.0
<b>L/R Phase</b>	Fase tra il canale destro e sinistro del segnale modulante. <b>Impostazioni:</b> da 0 a 180 deg (gradi). A 0 deg corrisponde un segnale modulante monofonico. Incrementando il valore si ottiene un segnale sempre più stereofonico.
<b>Sync</b>	Sincronizzazione del segnale modulante con il tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella Sezione COMMON (pag. 30). <b>Impostazioni:</b> OFF, ON

<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Dry/Wet</b>	Bilanciamento tra segnale originale in ingresso all'effetto ( <i>Dry/Wet</i> =0.0) e segnale elaborato dall'effetto ( <i>Dry/Wet</i> =10.0). <b>Impostazioni:</b> da 0.0 a 10.0

## Wah

Effetto basato su un filtro che si muove in frequenza, modulando la brillantezza del suono. Sono disponibili tre tipi di Wah: *Control Wah* modula il suono tramite un controllo continuo come un pedale collegato al [FOOT CONTROLLER 1] o [FOOT CONTROLLER 2], la ruota di modulazione o la manopola [RATE]. *Auto Wah* modula il suono ciclicamente in automatico. *Touch Wah* modula il suono in base al livello del suono (più si suona forte, più si apre il filtro).

Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Wah Type</b>	Tipo di Wah. <b>Impostazioni:</b> Control, Auto, Touch
<b>Top</b>	Frequenza massima del filtro. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Bottom</b>	Frequenza minima del filtro. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Resonance [AMOUNT]</b>	Risonanza del filtro che determina di quanto vengono esaltate le frequenze attorno a quella di taglio. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Filter Type</b>	Tipo di filtro. <b>Impostazioni:</b> LP (passa-basso), BP (passa-banda), HP (passa-alto)
<b>LFO Speed (Auto Wah) [RATE], [TAP]</b>	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Frequenza di modulazione. <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione in base al tempo metronomico impostato con il parametro <i>Master Clock</i> nella Sezione COMMON (pag. 30).   <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64           </li> </ul> <p><b>NOTA</b>  <i>D (dot): punto di valore</i>  <i>T (triplet): terzinato</i></p>
<b>Sensitivity (Touch Wah) [RATE]</b>	Sensibilità alla dinamica dei tasti (e quindi al livello del segnale). <b>Impostazioni:</b> da 0.0 a 10.0
<b>Control (Control Wah) [RATE]</b>	Posizione del controllo continuo. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Sync (Auto Wah)</b>	Sincronizzazione del segnale modulante con il tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella funzione COMMON (pag. 30). <b>Impostazioni:</b> OFF, ON
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB

### NOTA

Utilizzando il Control Wah è necessario assegnare la funzione FX1 o FX2 RATE (pagina 29) al pedale utilizzato.

## Amp

Effetto per la simulazione di amplificatore.

Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina <a href="#">32</a> .
<b>Amp Type</b>	Tipo di amplificatore. <b>Impostazioni:</b> Suit76, Wr200, Sweet, Vintage, '59 Clean, Twin, Small, Twin Punch, Lo-Fi, Punch Stack, Fuzz Drive, Bass Stack, Sub Bass
<b>Drive</b> [AMOUNT]	Quantità di distorsione del segnale. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Output Level</b> [RATE]	Livello di uscita dall'effetto. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Bass</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Middle</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle medie frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Treble</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB

**NOTA**

Per la categoria Amp non sono previsti preset.

## Delay

Effetto che genera ripetizioni del segnale per creare effetti ambientali o ritmici.

*Mono Delay* genera ripetizioni monofoniche, indipendentemente dal Sound selezionato (stereo o mono). *Stereo Delay* fornisce ripetizioni stereofoniche, per cui con un suono stereo anche le ripetizioni mantengono il panorama stereofonico. *PingPong Delay* permette di distribuire le ripetizioni alternativamente sul canale destro e sinistro.


Parameter name	Description
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina <a href="#">32</a> .
<b>Delay Type</b>	Tipo di Delay. <b>Impostazioni:</b> Mono, Stereo, PingPong
<b>Time / bpm</b> [RATE]	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Sync = OFF</b> Tempo che intercorre tra una ripetizione e la successiva, regolabile in millisecondi o bpm (battiti al minuti). <b>Impostazioni:</b> da 20 mses a 1.5 sec / da 40 a 750 bpm</li> <li>▪ <b>Se il parametro Sync = ON</b> Divisione musicale con cui viene calcolato il tempo tra una ripetizione e la successiva in base al tempo metronomico impostato con il parametro <i>Master Clock</i> (indicato dal parametro <i>bpm</i>) presente nella funzione <i>COMMON</i> (pag. <a href="#">30</a>). <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <p><b>NOTA</b>  <i>D (dot): punto di valore</i>  <i>T (triplet): terzinato</i></p>
<b>Feedback</b>	Quantità di segnale riportato all'ingresso e con ciò la durata dell'effetto. <b>Impostazioni:</b> da 0.0 a 10.0
<b>High Dump</b>	Velocità di attenuazione delle alte frequenze nelle ripetizioni del segnale. <b>Impostazioni:</b> da 0.0 a 10.0

<b>Sync</b>	Sincronizzazione del tempo tra le ripetizioni con il tempo metronomico impostato con il parametro <i>Master Clock</i> presente nella funzione <i>COMMON</i> (pag. 30). <b>Impostazioni:</b> OFF, ON
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Dry/Wet [AMOUNT]</b>	Bilanciamento tra segnale originale in ingresso all'effetto ( <i>Dry/Wet=0.0</i> ) e ripetizioni ( <i>Dry/Wet=10.0</i> ). <b>Impostazioni:</b> da 0.0 a 10.0

## Others

### Others Type: PEQ3 – PEQ5

Equalizzatore parametrico a 3 bande (PEQ3) e 5 bande (PEQ5).




Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Low Freq</b>	Frequenza centrale della banda delle basse frequenze. <b>Impostazioni:</b> da 40 a 400 Hz
<b>Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) della banda delle basse frequenze impostata con il parametro <i>Low Freq</i> . <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Mid Freq</b> (solo PEQ3) [RATE]	Frequenza centrale della banda delle medie frequenze. <b>Impostazioni:</b> da 60 a 8000 Hz
<b>Mid Gain</b> (solo PEQ3) [AMOUNT]	Guadagno (valori positivi) o attenuazione (valori negativi) delle banda delle medie frequenze impostata con il parametro <i>Mid Freq</i> . <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Mid Q</b> (solo PEQ3)	Larghezza di banda delle medie frequenze. Valori grandi di Q restringono la banda del filtro. <b>Impostazioni:</b> da 0.5 a 8.0
<b>Mid1 Freq</b> (solo PEQ5) [AMOUNT]	Frequenza centrale della banda 1 delle medie frequenze. <b>Impostazioni:</b> da 60 a 8000 Hz
<b>Mid1 Gain</b> (solo PEQ5) [RATE]	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 1 delle medie frequenze impostata con il parametro <i>Mid1 Freq</i> . <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Mid1 Q</b> (solo PEQ5)	Larghezza della banda 1 delle medie frequenze. Valori grandi di Q restringono la banda del filtro. <b>Impostazioni:</b> da 0.5 a 8.0
<b>Mid2 Freq</b> (solo PEQ5)	Frequenza centrale della banda 2 delle medie frequenze. <b>Impostazioni:</b> da 60 a 8000 Hz
<b>Mid2 Gain</b> (solo PEQ5)	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 2 delle medie frequenze. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Mid2 Q</b> (solo PEQ5)	Larghezza della banda 2 delle medie frequenze. Valori grandi di Q restringono la banda del filtro. <b>Impostazioni:</b> da 0.5 a 8.0

<b>Mid3 Freq</b> (solo PEQ5)	Frequenza centrale della banda 3 delle medie frequenze. <b>Impostazioni:</b> da 60 a 8000 Hz
<b>Mid3 Gain</b> (solo PEQ5)	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 3 delle medie frequenze. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Mid3 Q</b> (solo PEQ5)	Larghezza della banda 3 delle medie frequenze. Valori grandi di Q restringono la banda del filtro. <b>Impostazioni:</b> da 0.5 a 8.0
<b>High Freq</b>	Frequenza centrale della banda delle alte frequenze. <b>Impostazioni:</b> da 2000 a 160000 Hz
<b>High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle banda delle alte frequenze. <b>Impostazioni:</b> da -12.0 a +12.0 dB

## Others

### Others Type: GEQ5

Equalizzatore grafico 5 bande.



Nome parametro	Descrizione
<b>Switch</b> [FX ON]	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>EQ1 Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 1 con frequenza centrale a 100 Hz. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ2 Gain</b> [AMOUNT]	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 2 con frequenza centrale a 335 Hz. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ3 Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 3 con frequenza centrale a 1000 Hz. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ4 Gain</b> [RATE]	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 4 con frequenza centrale a 3350 Hz. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ5 Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) della banda 5 con frequenza centrale a 8000 Hz. <b>Impostazioni:</b> da -12.0 a +12.0 dB

## Others

### Others Type: Compressor

Effetto Compressore tramite il quale limitare e comprimere le dinamiche del segnale. Può essere utilizzato per creare un suono più potente e con un livello più costante o per incrementare il sustain delle note.

Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Threshold [AMOUNT]</b>	Livello del segnale sopra il quale comincia ad agire la compressione. <b>Impostazioni:</b> da -48.0 a 0.0 dB
<b>Ratio</b>	Rapporto di compressione. <b>Impostazioni:</b> 1.5:1, 2:1, 3:1, 4:1, 6:1, 8:1, 10:1, 20:1
<b>Attack</b>	Tempo di intervento della compressione del livello dopo che il segnale supera la soglia. <b>Impostazioni:</b> da 0 a 200 ms
<b>Release</b>	Tempo di rilascio della compressione del livello dopo che il segnale scende sotto la soglia. <b>Impostazioni:</b> da 25 a 2000 ms
<b>Output Level [RATE]</b>	Livello di uscita dell'effetto. <b>Impostazioni:</b> da 0.0 a 10.0
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB

## Others

### Others Type: Rotary

Effetto di simulazione di un amplificatore con diffusori rotanti tipicamente utilizzato con l'organo elettromeccanico.

Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>FX Config</b> <b>FX Out Routing</b> <b>Reverb Send</b>	Stessa funzione dei parametri descritti a pagina 32.
<b>Brake</b>	Arresto graduale della rotazione dei diffusori. <b>Impostazioni:</b> OFF, ON
<b>Speed [RATE]</b>	Velocità di rotazione dei diffusori. <b>Impostazioni:</b> Slow (lenta) – Fast (veloce)
<b>Drive [AMOUNT]</b>	Quantità di distorsione del segnale. <b>Impostazioni:</b> da 0.0 a 10.0
<b>D/H Balance</b>	Bilanciamento tra suono emesso dal diffusore dei bassi ( <i>D/H Balance</i> =0.0) e suono emesso dalla tromba ( <i>D/H Balance</i> =10.0). <b>Impostazioni:</b> da 0.0 a 10.0
<b>Drum Slow</b>	Velocità di rotazione del diffusore dei bassi quando è selezionata la velocità Slow <b>Impostazioni:</b> da 30.0 a 60.0 RPM
<b>Drum Fast</b>	Velocità di rotazione del diffusore dei bassi quando è selezionata la velocità Fast <b>Impostazioni:</b> da 360.0 a 420.0 RPM
<b>Drum Rise/Fall</b>	Tempo che impiega il diffusore dei bassi per cambiare velocità. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Horn Slow</b>	Velocità di rotazione della tromba quando è selezionata la velocità Slow <b>Impostazioni:</b> da 30.0 a 60.0 RPM
<b>Horn Fast</b>	Velocità di rotazione della tromba quando è selezionata la velocità Fast <b>Impostazioni:</b> da 360.0 a 420.0 RPM
<b>Horn Rise/Fall</b>	Tempo che impiega la tromba per cambiare velocità. <b>Impostazioni:</b> da 0.0 a 10.0
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB

## Sezione REVERB

Il riverbero nasce come somma delle varie riflessioni acustiche prodotte da un suono in un ambiente. Un gran numero di fattori determina la risposta acustica di un particolare tipo di riverbero, questi includono le dimensioni e la morfologia dell'ambiente, il materiale con cui sono rivestite le pareti e tanti altri.

Il menu *REVERB* raccoglie i parametri di configurazione della sezione REVERB del pannello principale (descritto a pagina 8).

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *REVERB* e premere il dial data entry, oppure tenere premuto per qualche istante la manopola di selezione della categoria di riverbero (punto 3 a pagina 8).

### Categorie dei riverberi

I riverberi disponibili in *Legend '70s* sono raggruppati in categorie, in base al tipo di ambiente o di dispositivo di riverberazione che si desidera simulare. Per selezionare la categoria desiderata utilizzare l'apposita manopola (punto 3 a pagina 8) oppure il parametro *Category* presente nel menu *REVERB*.

Per ciascuna categoria è possibile scegliere alcune varianti, premendo la manopola di selezione e scegliendo il tipo di riverbero della categoria selezionata, oppure utilizzando il parametro *Type* presente nel menu *REVERB*.

La tabella seguente mostra tutti i riverberi messi a disposizione dallo strumento:

Category	Type
<b>Room</b>	<ul style="list-style-type: none"> <li>• Small Room: riverbero in una stanza di piccole dimensioni, con pareti molto assorbenti.</li> <li>• Large Room: riverbero in una stanza di grandi dimensioni, con pareti poco assorbenti.</li> </ul>
<b>Hall</b>	<ul style="list-style-type: none"> <li>• Small Hall: riverbero in una sala da concerto di piccole dimensioni ma con pareti abbastanza riflettenti.</li> <li>• Medium Hall: riverbero in una sala da concerto di medie dimensioni con pareti abbastanza riflettenti.</li> <li>• Large Hall: riverbero in una sala da concerto di grandi dimensioni e con pareti molto riflettenti.</li> </ul>
<b>Stage</b>	<ul style="list-style-type: none"> <li>• Stage1, Stage2: simulano l'acustica di un palco da concerto in una situazione live.</li> </ul>
<b>Plate</b>	<ul style="list-style-type: none"> <li>• Medium Plate: riverbero prodotto dalla vibrazione di una piastra metallica di medie dimensioni.</li> <li>• Large Plate: riverbero prodotto dalla vibrazione di una piastra metallica di grandi dimensioni.</li> </ul>
<b>Spring</b>	<ul style="list-style-type: none"> <li>• Spring 1, Spring 2: due varianti del riverbero a molla simile a quello utilizzato negli amplificatori degli anni '70.</li> </ul>
<b>Tape</b>	<ul style="list-style-type: none"> <li>• Tape 1, Tape 2: due varianti del riverbero a nastro ottenuto dall'utilizzo di un registratore analogico e una camera riverberante.</li> </ul>

### Parametri dei riverberi

Nome parametro	Descrizione
<b>Switch [FX ON]</b>	Attivazione / disattivazione dell'effetto. <b>Impostazioni:</b> OFF, ON
<b>Time</b>	Durata della riverberazione. <b>Impostazioni:</b> da 0.0 a 10.0
<b>High Damp</b>	Velocità di attenuazione delle alte frequenze del segnale riverberato. <b>Impostazioni:</b> da 0.0 a 10.0
<b>EQ Low Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>EQ High Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono in uscita all'effetto. <b>Impostazioni:</b> da -12.0 a +12.0 dB
<b>Dry/Wet [DRY/WET]</b>	Bilanciamento tra segnale originale in ingresso all'effetto ( <i>Dry/Wet</i> =0.0) e segnale riverberato ( <i>Dry/Wet</i> =10.0). <b>Impostazioni:</b> da 0.0 a 10.0

## Sezione E.PIANO


Il menù *E.PIANO* raccoglie i parametri di configurazione del modulo *E.PIANO* (pag. 11).

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *E.PIANO* e premere il dial data entry, oppure tenere premuta per qualche istante la manopola di selezione dei suoni del modulo (punto 4 a pagina 12).



### NOTA

Nella tabella a seguire sono riportati tutti i parametri disponibili per il modulo *E.PIANO*. Sotto il nome del parametro è riportata la manopola o pulsante che ne permette il controllo diretto da pannello.

Nome parametro	Descrizione
<b>Timbre</b> [timbre selector]	Nome del timbro selezionato. Sono disponibili 8 timbri di pianoforte elettrico, diversi per caratteristiche elettriche e meccaniche. Con l'applicazione <i>Legend '70s Editor</i> è possibile modificare i timbri selezionati. Le modifiche apportate da questa applicazione hanno effetto su tutti i Program. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• Rhod 1, Rhod 2, Rhod 3, Rhod 4, Rhod 5: pianoforte elettrico di tipo "tine" (Rhodes).</li> <li>• Wurli 1, Wurli 2: pianoforte elettrico di tipo "reed" (Wurlitzer).</li> <li>• E.Grand: pianoforte elettro-acustico a coda (CP-80).</li> </ul>
<b>Switch</b> [ON/OFF]	Attivazione / disattivazione del modulo. <b>Impostazioni:</b> OFF, ON
<b>Volume</b> [VOLUME]	Volume del segnale generato dal modulo. <b>Impostazioni:</b> da 0 a 127
<b>Output Routing</b>	Assegnazione della uscita audio del modulo. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>Main L-R:</b> connettori AUDIO OUT [MAIN L/MONO] e [MAIN R] del pannello posteriore (segnale stereo).</li> <li>• <b>FX1:</b> ingresso dell'effetto FX1 della sezione EFFECTS.</li> <li>• <b>FX2:</b> ingresso dell'effetto FX2 della sezione EFFECTS.</li> <li>• <b>FX1+FX2:</b> ingresso di entrambi gli effetti FX1 e FX2 della sezione EFFECTS.</li> <li>• <b>Aux1 Mono:</b> connettore AUDIO OUT [AUX 1] del pannello posteriore (segnale mono).</li> <li>• <b>Aux2 Mono:</b> connettore AUDIO OUT [AUX 2] del pannello posteriore (segnale mono).</li> <li>• <b>Aux1-2:</b> connettori AUDIO OUT [AUX 1] e [AUX 2] del pannello posteriore (segnale stereo).</li> </ul>  <pre> graph LR     SM[Sound Module] --&gt; Reverb[Reverb]     SM --&gt; FX1[FX1]     SM --&gt; FX2[FX2]     SM --&gt; Aux1[AUX1]     SM --&gt; Aux2[AUX2]     Reverb --&gt; MEQ[Master EQ]     MEQ --&gt; MAINL["MAIN L-R"]     FX1 --&gt; FXROUT1["FX Out Routing"]     FX2 --&gt; FXROUT2["FX Out Routing"]     Aux1 --&gt; AUX1     Aux2 --&gt; AUX2     </pre> <p>The diagram illustrates the output routing configuration. The Sound Module has five output paths: one to a Reverb effect, which then connects to a Master EQ and finally to the MAIN L-R output; two paths to FX1 and FX2 effects, which can be selected via a switch labeled "depends on FX Config"; and two paths to AUX1 and AUX2 outputs. Dashed lines indicate alternative routing paths or configurations.</p>
<b>Reverb Send</b>	Livello del segnale audio generato dal modulo da inviare all'effetto Reverb. <b>Impostazioni:</b> da 0 a 127  <b>NOTA</b> Questo parametro ha effetto solo se l'uscita audio selezionata con il parametro Output Routing è MAIN L-R.
<b>Detune</b>	Intonazione per centesimi di semitono del suono generato dal modulo. <b>Impostazioni:</b> da -50 a +50 centesimi di semitono

<b>Note Shift</b>	Trasposizione per semitoni del suono generato dal modulo. <b>Impostazioni:</b> da -48 a +48 semitoni  <b>NOTA</b> Quando viene applicata una trasposizione il Led [  ] del modulo è acceso.
<b>Velocity Sens</b>	Sensibilità del livello del segnale generato dal modulo in risposta al tocco sulla tastiera (velocity). Applicando una determinata forza, il livello del segnale aumenta per valori positivi del parametro, mentre si riduce per valori negativi. <b>Impostazioni:</b> da -5 a +5
	<p><b>NOTA</b>  - Il grafico di cui sopra fa riferimento alla curva di dinamica della tastiera Normal (pag. 55).  - Il parametro Velocity Sens non ha effetto con la curva di dinamica di tastiera Fixed (pag. 55).</p>
<b>Pitch Bend</b>	Abilitazione per questo modulo della ruota ① (vedi sezione Ruote a pagina 5) <b>Impostazioni:</b> OFF, ON
<b>Mod.Wheel</b>	Abilitazione per questo modulo della ruota ② (vedi sezione Ruote a pagina 5) <b>Impostazioni:</b> OFF, ON  <b>NOTA</b> La funzione associata alla ruota modulation è definita nel menu COMMON dal parametro Mod.Wheel Dest (pag. 29) ed è comune a tutti i moduli.
<b>Sustain Pedal</b>	Abilitazione per questo modulo di Sustain collegato al connettore [SUSTAIN] del pannello posteriore. <b>Impostazioni:</b> OFF, ON
<b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Abilitazione per questo modulo dei pedali collegati ai connettori PEDAL [FOOT SWITCH 1], [FOOT SWITCH 2], [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2] del pannello posteriore. <b>Impostazioni:</b> OFF, ON  <b>NOTE</b> - La funzione associata a questi pedali è definita nella Sezione COMMON dai parametri FS1 Dest, FS2 Dest, FC1 Dest, FC2 Dest (pag. 29) ed è comune a tutti i moduli. - I parametri Foot Switch 1 e Foot Switch 2 controllano l'abilitazione rispettivamente anche dei pedali sinistro e centrale del triplo pedale collegato al connettore PEDAL [SUSTAIN]
<b>Trem Switch</b> [TREM ON]	Attivazione / disattivazione dell'effetto Tremolo del modulo E.PIANO. <b>Impostazioni:</b> OFF, ON
<b>Trem Intensity</b> [INTENSITY]	Profondità di modulazione dell'effetto Tremolo del modulo E.PIANO. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Trem Speed</b> [SPEED]	<ul style="list-style-type: none"> <li>▪ <b>Se il parametro Trem Sync = OFF</b> Frequenza di modulazione dell'effetto Tremolo del modulo E.PIANO. Per questo controllo è inoltre presente un indicatore a Led che lampeggi con frequenza pari a quella impostata. <b>Impostazioni:</b> da 0.0 a 10.0</li> <li>▪ <b>Se il parametro Trem Sync = ON</b> Divisione musicale con cui viene calcolata la frequenza di modulazione dell'effetto Tremolo del modulo E.PIANO in base al tempo metronomico impostato con il parametro Master Clock presente nella Sezione COMMON (indicato dal parametro bpm). <b>Impostazioni:</b> 1/1, 1/2D, 1/1T, 1/2, 1/4D, 1/2T, 1/4, 1/8D, 1/4T, 1/8, 1/16D, 1/8T, 1/16, 1/16T, 1/32, 1/64</li> </ul> <b>NOTA</b> D (dot): punto di valore T (triplet): terzinato
<b>Trem Wave</b>	Forma d'onda del segnale modulante. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>Triangle:</b> triangolo.</li> <li>• <b>Sine:</b> sinusoida.</li> <li>• <b>Square:</b> impulso.</li> <li>• <b>Suit76:</b> tremolo del Rhodes Suitcase 76.</li> <li>• <b>Wr200:</b> tremolo del Wurlitzer 200.</li> </ul>

<b>Trem Sync</b>	Attivazione / disattivazione della sincronizzazione dell'effetto Tremolo del modulo E.PIANO al <i>Master Clock</i> . Quando il parametro <i>Tremolo Sync</i> è abilitato ( <i>Tremolo Sync: ON</i> ), la frequenza di modulazione del Tremolo è regolata dal <i>Master Clock</i> ed il parametro <i>Tremolo Speed</i> determina il fattore moltiplicativo del parametro <i>Master Tempo</i> nella Sezione COMMON o del MIDI Clock ricevuto (pag. 30). <b>Impostazioni:</b> OFF, ON
<b>Trem Stereo</b>	Attivazione / disattivazione della modalità Stereo dell'effetto Tremolo del modulo E.PIANO. Quando questo parametro è disabilitato ( <i>Tremolo Stereo: OFF</i> ), il segnale in uscita dal Tremolo risulta centrato nell'immagine stereofonica. Quando il parametro viene abilitato ( <i>Tremolo Stereo: ON</i> ), il segnale in uscita si muove a sinistra e a destra dell'immagine stereofonica. <b>Impostazioni:</b> OFF, ON
<b>Amp Switch [AMP ON]</b>	Attivazione / disattivazione dell'effetto Amplificatore del modulo E.PIANO. <b>Impostazioni:</b> OFF, ON
<b>Amp Model</b>	Modello dell'effetto Amplificatore del modulo E.PIANO. Sono disponibili 13 modelli di amplificatore, diversi per sezione pre-amplificatore, finale di potenza, mobile ed altoparlanti. <b>Impostazioni:</b> Suit76, Wr200, Sweet, Vintage, '59 Clean, Twin, Small, Twin Punch, Lo-Fi, Punch Stack, Fuzz Drive, Bass Stack, Sub Bass
<b>Amp Drive</b>	Saturazione (distorsione) del segnale in uscita all'effetto Amplificatore del modulo E.PIANO. <b>Impostazioni:</b> da 0.0 a 10.0
<b>Bass Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle basse frequenze del suono generato dal modulo E.PIANO. <b>Impostazioni:</b> da -5.0 a +5.0
<b>Treble Gain</b>	Guadagno (valori positivi) o attenuazione (valori negativi) delle alte frequenze del suono generato dal modulo E.PIANO. <b>Impostazioni:</b> da -5.0 a +5.0

## Sezione A.PIANO

Il menù A.PIANO raccoglie i parametri di configurazione del modulo A.PIANO (descritto a pagina 13).

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *A.PIANO* e premere il dial data entry, oppure tenere premuta per qualche istante la manopola di selezione dei suoni del modulo (punto 4 a pagina 13).



### NOTA

Nella tabella a seguire sono riportati tutti i parametri disponibili per il modulo A.PIANO. Sotto il nome del parametro è riportata la manopola o pulsante che ne permette il controllo diretto da pannello.

Nome parametro	Descrizione
<b>Timbre</b> [timbre selector]	Nome del timbro selezionato. Sono disponibili 8 timbri di pianoforte acustico, diversi per caratteristiche meccaniche ed acustiche. Con l'applicazione <i>Legend '70s Editor</i> è possibile modificare i timbri selezionati. Le modifiche apportate da questa applicazione hanno effetto su tutti i Program. <b>Impostazioni:</b> Piano 1, Piano 2, Piano 3, Piano 4, Piano 5, Piano 6, Piano 7, Piano 8
<b>Switch</b> <b>Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Stessa funzione dei parametri descritti a pagina 42.
<b>Dynamic</b> [DYNAMIC]	Range dinamico del pianoforte acustico. Permette di ridurre (valori negativi) o accentuare (valori positivi) la differenza di livello tra il pianissimo ed il fortissimo. <b>Impostazioni:</b> da -5.0 a +5.0

<b>Brilliance</b> [BRILLIANCE]	Brillantezza del suono. Con un valore pari a 0 si ottiene un suono perfettamente bilanciato. Con valori negativi si ottiene un'enfatizzazione dei bassi ed un'attenuazione degli alti, di conseguenza il suono risulta meno brillante. Con valori positivi si ottiene un'enfatizzazione degli alti ed un'attenuazione dei bassi così da rendere il suono sempre più brillante <b>Impostazioni:</b> da -5.0 a +5.0
-----------------------------------	--

## Sezione CLAVI

Il menù CLAVI raccoglie i parametri di configurazione del modulo CLAVI (descritto a pagina 13).

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *CLAVI* e premere il dial data entry, oppure tenere premuta per qualche istante uno dei due pulsanti [Clavi 1] o [Clavi 2] (punto 6 a pagina 14).



### NOTA

Nella tabella a seguire sono riportati tutti i parametri disponibili per il modulo CLAVI. Sotto il nome del parametro è riportata la manopola o pulsante che ne permette il controllo diretto da pannello.

Nome parametro	Descrizione
<b>Timbre</b> [Clav 1] [Calv 2]	Nome del timbro selezionato. Sono disponibili i due modelli più famosi del piano elettrico Clavinet. Con l'applicazione <i>Legend '70s Editor</i> è possibile modificare i timbri selezionati. Le modifiche apportate da questa applicazione hanno effetto su tutti i Program. <b>Impostazioni:</b> Clavi 1 (modello D6), Clavi 2 (modello E7)
<b>Switch Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Stessa funzione dei parametri descritti a pagina 42.
<b>Brilliant Control</b> [BRILLIANT]	Attivazione / disattivazione del filtro passa-alto che rende il suono molto brillante. <b>Impostazioni:</b> OFF, ON
<b>Treble Control</b> [TREBLE]	Attivazione / disattivazione del filtro passa-banda molto ricco sulle alte frequenze. <b>Impostazioni:</b> OFF, ON
<b>Medium Control</b> [MEDIUM]	Attivazione / disattivazione del filtro passa-basso con frequenza di taglio sulle medie frequenze. <b>Impostazioni:</b> OFF, ON
<b>Soft Control</b> [SOFT]	Attivazione / disattivazione del filtro passa-basso che rende il suono molto chiuso. <b>Impostazioni:</b> OFF, ON
<b>C D Control</b> [C D]	Configurazione dei pickup. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>C:</b> attivazione di un singolo pickup.</li> <li>• <b>D:</b> attivazione di entrambi i pickup.</li> </ul>
<b>A B Control</b> [A B]	Configurazione dei pickup. <ul style="list-style-type: none"> <li>▪ <b>Se il parametro C D = C</b> Selezione del pickup.               <ul style="list-style-type: none"> <li>• <b>A:</b> pickup basso</li> <li>• <b>B:</b> pickup alto</li> </ul> </li> <li>▪ <b>Se il parametro C D = D</b> Selezione della fase.               <ul style="list-style-type: none"> <li>• <b>A:</b> pickup in fase</li> <li>• <b>B:</b> pickup in controfase</li> </ul> </li> </ul> <b>NOTA</b> In base alle combinazioni dei parametri C D Control e A B Control è possibile ottenere 4 diverse tonalità dello strumento. Per maggiori informazioni consultare il punto 4 a pagina 14.

<b>Mute</b>	Attivazione / disattivazione del filtro smorzatore. <b>Impostazioni:</b> OFF, ON
<b>Mute Value</b>	Posizione massima del felto smorzatore (Sliding Damper) che permette di diminuire il tempo di decadimento del suono. <b>Impostazioni:</b> da 30 a 127

## Sezione SOUND COLLECTION

Il menù SOUND COLLECTION raccoglie i parametri di configurazione del modulo SOUND COLLECTION (descritto a pagina 14).


Il modulo SOUND COLLECTION mette a disposizione due parti indipendenti, che possono essere richiamate utilizzando i pulsanti [1] o [2] del pannello principale. La videata mostra la parte selezionata nell'intestazione del menu, indicata dal numero [1] o [2], e il valore dei parametri della parte.

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo SOUND COLLECTION e premere il dial data entry, oppure tenere premuta per qualche istante la manopola di selezione della tipologia di suoni del modulo (punto 4 a pagina 15).


**NOTA**

Nella tabella a seguire sono riportati tutti i parametri disponibili per il modulo SOUND COLLECTION. Sotto il nome del parametro è riportata la manopola o pulsante che ne permette il controllo diretto da pannello.

Nome parametro	Descrizione
<b>Category</b> [category selector]	Tipologia del timbro selezionato. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>Pad:</b> pad sintetizzati.</li> <li>• <b>Strings:</b> strumenti ad arco, acustici o sintetizzati.</li> <li>• <b>Choir:</b> cori.</li> <li>• <b>Brass:</b> ottoni, acustici o sintetizzati.</li> <li>• <b>Keys:</b> pianoforti acustici ed elettronici, sintetizzatori, fisarmoniche.</li> <li>• <b>Organ:</b> organi elettromeccanici, elettrici e a canne.</li> <li>• <b>Bass:</b> bassi acustici, elettrici e sintetizzati.</li> <li>• <b>Others:</b> strumenti di diverse tipologie.</li> </ul>
<b>Timbre</b> [timbre selector]	Timbro della tipologia selezionata. Il numero dei timbri varia in funzione della tipologia selezionata con il parametro Category.  <b>NOTA</b> Per la lista completa dei suoni disponibili si rimanda alla tabella Lista dei suoni SOUND COLLECTION a pag. 66.
<b>Switch</b> <b>Volume</b> <b>Output Routing</b> <b>Reverb Send</b> <b>Note Shift</b> <b>Detune</b> <b>Velocity Sens</b> <b>Pitch Bend</b> <b>Mod.Wheel</b> <b>Sustain Pedal</b> <b>Foot Switch1</b> <b>Foot Switch2</b> <b>Foot Control1</b> <b>Foot Control2</b>	Stessa funzione dei parametri descritti a pagina 42.

<b>[parametro 1]</b> <b>[KNOB 1]</b> <b>[parametro 2]</b> <b>[KNOB 2]</b> <b>[parametro 3]</b> <b>[KNOB 3]</b>	<p>Parametri principali di generazione sonora del suono selezionato. I tre parametri disponibili dipendono dal suono selezionato e vengono descritti di seguito:</p> <ul style="list-style-type: none"> <li>• <b>Attack Time:</b> tempo di attacco del suono, impiegato per raggiungere il massimo livello del segnale dopo aver premuto un tasto della tastiera.</li> <li>• <b>Decay Time:</b> tempo di decadimento del suono dopo aver premuto un tasto della tastiera.</li> <li>• <b>Release Time:</b> tempo di decadimento del suono quando si rilascia il tasto della tastiera.</li> </ul>  <ul style="list-style-type: none"> <li>• <b>Filter CutOff:</b> frequenza di taglio del filtro che regola la brillantezza del suono.</li> <li>• <b>Efx Send:</b> livello della mandata all'effetto.</li> <li>• <b>Efx Rate:</b> velocità di modulazione dell'effetto.</li> <li>• <b>Efx Depth:</b> profondità di modulazione dell'effetto.</li> <li>• <b>High Bars:</b> livello del segnale dei drawbar acuti.</li> <li>• <b>Percussion:</b> livello della percussione nell'organo elettromeccanico.</li> <li>• <b>Rotary:</b> attivazione / disattivazione dell'effetto Rotary che simula il classico amplificatore con diffusori rotanti utilizzato con l'organo elettromeccanico.</li> <li>• <b>Vibrato Depth:</b> profondità di modulazione dell'effetto di vibrato.</li> </ul>
---	---

## Sezione EXTERNAL

Il menù *EXTERNAL* raccoglie i parametri di configurazione del modulo *EXTERNAL* (descritto a pagina 15).

Il modulo *EXTERNAL* mette a disposizione due parti indipendenti, che possono essere richiamate utilizzando i pulsanti [1] o [2] del pannello principale. La sezione *EXTERNAL* è sempre presente nel Program, indipendentemente dalla presenza o meno del modulo *EXTERNAL* all'interno dello strumento. Quando il modulo *EXTERNAL* non è presente, è possibile richiamare la parte [1] o [2] della sezione premendo i pulsanti [SET 1] o [SET 2] del pannello principale.

Per accedere a questo menu, nella videata *EDIT PROGRAM* (pag. 28) posizionare il cursore sul campo *EXTERNAL* e premere il dial data entry, oppure tenere premuta per qualche istante la manopola di selezione dei messaggi o funzioni MIDI (punto 4 a pagina 16).

**EXTERNAL [1]** 3/21  
**Output Port:**  
**USB**

### NOTA

Nella tabella a seguire sono riportati tutti i parametri disponibili per il modulo *EXTERNAL*. Sotto il nome del parametro è riportata la manopola o pulsante che ne permette il controllo diretto da pannello.

Nome parametro	Descrizione
<b>Switch</b> [ON/OFF]	Stessa funzione del parametro descritto a pagina 42.
<b>Volume</b> [VOLUME]	Valore del messaggio MIDI di Volume (Control Change 7) trasmesso. <b>Impostazioni:</b> da 0 a 127
<b>Output Port</b> [VALUE]	Porta di trasmissione dei dati MIDI. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettori del messaggio/funzione MIDI è posizionato su Port. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>MIDI:</b> connettore MIDI [OUT].</li> <li>• <b>USB:</b> connettore USB [TO HOST].</li> </ul>
<b>Channel</b> [VALUE]	Canale MIDI di trasmissione dei dati MIDI. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettori del messaggio/funzione MIDI è posizionato su Channel. <b>Impostazioni:</b> da 1 a 16

<b>Note Shift</b>	Stessa funzione dei parametri descritti a pagina <a href="#">42</a> .
<b>Pitch Bend</b>	
<b>Mod.Wheel</b>	
<b>Sustain Pedal</b>	
<b>Foot Switch1</b>	
<b>Foot Switch2</b>	
<b>Foot Control1</b>	
<b>Foot Control2</b>	
<b>Program Change [VALUE]</b>	Trasmissione del messaggio di Program Change. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettore del messaggio/funzione MIDI è posizionato su Program. <b>Impostazioni:</b> da 0 a 127
<b>Bank Select MSB [VALUE]</b>	Trasmissione del messaggio di Bank Select MSB. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettore del messaggio/funzione MIDI è posizionato su Bank MSB. <b>Impostazioni:</b> da 0 a 127
<b>Bank Select LSB [VALUE]</b>	Trasmissione del messaggio di Bank Select LSB. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettore del messaggio/funzione MIDI è posizionato su Bank LSB. <b>Impostazioni:</b> da 0 a 127
<b>Ctrl 1 CC</b> <b>Ctrl 2 CC</b> <b>Ctrl 3 CC</b> <b>[VALUE]</b>	Control Change assegnato alle manopole [CTRL 1], [CTRL 2] e [CTRL 3]. La regolazione è fattibile anche con il controllo [VALUE] del modulo quando il selettore del messaggio/funzione MIDI è posizionato su Ctrl 1 CC, Ctrl 2 CC e Ctrl 3 CC. <b>Impostazioni:</b> da 0 a 127
<b>Ctrl 1 Value</b> <b>[CTRL 1]</b> <b>Ctrl 2 Value</b> <b>[CTRL 2]</b> <b>Ctrl 3 Value</b> <b>[CTRL 3]</b>	Valore del Control Change assegnato alle manopole [CTRL 1], [CTRL 2] e [CTRL 3] e da trasmettere al richiamo del Program. La regolazione è fattibile anche con le manopole di cui sopra. <b>Impostazioni:</b> da 0 a 127

## MODALITA' SONG

La modalità Song permette di selezionare gruppi di 4 Program che possono essere richiamati velocemente, indipendentemente dalla locazione in cui sono salvati, senza la necessità quindi di scorrere tutte le locazioni. È possibile selezionare la modalità Song premendo il pulsante [SONG MODE]/[SYSTEM]: il Led si accende a luce fissa ed il display visualizza l'ultima Song selezionata. La videata presenta i seguenti campi:



### 1 Numero della Song.

Indica il numero della Song selezionata.

### 2 Nome della Song.

Il nome della Song è assegnabile in fase di memorizzazione (pagina 50).

### 3 Numero della List.

Indica il numero della List selezionata.


### 4 Program nella Song.

In questa sezione del display vengono visualizzati i Program inseriti nella Song corrente, indicati dal banco (la lettera) e la locazione (il numero). Il Program corrente viene indicato dal rettangolo in reverse.

Per tornare alla modalità Program premere il pulsante [SONG MODE]/[SYSTEM] oppure [EXIT].

## Cosa è una Song

La modalità Song permette di creare gruppi di 4 Program raggruppandoli, per esempio, in base al tipo di strumenti, al genere musicale o al concerto che si deve eseguire e di richiamarli rapidamente senza la necessità di scorrere le locazioni dei Program per cercare quello desiderato come occorrerebbe fare in modalità Program. È inoltre possibile creare liste di 40 Song (List), sino ad una massimo di 9 List, per una ancora più ampia possibilità di combinazioni.



## Selezione di una Song

Per selezionare le Song utilizzare il dial data entry. Ruotandolo in senso orario viene selezionata la Song successiva. Ruotandolo in senso antiorario si seleziona la precedente.

### SEQUENZA DI SELEZIONE DELLE SONG

...SNG 39 ← SNG 40 ← **SNG 01** → SNG 02 → ...SNG 40 → SNG 01...

Dopo aver selezionato una Song viene caricato il primo Program inserito nella stessa.

La selezione delle Song avviene nella videata principale della modalità Song, in cui vengono visualizzati il numero ed il nome. Per selezionare un altro Program utilizzare i pulsanti [<] o [>] oppure i pulsanti [SET],

durante la selezione il display visualizza temporaneamente il nome del nuovo Program nella sezione in cui viene normalmente riportato il nome della Song.

E' altresì possibile selezionare i Program con i pedali collegati alla presa PEDAL [PROGRAM + / -] del pannello posteriore.

Per selezionare una List tenendo premuto il pulsante [EXIT] premere [<] o [>] oppure utilizzare la funzione *LISTS* (pag. 53).

In base all'impostazione di sistema *Confirm Program* (pag. 58) una Song o un Program in essa contenuto possono essere caricati immediatamente oppure al momento desiderato tramite la pressione del dial data entry. In questo caso la locazione del Program lampeggia sino alla pressione del dial.

**NOTA**

*È importante notare che le Song non contengono copie dei Program ed i loro dati. Ciò significa che se un Program viene modificato e memorizzato, tutte le Song che lo contengono faranno uso del Program modificato.*

## Memorizzazione di una Song

Per rendere definitive le modifiche apportate ad una Song così da non perderle selezionandone un'altra o spegnendo lo strumento, è necessario memorizzare la Song. La procedura di memorizzazione prevede anche l'assegnazione di un nuovo nome alla Song, così come il salvataggio della locazione corrente od in un'altra locazione (numero), così da non sovrascrivere quella corrente.

Per memorizzare la Song, seguire questa procedura:

1. Assicurarsi che non sia selezionata la modalità Program, in caso contrario premere il pulsante [SONG MODE]/[SYSTEM].
2. Tenere premuto per qualche istante il pulsante [EDIT]/[STORE] per richiamare la funzione di STORE. Il led del pulsante inizia a lampeggiare e viene visualizzata la videata:
3. Premere il dial data entry od il pulsante [EDIT]/[STORE] per confermare il nome della Song, altrimenti comporre il nuovo nome. Utilizzare i pulsanti [<] o [>] per muovere il cursore (indicato dal carattere evidenziato) e ruotare il dial data entry per selezionare il carattere desiderato. La parte inferiore del display mostra tutti i caratteri disponibili per la composizione del nome della Song.




Tenendo premuto il pulsante [EXIT] e premendo [>] è possibile inserire un carattere prima di quello selezionato.

Tenendo premuto [EXIT] e premendo [<], invece, viene cancellato il carattere selezionato.

Una volta composto il nome della Song premere il dial data entry od il pulsante [EDIT]/[STORE] per continuare, oppure [EXIT] per annullare.

4. Premere il dial data entry od il pulsante [EDIT]/[STORE] per sovrascrivere la locazione della Song corrente, altrimenti selezionare la nuova locazione utilizzando il dial data entry. Utilizzare i pulsanti [<] o [>] per cambiare banco. Durante la selezione della locazione il display mostra il nome della Song di destinazione. Per confermare la memorizzazione premere il dial data entry od il pulsante [EDIT]/[STORE], oppure premere [EXIT] per annullare.


**NOTA**

Sovrascrivendo una Song, sia essa della locazione corrente o di un'altra locazione, i dati in essa contenuti vengono persi. Per evitare ciò è possibile salvare su un'unità flash USB tutte le impostazioni correnti da ricaricare quando necessario, evitando così perdite di dati. Per maggiori informazioni consultare la funzione Backup All a pagina 60.

E' inoltre possibile ripristinare in qualsiasi momento tutte le impostazioni di fabbrica dello strumento. Per maggiori informazioni consultare la funzione Factory Reset a pagina 61.

## MODIFICA DI UNA SONG O LIST

Premendo il pulsante [EDIT] quando il display visualizza la modalità Song è possibile accedere a tutti i parametri di programmazione della Song corrente.

Il menu principale di *EDIT SONG* raccoglie le funzioni di programmazione di una Song ed è composto dai seguenti campi:



**1 Nome del menu.**

Indica che ci si trova nella pagina principale del menu *EDIT SONG*.

**2 Numero della pagina.**

Informa quale pagina si sta visualizzando tra quelle previste dal menu (ad esempio “1/3” indica che ci si trova nella prima pagina delle tre previste). L’indicazione “1/1” informa che ci si trova nell’unica pagina prevista.

**3 Funzioni.**

Posizionando con i pulsanti [<] o [>] il cursore su questi campi e premendo il dial data entry è possibile accedere alle funzioni di modifica delle Song e delle List. Queste funzioni sono:


Campo a display	Descrizione
<b>PARTS</b>	Assegnazione dei Program alle parti della Song corrente.
<b>ORDER</b>	Ordinamento delle Song all’interno della List corrente.
<b>COPY/PASTE</b>	Copia di una Song all’interno della List corrente e copia dell’intera List.
<b>LISTS</b>	Selezione delle List.

Premere [EXIT] o [EDIT]/[STORE] per tornare a visualizzare la videata principale della modalità Song.

## Funzione PARTS

La funzione *Parts* permette di assegnare i Program alle 4 parti della Song. La parte di una Song può essere considerata come la locazione in cui inserire il Program. Per accedere a questa funzione, nella videata *EDIT SONG* posizionare il cursore sul campo *PARTS* e premere il dial data entry.

La videata presenta i seguenti campi:



**1 Nome della funzione.**

Indica che ci si trova nella funzione *Parts*.

**2 Nome del Program.**

Riporta il nome del Program assegnato alla parte selezionata.

**3 Parte selezionata e Program inseriti nelle parti.**

Visualizza la parte selezionata, indicata dal rettangolo in reverse, ed i Program delle parti della Song corrente, identificati dalla lettera del banco e dal numero della locazione.

Per selezionare la parte a cui si desidera assegnare un Program, utilizzare i pulsanti [<] o [>]. Per assegnare un nuovo Program alla parte ruotare l’encoder data entry.

## Funzione ORDER

La funzione Order permette di spostare la posizione di una Song all'interno della List corrente. Per accedere a questa funzione, nella videata *EDIT SONG* posizionare il cursore sul campo *ORDER* e premere il dial data entry.

La videata presenta i seguenti campi:

**1 Nome della funzione.**

Indica che ci si trova nella funzione Order ed il nome della List che si sta modificando.



**2 Numero della Song.**

Indica il numero della Song selezionata per lo spostamento.

**3 Nome della Song.**

Indica il nome della Song selezionata per lo spostamento.

**4 Numero della pagina.**

Indica la pagina corrente visualizzata e il numero totale delle pagine della lista.

Per spostare una Song all'interno della List, seguire questa procedura:

1. Utilizzando il dial data entry o i pulsanti [<] o [>] posizionare il cursore sul campo della Song che si desidera spostare.
2. Premere il dial data entry, vengono visualizzate due frecce ad indicare che ora è possibile cambiare posizione della Song.
3. Spostare la posizione della Song utilizzando il dial data entry o i pulsanti [<] o [>].
4. Premere il dial data entry per confermare la nuova posizione.

E' possibile inserire una nuova Song, denominata "Init Song", all'interno di una List. Per fare ciò, seguire questa procedura:

1. Utilizzando il dial data entry o i pulsanti [<] o [>] posizionare il cursore sul campo della lista in cui si desidera inserire la nuova Song.
2. Premere contemporaneamente i pulsanti [EXIT] e [>] per inserire la "Init Song" nella posizione corrente. Tutte le Song a partire da quella selezionata vengono spostate in avanti di una posizione.
3. Modificare la "Init Song" utilizzando la funzione *Parts* vista in precedenza.

E' possibile eliminare una Song dalla List. Per fare ciò, seguire questa procedura:

1. Utilizzando il dial data entry o i pulsanti [<] o [>] posizionare il cursore sul campo della Song che si desidera eliminare dalla List.
2. Premere contemporaneamente i pulsanti [EXIT] e [<] per eliminare la Song dalla posizione corrente. Tutte le Song successive a quella rimossa vengono spostate indietro di una posizione.

## Funzione COPY/PASTE

La funzione Copy/Paste permette di copiare una Song in altre posizioni della List, oppure tutte le Song di una List in un'altra. La procedura si compone di due fasi: nella prima fase, denominata *Copy From*, viene selezionata la Song che si desidera copiare, mentre nella seconda fase, denominata *Paste To*, viene scelta la posizione in cui copiare la Song.

Per accedere a questa funzione, nella videata *EDIT SONG* posizionare il cursore sul campo *COPY/PASTE* e premere il dial data entry.



La prima videata riguarda la fase COPY FROM e presenta i seguenti campi:

**1 Fase corrente della funzione COPY/PASTE.**

Indica che ci si trova nella fase *Copy From*.

**2 Numero della List.**

Indica il numero della List da cui copiare la Song.

**3 Numero della Song.**

Indica il numero della Song da copiare.

**4 Nome della Song.**

Indica il nome della Song da copiare.

Per copiare una o tutte le Song, seguire questa procedura:

- Utilizzando i pulsanti [<] o [>] selezionare la List da cui si desidera copiare una Song. Per copiare tutte le Song di una List, selezionare la voce "ALL".

**SEQUENZA DI SELEZIONE DELLE LIST**

...LIST9:SNG 01 ← **LIST1:SNG 01** → LIST2:SNG 01...

- Utilizzando il dial data entry selezionare il numero della Song che si desidera copiare.

**SEQUENZA DI SELEZIONE DELLE SONG**

...LIST1:SNG 40 ← LIST1:ALL ← **LIST1:SNG 01** → LIST1:SNG 02 → ...LIST1:ALL...

- Premere il dial data entry per confermare la selezione della Song da copiare, viene così visualizzata la videata relativa alla fase *Paste To*. La procedura di selezione della posizione in cui si desidera copiare la Song è analoga a quella della fase *Copy From*, descritta al punto 1 e 2. Nel caso in cui si è scelto di copiare tutte le Song di una List, nella fase *Paste To* è possibile selezionare la List di destinazione (da *LIST1:ALL* a *LIST9:ALL*).

- Premere il dial data entry per effettuare la copia o [EXIT] per annullarla.

## Funzione LISTS

La funzione *Lists* permette di selezionare la List corrente delle Song. Per accedere a questa funzione, nella videata *EDIT SONG* posizionare il cursore sul campo *LISTS* e premere il dial data entry.

La videata presenta i seguenti campi:

**1 Nome della funzione.**

Indica che ci si trova nella funzione *Lists*.

**2 Numero della List.**

Indica la List al momento selezionata.



Per selezionare la lista desiderata utilizzare il dial data entry o i pulsanti [<] o [>]. Per confermare la nuova selezione premere il dial data entry, per annullare premere il pulsante [EXIT].

## MENU SYSTEM

Il menu **SYSTEM** permette di impostare i parametri che interessano l'intero strumento. Tutte le impostazioni fatte in **SYSTEM** vengono immediatamente eseguite e rimangono memorizzate sino ad una nuova modifica o al richiamo di un Factory Reset.

Per accedere ai parametri System, tenere premuto per qualche istante il pulsante [SONG MODE]/[SYSTEM], viene visualizzato il menu principale della modalità System, composto dai seguenti campi:



**1 Nome del menu.**

Indica che ci si trova nella pagina principale del menu **SYSTEM**.

**2 Numero della pagina.**

Indica la pagina corrente visualizzata e il numero totale delle pagine del menu (ad esempio "1/2" indica che ci si trova nella prima pagina delle due previste).

**3 Sottomenu.**

Posizionando con i pulsanti [<] o [>] od il dial data entry il cursore su uno di questi campi e premendo il dial è possibile accedere ai menu che contengono i parametri di impostazione dello strumento. Questi menu sono:

Campo a display	Descrizione
KEYBOARD	Parametri di impostazione della tastiera.
EQUALIZER	Parametri di impostazione dell'equalizzatore generale.
MIDI SETTINGS	Impostazioni relative l'interfaccia MIDI.
PEDAL SETUP	Parametri di configurazione dei pedali collegati.
PREFERENCES	Funzioni di personalizzazione dello strumento.
UTILITY	Configurazione dei moduli, salvataggio/caricamento dei dati, Factory Reset, aggiornamento del sistema operativo.

Premere [EXIT] o [SONG MODE]/[SYSTEM] per tornare alla modalità Program o alla modalità Song.

La videata presenta i seguenti campi:

**1 Nome del sottomenu.**

Indica in quale sezione del menu **SYSTEM** ci si trova.

**2 Numero della pagina.**

Indica la pagina corrente visualizzata e il numero totale delle pagine del menu (ad esempio "1/4" indica che ci si trova nella prima pagina delle quattro previste).



**3 Nome del parametro.**

Indica il nome del parametro che si sta modificando.

**4 Valore del parametro.**

Indica il valore assegnato al parametro.

Utilizzando i pulsanti [<] o [>] è possibile scorrere tutti i parametri del menu. Per la regolazione del valore, ruotare il dial data entry.

Per abbandonare un sottomenu e tornare al menu **SYSTEM**, premere il pulsante [EXIT]. Premere invece [SONG MODE]/[SYSTEM] per tornare direttamente alla modalità Program o alla modalità Song.


## Sezione KEYBOARD

Il menù **KEYBOARD** contiene i parametri globali relativi alla tastiera dello strumento. Per accedere a questo menu, nella videata **SYSTEM** posizionare il cursore sul campo **KEYBOARD** e premere il dial data entry.

Nome parametro	Descrizione
<b>Transpose</b>	Trasposizione generale dello strumento per semitonni. <b>Impostazioni:</b> da -12 a +12 semitonni  <b>NOTA</b> <i>La trasposizione viene visualizzata anche nella videata principale con il campo T.</i>
<b>Fine Tuning</b>	Accordatura generale dello strumento espressa in centesimi di semitonni ed in Hertz. <b>Impostazioni:</b> da -50 a +50 / da 427.5 a 452.9 dB
<b>Velocity Curve</b>	Curve di risposta della tastiera al tocco. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li><b>Hard1</b> e <b>Hard2</b>: curve con cui è difficile raggiungere alti valori di dinamica. La 2 è più dura della 1.</li> <li><b>Normal</b>: curva standard che produce valori di dinamica direttamente proporzionale alla forza con cui viene suonata la tastiera.</li> <li><b>Soft1</b> e <b>Soft2</b>: curve morbide con cui è facile raggiungere alti valori di dinamica. La 2 è più morbida della 1.</li> <li><b>Fixed</b>: curva fissa che produce sempre lo stesso valore di dinamica, impostato con il parametro <i>Fixed Velocity</i>, indipendentemente dalla forza impressa sui tasti.</li> </ul>
<b>Fixed Velocity</b>	Valore di dinamica trasmesso nel caso sia selezionata la curva Fixed con il parametro <i>Velocity Curve</i> . <b>Impostazioni:</b> da 1 a 127  <b>NOTA</b> <i>Quando il parametro Velocity Curve è diverso da Fixed il parametro Fixed Velocity non può essere regolato ed il valore viene visualizzato come “---”.</i>

## Sezione EQUALIZER

Il menù **EQUALIZER** contiene i parametri di impostazione dell'equalizzatore generale dello strumento (vedi punto 2 a pagina 8). Per accedere a questo menu, nella videata **SYSTEM** posizionare il cursore sul campo **EQUALIZER** e premere il dial data entry.

Nome parametro	Descrizione
<b>Filter Type</b>	Tipo di filtro relativo alle bande LOW e HIGH. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li><b>Shelving</b>: vengono esaltati o attenuati i segnali a tutte le frequenze sotto (banda LOW) o sopra (banda HIGH) la frequenza specificata.</li> <li><b>Peaking</b>: vengono esaltati o attenuati i segnali intorno alla frequenza centrale di ogni banda.</li> </ul>  <p><b>NOTA</b> <i>La banda MID utilizza sempre un filtro di tipo Peaking.</i></p>
<b>Low Freq</b>	Frequenza centrale della banda LOW. <b>Impostazioni:</b> da 60 a 250 Hz
<b>Low Q</b>	Larghezza della campana del filtro della banda LOW la cui frequenza centrale è definita con il parametro <i>Low Freq</i> . A valori elevati corrisponde una campana più ristretta di frequenze e il suono cambia nettamente intorno alla frequenza centrale. A valori ridotti, viene esaltata od attenuata una banda più ampia di frequenze e il suono cambia più gradualmente intorno alla frequenza centrale.

	<b>Impostazioni:</b> da 0.5 a 4.0  <b>NOTA</b> Questo parametro è disponibile solo con Filter Type: Peaking.
<b>Mid Freq</b>	Frequenza centrale della banda MID. <b>Impostazioni:</b> da 250 a 2500 Hz
<b>Mid Q</b>	Larghezza della campana del filtro della banda MID la cui frequenza centrale è definita con il parametro <i>Mid Freq</i> . Il funzionamento di questo parametro è identico a quanto descritto per il parametro <i>Low Q</i> . <b>Impostazioni:</b> da 0,5 a 4.0
<b>High Freq</b>	Frequenza centrale della banda HIGH. <b>Impostazioni:</b> da 250 a 2500 Hz
<b>High Q</b>	Larghezza della campana del filtro della banda HIGH la cui frequenza centrale è definita con il parametro <i>High Freq</i> . Il funzionamento di questo parametro è identico a quanto descritto per il parametro <i>Low Q</i> . <b>Impostazioni:</b> da 0,5 a 4.0  <b>NOTA</b> Questo parametro è disponibile solo con Filter Type: Peaking.

## Sezione MIDI

Il menu *MIDI* consente di modificare le impostazioni MIDI generali dello strumento.

Per accedere a questo menu, nella videata *SYSTEM* posizionare il cursore sul campo *MIDI SETTINGS* e premere il dial data entry.

Nome parametro	Descrizione
<b>Control Port</b>	Porta di trasmissione e ricezione dei messaggi di controllo dello strumento, come gli eventi di tastiera, i pedali, le ruote e i controlli a pannello. <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>OFF:</b> non viene trasmesso e ricevuto nessun messaggio di controllo.</li> <li>• <b>USB:</b> i messaggi di controllo vengono trasmessi e ricevuti dal connettore USB [TO HOST] presente nel pannello posteriore.</li> <li>• <b>MIDI:</b> i messaggi di controllo vengono trasmessi dal connettore MIDI [OUT] e ricevuti dal connettore MIDI [IN] presenti nel pannello posteriore.</li> </ul>
<b>Global Channel</b>	Canale MIDI di trasmissione e ricezione dei messaggi di controllo dello strumento. <b>Impostazioni:</b> da 1 a 16
<b>Local Control</b>	Abilitazione della trasmissione degli eventi di tastiera, del pannello e dei pedali alla generazione sonora interna dello strumento. E' consigliabile impostare su OFF questa funzione quando lo strumento è collegato via USB ad un computer con la funzione Thru attivata (che quindi ritrasmette i dati al <i>Legend '70s</i> ) al fine di evitare note doppie e loop MIDI. <b>Impostazioni:</b> OFF, ON  <b>NOTA</b> La trasmissione e ricezione degli eventi MIDI sulla porta MIDI e USB dipende dalla impostazione del parametro <i>Control Port</i> , visto in precedenza.
<b>Tx/Rx Program</b>	Abilitazione della trasmissione e ricezione dei messaggi MIDI di Bank Select e Program Change (associati al cambio dei Program) attraverso la porta di controllo. <b>Impostazioni:</b> OFF, ON
<b>Tx/Rx CC</b>	Abilitazione della trasmissione e ricezione dei messaggi MIDI di Control Change (associati alla variazione dei controlli) attraverso la porta di controllo. <b>Impostazioni:</b> OFF, ON
<b>Soft Thru</b>	Ritrasmissione dei messaggi MIDI ricevuti dal <i>Legend '70s</i> . <b>Impostazioni:</b> <ul style="list-style-type: none"> <li>• <b>OFF:</b> non viene ritrasmesso nessun messaggio MIDI.</li> <li>• <b>MidiIn&gt;MidiOut:</b> i messaggi ricevuti dal connettore MIDI [IN] vengono ritrasmessi dal connettore MIDI [OUT].</li> <li>• <b>MidiIn&gt;USB:</b> i messaggi ricevuti dal connettore MIDI [IN] vengono ritrasmessi dal connettore USB [TO HOST].</li> <li>• <b>USB&gt;MidiOut:</b> i messaggi ricevuti dal connettore USB [TO HOST] vengono ritrasmessi dal connettore MIDI [OUT].</li> </ul>

### NOTA

Per la descrizione dettagliata dei messaggi MIDI trasmessi e ricevuti da *Legend '70s* consultare la sezione MIDI Informations a pagina MIDI - 1.

## Sezione PEDAL SETUP

Il menù *PEDAL SETUP* contiene i parametri di impostazione dei pedali collegati ai jack PEDAL presenti nel pannello posteriore. Per accedere a questo menu, nella videata *SYSTEM* posizionare il cursore sul campo *PEDAL SETUP* e premere il dial data entry.

Nome parametro	Descrizione
<b>Sustain Type</b>	<p>Tipo di pedale collegato al connettore PEDAL [SUSTAIN].</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Half-Damper:</b> pedale di sustain continuo per utilizzare la tecnica del mezzo pedale.</li> <li>• <b>Switch:</b> foot switch.</li> <li>• <b>Triple:</b> triplo pedale Studiologic SLP-3D.</li> </ul>
<b>Sustain Polarity</b>	<p>Polarità del pedale collegato al connettore PEDAL [SUSTAIN].</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> la polarità viene automaticamente riconosciuta all'accensione dello strumento.</li> <li>• <b>Open</b> (con <i>Sustain Type: Switch</i>): pedale con contatto normalmente aperto (N.O.).</li> <li>• <b>Closed</b> (con <i>Sustain Type: Switch</i>): pedale con contatto normalmente chiuso (N.C.).</li> <li>• <b>Type1</b> (con <i>Sustain Type: Half-Damper</i>): pedale tipo Yamaha FC3A.</li> <li>• <b>Type2</b> (con <i>Sustain Type: Half-Damper</i>): pedale tipo Roland DP-10.</li> </ul> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>- <i>Non premere il pedale all'accensione dello strumento e quando si seleziona la polarità.</i></li> <li>- <i>Questo parametro non ha influenza nel caso Sustain Type è impostato come Triple.</i></li> </ul>
<b>Sustain Range</b>	<p>Posizione e range di copertura del pedale collegato al connettore PEDAL [SUSTAIN]. Tramite questa videata è inoltre possibile calibrare il pedale di sustain (pag. 58).</p> <p><b>Impostazioni:</b> da 0 a 100%</p>
<b>FS1 Polarity</b> <b>FS2 Polarity</b>	<p>Polarità del foot switch collegato ai connettori PEDAL [FOOT SWITCH 1] e [FOOT SWITCH 2].</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> la polarità viene automaticamente riconosciuta all'accensione.</li> <li>• <b>Open:</b> pedale con contatto normalmente aperto (N.O.).</li> <li>• <b>Closed:</b> pedale con contatto normalmente chiuso (N.C.).</li> </ul> <p><b>NOTE</b></p> <p><i>Non premere il pedale all'accensione dello strumento e quando si seleziona la polarità.</i></p>
<b>FC1 Type</b> <b>FC2 Type</b>	<p>Tipo di foot controller collegato ai connettori PEDAL [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2].</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Type1:</b> pedale con connettore RTS, tipo Yamaha FC7.</li> <li>• <b>Type2:</b> pedale con connettore TRS, tipo Fatar VP/25.</li> </ul> <div style="text-align: center;"> <p><b>TYPE 1</b></p> <p><b>TYPE 2</b></p> </div>
<b>FC1 Range</b> <b>FC2 Range</b>	<p>Posizione e range di copertura del foot controller collegato ai connettori PEDAL [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2]. Tramite questa videata è inoltre possibile calibrare il foot controller (pag. 58).</p> <p><b>Impostazioni:</b> da 0 a 100%</p>
<b>Prog +/- Polarity</b>	<p>Polarità del foot switch a due pulsanti collegato al connettore PEDAL [PROGRAM + / -].</p> <p><b>Impostazioni:</b></p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> la polarità viene automaticamente riconosciuta all'accensione dello strumento.</li> <li>• <b>Open:</b> pedale con contatto normalmente aperto (N.O.).</li> <li>• <b>Closed:</b> pedale con contatto normalmente chiuso (N.C.).</li> </ul> <p><b>NOTA</b></p> <ul style="list-style-type: none"> <li>- <i>Utilizzando un pedale a due pulsanti con polarità diverse, selezionare l'impostazione Auto.</i></li> <li>- <i>Non premere il pedale all'accensione dello strumento e quando si seleziona la polarità.</i></li> </ul>

<b>Prog +/- Type</b>	Modalità di funzionamento del foot switch a due pulsanti collegato al connettore PEDAL [PROGRAM + / -]. <b>Impostazioni:</b> <ul style="list-style-type: none"><li>• <b>Normal:</b> il pulsante destro esegue la funzione PROGRAM +, il pulsante sinistro esegue la funzione PROGRAM -.</li><li>• <b>Inverted:</b> il pulsante destro esegue la funzione PROGRAM -, il pulsante sinistro esegue la funzione PROGRAM +.</li></ul> <b>NOTA</b> <i>Utilizzando un pedale a singolo pulsante tramite questa impostazione è possibile scegliere se eseguire la funzione PROGRAM + o PROGRAM -.</i>
----------------------	--

## Calibrazione dei pedali

Collegando pedali ai connettori PEDAL [SUSTAIN], PEDAL [FOOT CONTROLLER 1] e [FOOT CONTROLLER 2] può essere utile eseguire la calibrazione qualora il range di funzionamento non sia corretto (vedere i parametri *Sustain Range*, *FC1 Range* ed *FC2 Range* del menu *PEDAL SETUP*). Per calibrare il pedale, seguire questa procedura:

1. Visualizzare il parametro *Sustain Range*, *FC1 Range* o *FC2 Range* in base al pedale che si desidera calibrare.
2. Avviare la calibrazione, premendo il dial data entry.
3. Muovere il pedale nella posizione minima e massima, verificando che i campi *MIN* e *MAX* riportino il valore percentuale.
4. Premere il dial data entry per memorizzare la nuova calibrazione (messaggio “Calibration stored!”) o [EXIT] per annullarla (messaggio “Calibration aborted!”).

## Sezione PREFERENCES

Il menù *PREFERENCES* permette di personalizzare alcune funzionalità dello strumento. Per accedere a questo menu, nella videata *SYSTEM* posizionare il cursore sul campo *PREFERENCES* e premere il dial data entry.


Nome parametro	Descrizione
<b>Confirm Prg</b>	Attivazione / disattivazione della richiesta di conferma del caricamento di un Program. Quando impostato su OFF il caricamento del Program viene eseguito immediatamente dopo la selezione. Quando impostato su ON dopo la selezione lo strumento rimane in attesa di conferma che avviene con la pressione del dial data entry. <b>Impostazioni:</b> OFF, ON
<b>All Notes Off</b>	Spegnimento, al cambio Program, di tutte le note. <b>Impostazioni:</b> Enabled, Disabled
<b>Leds Intensity</b>	Luminosità di tutti i Led a pannello. <b>Impostazioni:</b> da 1 a 8
<b>Display Contrast</b>	Contrasto del display OLED. <b>Impostazioni:</b> da 1 a 8
<b>USB to Device</b>	Modalità di funzionamento della porta [USB TO DEVICE]. <b>Impostazioni:</b> <ul style="list-style-type: none"><li>• <b>Flash Drive:</b> per utilizzare un'unità flash USB.</li><li>• <b>Charger:</b> per ricaricare un tablet od uno smartphone. CARICA SEMPRE SE IN CHARGER E' PIU' VELOCE MA NON CI SONO I DATI</li></ul>
<b>USB Audio Level</b>	Livello del segnale USB Audio stereo ricevuto dal connettore [USB TO HOST]. <b>Impostazioni:</b> da 1 a 127
<b>Memory Lock</b>	Blocco della memorizzazione dei Program e delle Song e del caricamento del file di backup per evitare sovrascritture indesiderate. <b>Impostazioni:</b> OFF, ON
<b>Auto Power Off</b>	Regolazione del tempo di inattività prima dello spegnimento automatico dello strumento. <b>Impostazioni:</b> Disabled, 30 min, 120 min

### NOTA

- Quando lo strumento viene spento mediante la funzione Auto Power Off, prima di riaccenderlo è necessario riportare l'interruttore [POWER] nella posizione “0” (OFF), attendere circa 10 secondi, dopodichè posizionare l'interruttore su “1” (ON).
- Tutti i dati non salvati vengono persi quando lo strumento si spegne automaticamente. Per evitare ciò assicurarsi di memorizzare sempre le modifiche che si desidera mantenere.

## MENU UTILITY

Il menu *UTILITY* raccoglie alcune funzioni di utilità che interessano l'intero strumento. Il display mostra i seguenti campi:



**1 Nome del sottomenu.**

Indica che ci si trova nel menu *UTILITY*.

**2 Numero della pagina.**

Indica la pagina corrente visualizzata e il numero totale delle pagine del menu. (ad esempio "1/5" indica che ci si trova nella prima pagina delle cinque previste).

**3 Nome della funzione.**

Indica il nome della funzione che si desidera richiamare. Le funzioni disponibili sono le seguenti:

Campo a display	Descrizione
<b>Identify Modules</b>	Modifica della posizione dei moduli visualizzati a display.
<b>Backup All</b>	Salvataggio dei dati dello strumento in un'unità flash USB.
<b>Restore All</b>	Caricamento dei dati dello strumento da un'unità flash USB.
<b>Factory Reset</b>	Ripristino delle impostazioni di fabbrica.
<b>Version</b>	Versione ed aggiornamento del sistema operativo.

**4 Operazione per richiamare la funzione.**

Indica di premere il dial data entry per avviare la funzione selezionata.

Utilizzando i pulsanti [<] o [>] è possibile scorrere tutte le funzioni del menu. Premere il dial data entry per accedere alla funzione.

Per abbandonare una funzione e tornare al menu *SYSTEM* premere il pulsante [EXIT]. Premere invece [SONG MODE]/[SYSTEM] per tornare direttamente alla modalità Program o alla modalità Song.

## Funzione IDENTIFY MODULES

La funzione *Identify Modules* permette di indicare la posizione dei moduli installati negli slot dello strumento, così che questi vengano visualizzati con la giusta sequenza nella videata principale e nel menu *EDIT PROGRAM*.

Per accedere a questa funzione, nella videata *UTILITY* del menu *SYSTEM* selezionare la voce *Identify Modules* e premere il dial data entry, il display mostra i seguenti campi:



**1 Nome della funzione.**

Indica che ci si trova nella funzione *Identify Modules*.

**2 Numero dello slot.**


Indica lo slot di cui si vuole identificare il modulo.

**3 Nome del modulo.**

Indica il nome del modulo presente nello slot indicato dal punto 2.

Per identificare il modulo installato in ciascuno slot dello strumento, seguire questa procedura:

1. Utilizzando il dial data entry selezionare il modulo attualmente installato nello slot.
2. Premere il dial data entry per confermare e passare allo slot successivo. Premere invece [EXIT] per abbandonare l'operazione e tornare alla videata *UTILITY*.
3. Ripetere le operazioni al punto 1 e 2 per tutti gli slot presenti nello strumento. Al termine della procedura viene visualizzata la videata di conferma in cui vengono riportate le icone dei moduli per una



verifica visuale delle posizioni.

Se il posizionamento è corretto premere il dial data entry per confermare, viene visualizzato il messaggio “Allocation Completed!”. Premere invece [EXIT] per annullare e tornare alla videata *UTILITY*.

**NOTA**

*Nel caso in cui in uno slot dello strumento non sia installato alcun modulo, durante la procedura di identificazione è necessario selezionare per tale slot il valore “empty”.*

## Funzione BACKUP ALL

La funzione *Backup All* permette di memorizzare tutti i dati dello strumento in un'unità flash USB inserita nel connettore USB [TO DEVICE]. I dati vengono memorizzati come file “BACKUP-XX.L7B”, dove XX è un numero progressivo da 01 a 99, nella cartella “Legend'70s\BackUp” dell'unità flash USB.

Per eseguire un salvataggio dei dati, seguire questa procedura:

1. Nella videata *UTILITY* del menu *SYSTEM* selezionare la voce *Backup All* e premere il dial data entry:



2. Utilizzando il dial data entry selezionare il numero di backup desiderato, che corrisponderà al nome del file .L7B e premere il dial data entry, viene visualizzato il messaggio “Executing Backup...”. Qualora nell'unità flash USB sia già presente un file con il nome scelto, viene visualizzato il messaggio “*BACKUP-XX already exists. Overwrite?*” con il quale il sistema chiede se sovrascrivere il file. Premere il dial data entry per confermare o [EXIT] per annullare.
3. La conferma dell'avvenuto salvataggio viene indicato dal messaggio “*Backup Completed!*”

**NOTA**

*Quando un file di backup viene sovrascritto i dati in esso contenuti vengono persi.*

## Funzione RESTORE ALL

La funzione *Restore All* permette di ricaricare tutti i dati dello strumento, memorizzati tramite la funzione *Backup All*, da un'unità flash USB inserita nel connettore USB [TO DEVICE].

Per eseguire un caricamento dei dati, seguire questa procedura:

1. Nella videata *UTILITY* del menu *SYSTEM* selezionare la voce *Restore All* e premere il dial data entry:



2. Utilizzando il dial data entry selezionare il file di backup desiderato tra quelli memorizzati nell'unità USB e premere il dial data entry per procedere con il caricamento. Viene quindi richiesta una conferma a procedere “*Reset all data in internal mem. Are you sure?*” in quanto i dati presenti nella memoria dello strumento verranno irrimediabilmente persi. Premere il dial data entry per confermare o [EXIT] per annullare.
3. Durante il caricamento dei dati viene visualizzato il messaggio “*Executing Restore...*” ed a procedura completata viene visualizzato il messaggio “*Restore Completed!*”

**NOTA**

Per evitare la perdita dei dati dello strumento, prima di effettuare il caricamento si consiglia di eseguire un backup dei dati nell'unità flash USB tramite la funzione Backup All (pag. 60).

## Funzione FACTORY RESET

La funzione Factory Reset esegue il ripristino di tutti i Program, le Song, i parametri di sistema dello strumento alle impostazioni di fabbrica.

Per effettuare un Factory Reset, seguire questa procedura:

1. Nella videata *UTILITY* del menu *SYSTEM* selezionare la funzione *Factory Reset* e premere il dial data entry. Viene richiesta una conferma a procedere “Reset all data in internal mem. Are you sure?” in quanto tutte le modifiche dello strumento verranno irrimediabilmente perse. Premere il dial data entry per confermare o [EXIT] per annullare.
2. Durante il ripristino dei dati di fabbrica viene visualizzato il messaggio “Executing Factory Reset...”. A procedura completata lo strumento viene riavviato automaticamente.

**NOTA**

Per evitare la perdita dei dati dello strumento, prima di effettuare il caricamento si consiglia di eseguire un backup dei dati nell'unità flash USB tramite la funzione Backup All (pag. 60).

## Funzione RELEASE/UPDATE

La funzione *Release/Update* permette di conoscere la versione del sistema operativo attualmente installata sullo strumento e di effettuarne l'aggiornamento. Ogni qualvolta verrà rilasciato un file di aggiornamento (nome del file L70S-XXX.L7U dove XXX indica la versione che verrà installata), questo sarà reso disponibile sul sito web <http://www.viscountinstruments.com>. Dopo aver scaricato il file, copiarlo nella cartella principale (root) di un'unità flash USB.

Per verificare la versione del sistema operativo installata, nella videata *UTILITY* del menu *System* selezionare la voce *Release*:



Per effettuare l'aggiornamento del sistema operativo, seguire questa procedura:

1. Inserire nel connettore USB [TO DEVICE] l'unità flash USB in cui si è copiato il file di aggiornamento.
2. Dalla videata sopra riportata premere il dial data entry, viene visualizzato il nome del file trovato nell'unità flash USB inserita, indicato dal campo *File*:



3. Se si è certi che il file è corretto premere il dial data entry per avviare l'aggiornamento, premere invece [EXIT] per annullare l'operazione. Una volta avviato l'aggiornamento il sistema dapprima verifica l'integrità del file visualizzando il messaggio “Checking update...” dopodichè procede con il suo caricamento, indicato dal messaggio “Updating...” seguito dalla percentuale di avanzamento. Completata l'operazione viene visualizzato il messaggio “Update successful [Turn on/off]”. Spegnere e riaccendere lo strumento.

## Aggiornamento dei moduli installati nello strumento

In aggiunta all'aggiornamento del sistema operativo, è previsto anche l'aggiornamento dei singoli moduli installati nello strumento ogni qualvolta ne sarà reso disponibile il file sul sito web <http://www.viscountinstruments.com>. La procedura di aggiornamento è la medesima di quella del sistema operativo descritta in precedenza, con la differenza che al punto 2 è necessario ruotare il dial data entry sino a visualizzare, al posto della dicitura *Release*, il nome del modulo che si andrà ad aggiornare.

**NOTA IMPORTANTE!**

- *Non estrarre l'unità flash USB o spegnere lo strumento durante l'aggiornamento.*
- *Porre particolare attenzione al fatto che nella root dell'unità flash USB deve essere presente solo un file .L7U o un solo file di aggiornamento di un modulo (es. un solo file .L7A di aggiornamento del modulo A.PIANO).*
- *Si consiglia di consultare periodicamente il sito web ufficiale <http://www.viscountinstruments.com> per verificare la presenza di nuovi aggiornamenti.*

## APPENDICE

### Funzioni rapide

Nella seguente tabella sono descritte le funzioni che è possibile eseguire premendo i pulsanti del pannello frontale senza bisogno di accedere e scorrere le varie pagine a display. In caso di combinazione di due pulsanti, premere il primo pulsante indicato, quindi, tenendolo premuto, premere il secondo pulsante.

Combinazione pulsanti	Funzione	Spiegazione a pagina
<b>Pressione corta manopola selezione categoria REVERB</b>	Selezione del tipo di riverbero della categoria selezionata.	<a href="#">41</a>
<b>Pressione lunga manopola selezione categoria REVERB</b>	Accesso al menu che raccoglie tutti i parametri di regolazione del riverbero.	<a href="#">41</a>
<b>Pressione corta manopola selezione categoria EFFECTS</b>	Selezione del preset dell'effetto della categoria selezionata.	<a href="#">32</a>
<b>Pressione lunga manopola selezione categoria EFFECTS</b>	Accesso al menu che raccoglie tutti i parametri di regolazione dell'effetto.	<a href="#">32</a>
<b>[FX ON] + [ON/OFF] di un modulo</b>	Assegnazione dell'effetto al modulo.	<a href="#">42</a>
<b>[SPLIT] + [ON/OFF] di un modulo</b>	Attivazione della modalità Split, assegnazione ciclica del modulo alle parti Lower o Upper.	<a href="#">31</a>
<b>[SPLIT] + tasto tastiera</b>	Attivazione della modalità Split, impostazione del punto di Split.	<a href="#">31</a>
<b>[EXIT] + [&lt;] o [&gt;] in modalità Song</b>	Selezione delle List di Song.	<a href="#">49</a>
<b>Pressione lunga manopola o pulsanti selezione suoni di un modulo</b>	Accesso al menu che raccoglie tutti i parametri di regolazione del suono selezionato.	<a href="#">42</a> , <a href="#">44</a> , <a href="#">46</a> , <a href="#">45</a>
<b>Pressione lunga pulsante [TREM ON] del modulo E.PIANO</b>	Attivazione dell'effetto Tremolo e visualizzazione del parametro <i>Trem Wave</i> per la selezione della forma d'onda del segnale modulante.	<a href="#">43</a>
<b>Pressione lunga pulsante [AMP ON] del modulo E.PIANO</b>	Attivazione dell'effetto Amplificatore e visualizzazione del parametro <i>Amp Drive</i> per la regolazione della quantità di distorsione.	<a href="#">44</a>
<b>Pressione lunga pulsante [MUTE] del modulo CLAVI</b>	Attivazione del Mute e visualizzazione del parametro <i>Mute Value</i> per la regolazione del tempo di decadimento.	<a href="#">46</a>
<b>Pressione lunga manopola selezione messaggi MIDI del modulo EXTERNAL</b>	Accesso al menu che raccoglie tutti i parametri di regolazione del modulo.	<a href="#">47</a>

### Messaggi di errore

#### NOTA

A fianco dei messaggi di errore di seguito riportati viene indicato il Led della manopola per la selezione della categoria di effetto (pag. [9](#)) che viene acceso se il sistema non riesce a visualizzare il messaggio a display. Qualora il Led acceso non sia tra quelli riportati, contattare l'assistenza tecnica all'indirizzo [service@viscount.it](mailto:service@viscount.it).

#### Backup aborted!

Il sistema non riesce a salvare nell'unità flash USB il file di backup. Controllare che l'unità flash USB non sia protetta da scrittura, sia formattata con file system FAT32 e che non sia danneggiata.

#### Backup files not detected!

Nell'unità flash USB inserita non è presente nessun file di backup compatibile con lo strumento.

#### Corrupted update file! – Led [PHASER] o [WAH]

Il file di aggiornamento che si sta caricando presenta errori. Tentare di scaricare nuovamente dal sito [www.viscountinstruments.com](http://www.viscountinstruments.com) il file e ricopiarlo nell'unità flash USB, quindi ritentare l'operazione.

**Error in reading file! – Led [DELAY]**

Il sistema non riesce a leggere il file precedentemente selezionato. Verificare che l'unità flash USB sia correttamente inserita e che non sia danneggiata.

**INTERNAL ERROR #”X”**

Questi messaggi di errore vengono visualizzati all'accensione dello strumento qualora uno o più componenti interni non funzionino correttamente. In base al dispositivo ed al tipo di malfunzionamento, al posto della "X" viene visualizzato un numero ed a seguire la dicitura [Update required] o [Conctact service].

In caso di [Update required] il malfunzionamento potrebbe essere riparato con una nuova installazione del sistema operativo (pag. 61). Se al termine dello stesso viene di nuovo visualizzato lo stesso errore od in caso di messaggio con la dicitura [Contact service], è necessario contattare il servizio di assistenza tecnica all'indirizzo [service@viscount.it](mailto:service@viscount.it) indicando il messaggio di errore ed il numero visualizzato.

**Memory is protected!**

Non è possibile memorizzare il Program o la Song o caricare file di backup in quanto è stata attivata la funzione *Memory Lock* (pag. 58).

**Not recognized as backup file.**

Il file che si sta tentando di caricare non è un file di backup compatibile con *Legend '70s*.

**Restore aborted!**

Il file di backup che si sta caricando presenta errori. Tentare di ricopiare il file nell'unità flash USB, quindi ritentare l'operazione.

**Too many update files!**

Nell'unità flash USB inserita sono presenti più di un file di aggiornamento. Nella root dell'unità flash USB deve essere presente solo il file di aggiornamento alla versione desiderata.

**Update Failed. Error #”X”. [Please retry]**

L'aggiornamento del sistema operativo o dei moduli non è andato a buon fine. Spegnere e riaccendere lo strumento lasciando l'unità flash USB inserita in quanto lo strumento tenterà un nuovo aggiornamento. Se al termine dello stesso viene di nuovo visualizzato il messaggio di errore, contattare il servizio di assistenza tecnica all'indirizzo [service@viscount.it](mailto:service@viscount.it) indicando il messaggio di errore ed il numero visualizzato.

**Update file not detected! – 3 led lampeggianti**

Nell'unità flash USB inserita non è presente nessun file per l'aggiornamento del sistema operativo.

**USB charger active**

Si sta tentando di effettuare l'aggiornamento del sistema operativo ma la porta USB [TO DEVICE] è impostata per l'alimentazione / caricabatteria di un dispositivo esterno (pag. 58).

**USB charger OVERCURRENT [Extract device]**

Il dispositivo esterno che si sta tentando di caricare tramite la porta USB [TO DEVICE] sta assorbendo troppa corrente. Onde evitare malfunzionamenti la porta viene disattivata per 10 secondi, scollegare il dispositivo e verificare che non sia danneggiato.

**USB flash drive DAMAGED [Extract drive]**

L'unità flash USB collegata alla porta USB [TO DEVICE] non sta funzionando correttamente. Onde evitare malfunzionamenti la porta viene disattivata per 10 secondi, disinserire l'unità USB e verificare che non sia danneggiata.

**USB flash drive not detected!**

Non è inserita un'unità flash USB necessaria per l'operazione che si sta eseguendo. Se l'unità flash USB è presente, provare ad estrarla e reinserirla, controllare inoltre sia correttamente formattata con file system FAT32 e che non sia danneggiata.

**USB flash drive not detected! – 3 led lampeggianti**

Non è inserita un'unità flash USB necessaria per completare l'aggiornamento del sistema operativo. Se l'unità flash USB è presente, provare ad estrarla e reinserirla.

**Wrong backup file!**

Il file di backup che si sta tentando di caricare non è compatibile con lo strumento.

**Wrong format. Newer software is required**

Il file di backup che si sta tentando di caricare è stato generato con una versione del sistema operativo più recente di quella attualmente installata nello strumento. Aggiornare il proprio strumento all'ultima versione disponibile.

**Wrong update file!**

Il file di aggiornamento che si sta non è compatibile con lo strumento. Tentare di scaricare nuovamente dal sito [www.viscountinstruments.com](http://www.viscountinstruments.com) il file e ricopiarlo nell'unità flash USB, quindi ritentare l'operazione.

## Risoluzione ai problemi più comuni

**Lo strumento non si accende.**

- Controllare che il cavo di alimentazione sia collegato allo strumento e sia correttamente inserito nella presa di corrente.
- Assicurarsi che nella presa ci sia corrente.

**Lo strumento si è spento in modo imprevisto.**

- E' attiva la funzione *Auto Power Off*. Per disattivarla consultare pag. 58.

**Lo strumento non produce alcun suono.**

- Controllare che la manopola [MASTER VOLUME] non sia posizionato completamente a sinistra.
- L'impianto di diffusione esterno è spento o ha il volume al minimo.
- Controllare che il foot controller eventualmente collegato ed assegnato alla funzione Expression (pag. 29) non sia posizionato al minimo (completamente alzato).
- Controllare che i moduli non siano tutti spenti o con la manopola [VOLUME] completamente a sinistra.
- Il volume o l'espressione MIDI è stato impostato sul livello minimo da un controller MIDI esterno.

**Il suono è distorto.**

- Abbassare il volume.
- Si è aggiunto effetto di distorsione tramite gli effetti della categoria Amp. Se non si desidera avere distorsione, impostare il parametro *Drive* con valore 0 (pag. 37 e 44).

**Non viene udito alcun effetto.**

- Assicurarsi che il modulo che si sta suonando sia assegnato ad un effetto (pag. 42) e che lo stesso sia attivo (pag. 10).

**Lo scambio di dati con un computer collegato non funziona correttamente.**

- Assicurarsi che le impostazioni della porta del computer siano corrette.
- Assicurarsi che la funzione *MIDI Control Port* (pag. 56) sia stata impostata sull'interfaccia utilizzata (MIDI o USB).

**Impossibile salvare i dati nell'unità flash USB inserita.**

- Assicurarsi che l'unità flash USB non sia protetta da scrittura.
- Assicurarsi che l'unità flash USB sia formattata con file system FAT o FAT32 (no NTFS o altri).

## Lista dei preset degli effetti

Categorie REVERB	Preset
Room	Small Room, Large Room
Hall	Small Hall, Medium Hall, Large Hall
Stage	Stage 1, Stage 2
Plate	Medium Plate, Large Plate
Spring	Spring 1, Spring 2
Tape	Tape 1, Tape 2

Categorie EFFECTS	Preset
Tremolo	Custom, Stage Tremolo, Opto Tremolo, 1960s Tremolo, Light Tremolo, Wide Tremolo, Stereo Pan, Slicer Tremolo, Psych Tremolo, 1970s Vibrato, Modern VB-Z, 1960s Vibrato, Light Vibrato, Ghost Vibrato, Badoon Vibrato
Chorus	Custom, Stage Chorus, 1970s Chorus, St. Slow Chorus, Modern CH-Z, Light Chorus, Wide Chorus, Dream Chorus

<b>Flanger</b>	Custom, Stage Flanger, Stress-me I, Stress-me II, Gentle Flanger, Color Flanger, Dyn Flanger
<b>Phaser</b>	Custom, Stage Phaser, PH90, Modern Phaser, Deep Phaser, PH Deluxe, Spread Phaser
<b>Wah</b>	Custom, Cry Wah, Gun Wah, UK Wah, Drop Wah, AutoWah-1, AutoWah-2, AutoWah-3, AutoWah-4, Stage T-Wah, Q-Wah, LT-Wah
<b>Delay</b>	Custom, Short Tail, Long Tail, Neverending, Ping Pong, One Shot, Double Shot,
<b>Others - PEQ3</b>	Custom, Mid Boost, Mid Scoop, More Mids, Bass Eq, Ultra Bass
<b>Others - PEQ5</b>	Custom, Bright Eq, Dark Eq, AGuit Eq, Piano Eq, Funky Eq
<b>Others - GEQ5</b>	Custom, V-Mid, Hi Smooth, Bass Cut, Huge Bass, Light Eq
<b>Others - Comp</b>	Custom, Generic, Gentle, Acoustic, Precise, LeadGtr, Punchy, Loud, Brute
<b>Others - Rotary</b>	Custom, Clean, Jazz, Blues, Rock, Horn Mic, Basic, Fat Drum

## Lista dei suoni Sound Collection

Categoria	#	Suono	Knob 1	Knob 2	Knob 3
<b>Pad</b>	1	Warm Pad	Filter Cutoff	Attack Time	Release Time
	2	Reso Pad	Filter Cutoff	Attack Time	Release Time
	3	Square Pad	Filter Cutoff	Attack Time	Release Time
	4	Poly Pad	Filter Cutoff	Attack Time	Release Time
	5	Sweep Pad	Filter Cutoff	Attack Time	Release Time
	6	Dark Pad	Filter Cutoff	Attack Time	Release Time
	7	DSS Pad	Filter Cutoff	Attack Time	Release Time
	8	DSS Octa Pad	Filter Cutoff	Attack Time	Release Time
	9	DSS Smooth	Filter Cutoff	Attack Time	Release Time
	10	LFO Pad	Filter Cutoff	Attack Time	Release Time
	11	Slow ResoPad	Filter Cutoff	Attack Time	Release Time
<b>Strings</b>	1	Str Ensemble	Filter Cutoff	Attack Time	Release Time
	2	Dyna Strings	Filter Cutoff	Attack Time	Release Time
	3	Octa Strings	Filter Cutoff	Attack Time	Release Time
	4	Med Ensemble	Filter Cutoff	Attack Time	Release Time
	5	Pizzicato	Filter Cutoff	Decay Time	Release Time
	6	Trio Concert	Filter Cutoff	Attack Time	Release Time
	7	Solina Violin	Filter Cutoff	Attack Time	Release Time
	8	Solina Duo	Filter Cutoff	Attack Time	Release Time
	9	Crumar Perf.	Filter Cutoff	Attack Time	Release Time
	10	PWM Strings	Filter Cutoff	Attack Time	Release Time
	11	PWM Decay	Filter Cutoff	Decay Time	Release Time
<b>Choir</b>	1	Choir Oohs	Filter Cutoff	Attack Time	Release Time
	2	Soft Aahs	Filter Cutoff	Attack Time	Release Time
	3	Choir Oohs	Filter Cutoff	Attack Time	Release Time
	4	Gregorian	Filter Cutoff	Attack Time	Release Time
	5	Boys Aahs	Filter Cutoff	Attack Time	Release Time
	6	Gospel Aahs	Filter Cutoff	Attack Time	Release Time
	7	Gospel Uuhs	Filter Cutoff	Attack Time	Release Time
	8	Gospel Dooh	Filter Cutoff	Attack Time	Release Time
	9	Gospel Bah	Filter Cutoff	Attack Time	Release Time
	10	Soul Uuhs	Filter Cutoff	Attack Time	Release Time
	11	Soul Mmh	Filter Cutoff	Attack Time	Release Time
<b>Brass</b>	1	Big Band	Filter Cutoff	Attack Time	Release Time
	2	Brass Band	Filter Cutoff	Attack Time	Release Time
	3	Brass Falls	Filter Cutoff	Attack Time	Release Time
	4	Soul Horns	Filter Cutoff	Attack Time	Release Time
	5	Vintage Horns	Filter Cutoff	Attack Time	Release Time
	6	Brass Section	Filter Cutoff	Attack Time	Release Time
	7	Soft Horns	Filter Cutoff	Attack Time	Release Time
	8	Sax Section	Filter Cutoff	Attack Time	Release Time
	9	Symph Brass	Filter Cutoff	Attack Time	Release Time
	10	Mellow Horns	Filter Cutoff	Attack Time	Release Time
	11	French Horns	Filter Cutoff	Attack Time	Release Time
	12	SynBrass '82	Filter Cutoff	Attack Time	Release Time
	13	SynBrass '84	Filter Cutoff	Attack Time	Release Time
	14	OB Brass	Filter Cutoff	Attack Time	Release Time
	15	OB Smooth	Filter Cutoff	Attack Time	Release Time
	16	PWM Brass	Filter Cutoff	Attack Time	Release Time
	17	Fat Brass	Filter Cutoff	Attack Time	Release Time

<b>Keys</b>	1	Grand Piano	Attack Time	Decay Time	Release Time
	2	Bright Piano	Attack Time	Decay Time	Release Time
	3	House Piano	Filter Cutoff	Attack Time	Release Time
	4	Electric Grand	Attack Time	Release Time	Efx Send
	5	Digital '80	Filter Cutoff	Release Time	Efx Send
	6	Mark 73	Filter Cutoff	Efx Rate	Efx Depth
	7	Wurli 140B	Filter Cutoff	Efx Rate	Efx Depth
	8	DX Memories	Filter Cutoff	Attack Time	Release Time
	9	Full Tines	Filter Cutoff	Attack Time	Release Time
	10	Crystal EP	Filter Cutoff	Attack Time	Release Time
	11	Harpsichord	Filter Cutoff	Attack Time	Release Time
	12	Clavinet	Filter Cutoff	Attack Time	Release Time
	13	Velo Duck	Filter Cutoff	Attack Time	Release Time
	14	Accordion	Filter Cutoff	Attack Time	Release Time
	15	Bandeon	Filter Cutoff	Attack Time	Release Time
	16	Musette	Filter Cutoff	Attack Time	Release Time
<b>Organ</b>	1	Jazz Organ	Percussion	Rotary Speed	Rotary
	2	Even Bars	Percussion	Rotary Speed	Rotary
	3	Bright Organ	Percussion	Rotary Speed	Rotary
	4	Full Bars	Percussion	Rotary Speed	Rotary
	5	Gospel Organ	Percussion	Rotary Speed	Rotary
	6	Lower Man	Percussion	Rotary Speed	Rotary
	7	Vox Organ 1	High Bars	Release Time	Vibrato Depth
	8	Vox Organ 2	High Bars	Release Time	Vibrato Depth
	9	Transistor	Filter Cutoff	Release Time	Vibrato Depth
	10	Bourdon 8'	Filter Cutoff	Attack Time	Release Time
	11	Principal 8'	Filter Cutoff	Attack Time	Release Time
	12	Voce Umana	Filter Cutoff	Attack Time	Release Time
	13	Principal 8'+4'	Filter Cutoff	Attack Time	Release Time
	14	Plenum 8'	Filter Cutoff	Attack Time	Release Time
	15	Plenum 16'	Filter Cutoff	Attack Time	Release Time
<b>Bass</b>	1	Acoustic Bass	Attack Time	Release Time	Efx Send
	2	Fingered Bass	Filter Cutoff	Release Time	Release Noise
	3	Picked Bass	Filter Cutoff	Attack Time	Release Time
	4	Fretless Bass	Filter Cutoff	Attack Time	Release Time
	5	Sting Bass	Filter Cutoff	Attack Time	Release Time
	6	Slap Bass	Filter Cutoff	Attack Time	Release Time
	7	Synth Bass 1	Filter Cutoff	Attack Time	Release Time
	8	Synth Bass 2	Filter Cutoff	Attack Time	Release Time
	9	Synth Bass 3	Filter Cutoff	Attack Time	Release Time
	10	Synth Bass 4	Filter Cutoff	Attack Time	Release Time
	11	Synth Bass 5	Filter Cutoff	Attack Time	Release Time
	12	Synth Bass 6	Filter Cutoff	Attack Time	Release Time
<b>Others</b>	1	Nylon Guitar	Filter Cutoff	Attack Time	Release Time
	2	Ac. Guitar	Filter Cutoff	Attack Time	Release Time
	3	Steel Guitar	Filter Cutoff	Attack Time	Release Time
	4	12 Strings	Filter Cutoff	Attack Time	Release Time
	5	Jazz Guitar	Filter Cutoff	Release Time	Efx Send
	6	Clean Guitar	Filter Cutoff	Release Time	Efx Send
	7	Neck Pickup	Filter Cutoff	Release Time	Efx Send
	8	Muted Guitar	Filter Cutoff	Decay Time	Release Time
	9	Vibes	Filter Cutoff	Decay Time	Release Time
	10	Marimba	Filter Cutoff	Decay Time	Release Time
	11	Xylophone	Filter Cutoff	Attack Time	Release Time
	12	Steel Drum	Filter Cutoff	Attack Time	Release Time
	13	Celesta	Filter Cutoff	Decay Time	Release Time
	14	Bells	Filter Cutoff	Decay Time	Release Time
	15	Wood Bells	Filter Cutoff	Decay Time	Release Time
	16	Glockenspiel	Filter Cutoff	Decay Time	Release Time

**Smaltimento dei rifiuti elettrici ed elettronici (applicabile nell'Unione Europea e negli altri paesi europei con servizio di raccolta differenziata)**

**Ai sensi dell'art. 13 del Decreto legislativo 25 luglio 2005, n. 151 "Attuazione delle Direttive 2002/95/CE, 2002/96/CE e 2003/108/CE"**



Il simbolo presente sul prodotto o sulla sua confezione indica che il prodotto non verrà trattato come rifiuto domestico. Sarà invece consegnato al centro di raccolta autorizzato per il riciclo dei rifiuti elettrici ed elettronici. Assicurandovi che il prodotto venga smaltito in modo adeguato, eviterete un potenziale impatto negativo sull'ambiente e la salute umana, che potrebbe essere causato da una gestione non conforme dello smaltimento del prodotto. Il riciclaggio dei materiali contribuirà alla conservazione delle risorse naturali. Per ricevere ulteriori informazioni più dettagliate Vi invitiamo a contattare l'ufficio preposto nella Vostra città, il servizio per lo smaltimento dei rifiuti o il negozio in cui avete acquistato il prodotto.

Lo smaltimento del prodotto da parte dell'utente comporta l'applicazione delle sanzioni amministrative previste dalla normativa di legge.



Questo prodotto è conforme ai requisiti delle direttive EMCD 2004/108/EC e LVD 2006/95/EC.

## MIDI INFORMATIONS

### What is MIDI

The MIDI (Musical Instrument Digital Interface) allows instruments of different makes and types to communicate with each other by means of this clearly specified protocol of codes. This makes it possible to create systems of MIDI instruments which offer much better versatility and control than can be achieved with separate instruments. To make this communication possible, all MIDI instruments are equipped with two or three 5 pin DIN connectors marked:

- **MIDI IN:** By means of this connector, the device receives the MIDI data emitted by other units.
- **MIDI OUT:** By means of this connector, the device sends the MIDI data it has generated to other units.
- **MIDI THRU:** This connector, used to connect several units in series, emits the MIDI data exactly as they are received by the respective MIDI IN port.

**N.B.:** Legend '70s is not equipped with the MIDI THRU connector. However, a Thru software function is available.

For example, most instruments equipped with MIDI interface transmit MIDI messages which specify which note has been played and with what velocity by means of the MIDI OUT connector. If this connector is connected to the MIDI IN of another MIDI instrument, such as a synthesiser or an expander, the connected instrument will give a precise response to the notes played on the transmitter instrument. This allows you actually to play two instruments at the same time, and obtain special multi-instrument sounds. The same type of transfer of information is used to record MIDI sequences. A sequencer can be used to record the MIDI data transmitted by the *Legend '70s*. When these recorded data are sent to the *Legend '70s*, it will automatically play back the recorded performance.

### MIDI Channels

The MIDI is able to transmit a multitude of digital data by means of a single cable and thus a single connector, thanks to the MIDI channels. There are 16 MIDI channels, so MIDI messages are processed when the channels of the receiver and transmitter instruments are the same. *Legend '70s* transmits and receives MIDI data in the channel setted with the *Global Channel* parameter in the *SYSTEM / MIDI SETTINGS* section.

## Main MIDI messages transmitted and received by the Legend '70s

### CHANNEL MESSAGES

#### NOTE ON

This message is transmitted when a keyboard note is pressed. Each Note On contains the following data:

*Note On:* when the key has been pressed;

*Note Number:* which key and therefore note has been pressed;

*Velocity:* dynamic, that is, the quantity of pressure on the key.

Note numbers vary between 0 and 127; the central C corresponds to number 60.

Data format: 9nH kkH vvH

n=channel number: 00H - 0FH (1 - 16)

kk=note number: 00H - 7FH (0 - 127)

vv=note on velocity: 01H - 7FH (1 - 127)

00H (0) Note Off

#### NOTE OFF

This message is transmitted when a key is released. When the message is received, the corresponding sound stops. A Note Off message contains the following data:

*Note Off:* a key has been released;

*Note Number:* which key has been released;

*Velocity:* dynamic, that is, energy of the release.

Data format: 8nH kkH vvH  
9nH kkH 00H

n=channel number: 00H - 0FH (1 - 16)

kk=note number: 00H - 7FH (0 - 127)

vv=note off velocity: 00H - 7FH (0 - 127)

**NB:** if a Note On message has Velocity=0, it counts as a Note Off message.

## CONTROL CHANGE

These are control messages (often associated to trimmers or pedals) used to add expression to the performance, allowing you to set (and control in real time if necessary) voice parameters such as volume (CC n.7) or the position of the swell pedals (CC n.11), etc.

This message contains the following information:

*Control Change:* a controller has been adjusted

*Controller Number:* which controller has been adjusted

*Controller Position:* the position of the controller

Data format: BnH 00H vvH

n=channel number: 00H - 0FH (1 - 16)

vv=controller number: 00H - 7FH (0 - 127)

vv=value: 00H - 7FH (0 - 127)

## PROGRAM CHANGE

This message selects sounds or programs on the receiving instrument.

The sounds recalled by each Program Change message is described by the General MIDI standard. Usually, the recalled sounds can be found on a chart included in the User Manual of instruments using this standard.

This message contains the following data:

*Program Change:* change sound or program;

*Program Change Number:* the number of sound/program that has to be activated;

Data format: CnH mmH

n=channel number: 00H - 0FH (1 - 16)

mm=Program Change number: 00H - 7FH (0 - 127)

## PITCH BEND

This continuous control message bends the instrument's pitch upwards or downwards.

Data format: EnH vvH

n=channel number: 00H - 0FH (1 - 16)

vv=value: 00H - 7FH (0 - 127)

## CHANNEL AFTERTOUCH

This message controls the sound according to the pressure on the key. Only one value is transmitted through the channel; therefore the said value is the same for all notes, and is set by the last key pressed.

Data format: DnH vvH

n=channel number: 00H - 0FH (1 - 16)

vv=value: 00H - 7FH (0 - 127)

**NB:** in the Legend '70s the Aftertouch message can be transmitted using a foot controller or modulation wheel (see FC1, FC2 and Mod.Wheel Dest parameters in the EDIT / COMMON section).

## SYSTEM MESSAGES

### ACTIVE SENSING

Active Sensing is a type of MIDI message used to prevent unexpected results in the event that a MIDI cable is disconnected or damaged while the instrument is being played. Upon the receipt of an Active Sensing message, the stage piano will begin to monitor the status of connected MIDI cables. If no MIDI data is received over the next 300 ms, the Legend '70s will conclude that a problem has occurred with a MIDI cable, and in response, it turns off all notes.

### TIMING CLOCK

Timing Clock messages are transmitted at a fixed interval (i.e., 24 times per 1/4 note) to synchronize connected MIDI instruments. Use the *Master Clock* parameter in the *EDIT / COMMON* section to specify whether the instrument's internal clock or Timing Clock messages received via the MIDI [IN] terminal should be used for synchronization.

# List of MIDI messages transmitted and received by the Legend '70s

Message	Parameter	Value Range	Message	Parameter	Value Range
Program Change	Program selection	1-128	CC 47	SOUND COLLECTION Part1 Knob2 parameter	0-127
PitchBend	Pitch wheel	0-127	CC 48	SOUND COLLECTION Part1 Knob3 parameter	0-127
Aftertouch	When associated to FC1, FC2 or modulation wheel. NB: this message is only transmitted	0-127	CC 49	SOUND COLLECTION Part2 On/Off	≤63 off, ≥64 on
CC 1	Modulation wheel	0-127	CC 50	SOUND COLLECTION Part2 Volume	0-127
CC 4	[FOOT CONTROLLER 2] pedal	0-127	CC 51	SOUND COLLECTION Part2 Category	0-7
CC 11	[FOOT CONTROLLER 1] pedal	0-127	CC 52	SOUND COLLECTION Part2 Timbre	0-X (number of sounds depends on the family)
CC 12	E.PIANO On/Off	≤63 off, ≥64 on	CC 53	SOUND COLLECTION Part2 Knob1 parameter	0-127
CC 13	E.PIANO Volume	0-127	CC 54	SOUND COLLECTION Part2 Knob2 parameter	0-127
CC 14	E.PIANO Timbre	0-7	CC 55	SOUND COLLECTION Part2 Knob3 parameter	0-127
CC 15	E.PIANO Bass	0-127	CC 64	[SUSTAIN] pedal	≤63 off, ≥64 on (switch) 0-127 (half damper)
CC 16	E.PIANO Treble	0-127	CC 66	[FOOT SWITCH 2] pedal	≤63 off, ≥64 on
CC 17	E.PIANO Tremolo On/Off	≤63 off, ≥64 on	CC 67	[FOOT SWITCH 1] pedal	≤63 off, ≥64 on
CC 18	E.PIANO Tremolo Intensity	0-127	CC 80	REVERB On/Off	≤63 off, ≥64 on
CC 19	E.PIANO Tremolo Speed	0-127	CC 81	REVERB Type	0-15 Rooms 16-31 Halls 32-47 Stages 48-63 Plates 64-79 Springs 80-95 Tapes
CC 20	E.PIANO Amp On/Off	≤63 off, ≥64 on	CC 82	FX1 Switch	≤63 off, ≥64 on
CC 25	A.PIANO On/Off	≤63 off, ≥64 on	CC 83	FX1 Category	0 Tremolo 1 Chorus 2 Flanger 3 Phaser 4 Wah 5 Amp 6 Delay 7 Others / PEQ3 8 Others / PEQ5 9 Others / GEQ5 10 Others / Comp 7 Others / Rotary
CC 26	A.PIANO Volume	0-127	CC 84	FX1 Preset	0-X (it depends on the number of presets in each category)
CC 27	A.PIANO Timbre	0-7	CC 85	FX1 [TAP] parameter	0-127
CC 28	A.PIANO Dynamic	0-127	CC 87	FX2 Switch	≤63 off, ≥64 on
CC 29	A.PIANO Brilliance	0-127	CC 88	FX2 Category	0 Tremolo 1 Chorus 2 Flanger 3 Phaser 4 Wah 5 Amp 6 Delay 7 Others / PEQ3 8 Others / PEQ5 9 Others / GEQ5 10 Others / Comp 7 Others / Rotary
CC 32	Program Selection	0 Program A01-H16 1 Program I01-P16	CC 89	FX2 Preset	0-X (it depends on the number of presets in each category)
CC 33	CLAVI On/Off	≤63 off, ≥64 on	CC 90	FX2 [TAP] parameter	0-127
CC 34	CLAVI Volume	0-127	CC 91	REVERB Dry/Wet	0-127
CC 35	CLAVI Timbre	0-1	CC 92	FX1 [AMOUNT] parameter	0-127
CC 36	CLAVI Brilliant, Treble, Medium, Soft, C D, A B	See CLAVI timbre controls table	CC 93	FX2 [AMOUNT] parameter	0-127
CC 37	CLAVI Mute	≤63 off, ≥64 on	CC 94	FX1 [RATE] parameter	0-127
CC 42	SOUND COLLECTION Part1 On/Off	≤63 off, ≥64 on	CC 95	FX2 [RATE] parameter	0-127
CC 43	SOUND COLLECTION Part1 Volume	0-127	CC 120	All Sound Off. See N.B.	0-127
CC 44	SOUND COLLECTION Part1 Category	0-7	CC 121	Reset All Controllers. See N.B.	0-127
CC 45	SOUND COLLECTION Part1 Timbre	0-X (number of timbres depends on the family)	CC 123	All Notes Off. See N.B.	0-127
CC 46	SOUND COLLECTION Part1 Knob1 parameter	0-127			

**N.B.**

- *Reset All Controllers message sets the following parameters:*  
*Pitch Bend = 00 64*  
*Expression (CC 11) = 127*  
*Sustain (CC 64) = Off*  
*This message is received only.*
- *All Sound Off message mutes all sounds regardless of whether the Sustain pedal is on. This message is received only.*
- *All Notes Off message sets off all notes on. This message is received only.*

**CLAVI timbre controls**

BRILLIANT	TREBLE	MEDIUM	SOFT	CC 37 value
OFF	OFF	OFF	OFF	0 ( <b>C D OFF, A B OFF</b> ) 16 ( <b>C D ON, A B OFF</b> ) 32 ( <b>C D OFF, A B ON</b> ) 48 ( <b>C D ON, A B ON</b> )
ON	OFF	OFF	OFF	1 ( <b>C D OFF, A B OFF</b> ) 17 ( <b>C D ON, A B OFF</b> ) 33 ( <b>C D OFF, A B ON</b> ) 49 ( <b>C D ON, A B ON</b> )
OFF	ON	OFF	OFF	2 ( <b>C D OFF, A B OFF</b> ) 18 ( <b>C D ON, A B OFF</b> ) 34 ( <b>C D OFF, A B ON</b> ) 50 ( <b>C D ON, A B ON</b> )
ON	ON	OFF	OFF	3 ( <b>C D OFF, A B OFF</b> ) 19 ( <b>C D ON, A B OFF</b> ) 35 ( <b>C D OFF, A B ON</b> ) 51 ( <b>C D ON, A B ON</b> )
OFF	OFF	ON	OFF	4 ( <b>C D OFF, A B OFF</b> ) 20 ( <b>C D ON, A B OFF</b> ) 36 ( <b>C D OFF, A B ON</b> ) 52 ( <b>C D ON, A B ON</b> )
ON	OFF	ON	OFF	5 ( <b>C D OFF, A B OFF</b> ) 21 ( <b>C D ON, A B OFF</b> ) 37 ( <b>C D OFF, A B ON</b> ) 53 ( <b>C D ON, A B ON</b> )
OFF	ON	ON	OFF	6 ( <b>C D OFF, A B OFF</b> ) 22 ( <b>C D ON, A B OFF</b> ) 38 ( <b>C D OFF, A B ON</b> ) 54 ( <b>C D ON, A B ON</b> )
ON	ON	ON	OFF	7 ( <b>C D OFF, A B OFF</b> ) 23 ( <b>C D ON, A B OFF</b> ) 39 ( <b>C D OFF, A B ON</b> ) 55 ( <b>C D ON, A B ON</b> )
OFF	OFF	OFF	ON	8 ( <b>C D OFF, A B OFF</b> ) 24 ( <b>C D ON, A B OFF</b> ) 40 ( <b>C D OFF, A B ON</b> ) 56 ( <b>C D ON, A B ON</b> )
ON	OFF	OFF	ON	9 ( <b>C D OFF, A B OFF</b> ) 25 ( <b>C D ON, A B OFF</b> ) 41 ( <b>C D OFF, A B ON</b> ) 57 ( <b>C D ON, A B ON</b> )
OFF	ON	OFF	ON	10 ( <b>C D OFF, A B OFF</b> ) 26 ( <b>C D ON, A B OFF</b> ) 42 ( <b>C D OFF, A B ON</b> ) 58 ( <b>C D ON, A B ON</b> )
ON	ON	OFF	ON	11 ( <b>C D OFF, A B OFF</b> ) 27 ( <b>C D ON, A B OFF</b> ) 43 ( <b>C D OFF, A B ON</b> ) 59 ( <b>C D ON, A B ON</b> )
OFF	OFF	ON	ON	12 ( <b>C D OFF, A B OFF</b> ) 28 ( <b>C D ON, A B OFF</b> ) 44 ( <b>C D OFF, A B ON</b> ) 60 ( <b>C D ON, A B ON</b> )
ON	OFF	ON	ON	13 ( <b>C D OFF, A B OFF</b> ) 29 ( <b>C D ON, A B OFF</b> ) 45 ( <b>C D OFF, A B ON</b> ) 61 ( <b>C D ON, A B ON</b> )
OFF	ON	ON	ON	14 ( <b>C D OFF, A B OFF</b> ) 30 ( <b>C D ON, A B OFF</b> ) 46 ( <b>C D OFF, A B ON</b> ) 62 ( <b>C D ON, A B ON</b> )
ON	ON	ON	ON	15 ( <b>C D OFF, A B OFF</b> ) 31 ( <b>C D ON, A B OFF</b> ) 47 ( <b>C D OFF, A B ON</b> ) 63 ( <b>C D ON, A B ON</b> )

## MIDI IMPLEMENTATION CHART

**Viscount Legend '70s**

Version: 1.0  
Date: 08 Jun. 2020

FUNCTION...		TRANSMITTED	RECEIVED	REMARKS
<b>BASIC CHANNEL</b>	Default Changed	1 *****	1 *****	*1
<b>MODE</b>	Default Messages Altered	Mode 3 ***** *****	Mode 3 ***** *****	
<b>NOTE NUMBER</b>		0÷127	0÷127	
<b>VELOCITY</b>	Note ON Note OFF	O O	O O	*1
<b>AFTER TOUCH</b>	Key's Ch's	X O	X X	
<b>PITCH BENDER</b>		O	O	
<b>CONTROL CHANGE</b>		O	O	*1
<b>PROGRAM CHANGE</b>	True#	O	O	*1
<b>SYSTEM EXCLUSIVE</b>		O	O	
<b>SYSTEM COMMON</b>	Song Pos Song Sel Tune	X X X	X X X	
<b>SYSTEM REAL TIME</b>	Clock Commands	X X	X X	
<b>AUX MESSAGES</b>	Local On-Off All notes off Active Sense Reset	X O O X	X O O X	
<b>NOTES:</b>				
*1: for further informations see "MIDI Informations" chapter.				

Mode 1: Omni On, Poly  
Mode 3: Omni Off, Poly

Mode 2: Omni On, Mono  
Mode 4: Omni Off, Mono

O=YES  
X=NO







VISCOUNT

**Viscount International S.p.A.**

Via Borgo, 68 / 70 – 47836 Mondaino (RN), ITALY

**Tel:** +39-0541-981700 **Fax:** +39-0541-981052

**Website:** [www.viscountinstruments.com](http://www.viscountinstruments.com)